

Cantel Mobitex


Doc No 52/1056 - A 296	5171/2 Ue
Issue Date 1990-02-23	Rev A F. File MTS09B.2

14 LOGOUT

The A-party generates 'LOGOUT' according to the criteria and with the structure stated in Appendix A.

Dialogue 14.1:

Subscription initiates log-out.




Dialogue 14.2:

Network initiates logout.

The subscription has sent a LOGINREQ from a terminal but is still registered as logged-in to another terminal. The network will then send LOGOUTORD to the old terminal according to the criteria and with the format stated in Appendix A.

The personal subscription should immediately be deleted from the B-party's flexlist.



If the network has sent a LOGOUTORD and the old terminal did not receive it, the LOGOUTORD is repeated when the subscriber sends a message next time.

BilKart

Reprod

A 292 5153-3

Cantel Mobitex


Doc No.	52/1056 - A 296 5171/2 Ue
Doc. Date	1990-02-23 A
Doc. No.	MTS09B.2

15 ACTIVATION

The A-party generates 'ACTIVE' according to the criteria and with the format stated in Appendix A.


Dialogue 15.1:

Activation is approved and the mailbox is empty.



Dialogue 15.2:

Activation is approved and there are packets in the mailbox, both for the terminal and the personal subscription.



MSG 1 and 2 are packets (MPAK) that has been stored in the network mailbox while the terminal has been inactive. Each packet sent out from the mailbox is delayed a certain time in order not to overload the terminal.

Blockers

Regres

A.202 51553

Cantel Mobitex


No. 52/1056 - A 296	5171/2 Ue
Deposited Date 1990-02-23	1 Set A MTS09B.2

16 INACTIVATION

The A party generates 'INACTIVE' according to the criteria and with the format stated in Appendix A.

Dialogue 16.1:

Inactivation.



Revised

Revised

A 297 51553

Cantel Mobitex

Doc No
52/1056 - A 296 5171/2 Ue
Series Date Rev
1990-02-23 A F. No
MTS09B.2


17 DIE - LIVE

The network generates 'DIE' and 'LIVE' according to the criteria and with the format stated in Appendix A.

when the terminal receives 'DIE' it is not allowed to send any user traffic to the network, until a 'LIVE' has been received. User traffic is defined as packets included in the packet classes; PSUBCOM, PSOSCOM and CSUBCOM. The terminal may send DTESERV packets.

Dialogue 17.1:


The terminal may not send user traffic.



'DIE' is stored in the network mailbox if the B-party is not active. The packet is sent out according to Dialogue 15.2 when the B party is active again.

Dialogue 17.2 :

The terminal may send packets again.



'LIVE' is stored in the network mailbox if the B-party is not active. The packet is sent out according to dialogue 15.2 when the B-party is active again.

Diagrams

Diagram

Cantel Mobitex


Doc No: 52/1056 - A 296 5171/2 Ue
 Edition Date: 1990-02-23 A
 Rev: 1
 P. No: MTS09B.2

18 ROAMING

Dialogue 18.1:

The network requests the terminal to send a ROAM packet.


The network generates 'ROAMORD' according to the criteria and with the format stated in Appendix A.



The B-party generates 'ROAM' 2 according to the criteria and with the format stated in Appendix A.

Dialogue 18.2:

The A-party generates 'ROAM' spontaneously according to the criteria and with the format stated in Appendix A. A spontaneous generation of a ROAM packet is initiated from the roaming procedure described in the mobile terminal data link layer.



Bildzeit

Repro

A 292 51552

Cantel Mobitex

No. 52/1056 - A 296 5171/2 Ue						
<table border="1"> <tr> <td>Version Date</td> <td>Rev</td> <td>File No</td> </tr> <tr> <td>1990-02-23</td> <td>A</td> <td>MTS09B.2</td> </tr> </table>	Version Date	Rev	File No	1990-02-23	A	MTS09B.2
Version Date	Rev	File No				
1990-02-23	A	MTS09B.2				


19 RE-DIRECTION OF EMERGENCY MESSAGES

This is used when the emergency messages should be sent to the alternative emergency receiver.

The A party generates 'VICESOSRX' according to the criteria and with the format stated in Appendix A.


Dialogue 19.1:

The re-direction is approved.



Dialogue 19.2:

The 'VICESOSRX' is returned from the network.



- a) Re-direction cannot/may not take place.
'VICESOSRX' 2 is returned with traffic state =ILLEGAL
- b) The network is overloaded.
'VICESOSRX' 2 is returned with traffic state = CONGEST
- c) A technical fault may have occurred.
'VICESOSRX' 2 is returned with traffic state = ERROR

Editors

Revises


Cantel Mobitex

Doc. No. 52/1056 - A 296 5171/2 Ue
Issue Date 1990-02-23
Rev. A
Ed. No. MTS09B.2

20 CANCEL RE-DIRECTION OF EMERGENCY MESSAGES


Dialogue 20.1:

The re-direction is cancelled.



Dialogue 20.2:

The cancellation of the re-direction cannot/may not be accepted.



'SOSRX' 2 is returned with traffic state = ILLEGAL

Signature

Revised

A 792 51533


Cantel Mobitex

No. 54	52/1056 - A 296 5171/2 Ue	
Date - Date	Rev	PC File
1990-02-23	A	MTS09B.2

21 UPDATING GROUPLIST

Dialogue 21.1:

The network generates 'GROUPLIST' according to the criteria and with the format stated in Appendix A.



'GROUPLIST' is stored in the network mailbox if the B party is not active. The packets are sent out according to dialogue 15.2 when the B party is active again.

Bitkart

Repro

A 1985153/0


Cantel Mobitex

Doc No. 52/1056 - A 296 5171/2.0e
Issue Date 1990-02-23 Ver. A Ed. Rev. MTS09B.2

22 UPDATING THE LIST OF PERSONAL SUBSCRIPTIONS

Dialogue 22.1:


The network generates 'FLEXREQ' according to the criteria and with the format stated in Appendix A.



'FLEXLIST' is generated according to the criteria and with the format stated in Appendix A.

Dialogue 22.2:

The network generates 'FLEXLIST' according to the criteria and with the format stated in Appendix A.



'FLEXLIST' is stored in mailbox if the B party is not active. The packet is sent out according to dialogue 15.2 when the B party is active again.

Didakt

Repro


Cantel Mobitex -

St. No.	52/1056 - A 296 5171/2 Ue
Station Date	1990-02-23 A
St. No.	MTS09B.2

23 TECHNICAL INFORMATION

Dialogue 23.1:


The network generates 'INFOREQ' according to the criteria and with the format stated in Appendix A.



24 TIME INFORMATION

Dialogue 24.1:

The network generates 'TIME' according to the criteria and with the format stated in Appendix A.



000000

Reproce

A 292 51532


Cantel Mobitex

No. 52/1056 - A 296	5171/2 Use
Issue Date 1990-02-23	Rev. A
File No. MTS09B.2	

25 UPDATING AREALIST

Dialogue 25.1:

The network generates 'AREALIST' according to the criteria and with the format stated in Appendix A.




'AREALIST' is stored in the network mailbox if the B party is not active. The packets are sent out according to dialogue 15.2 when the B party is active again.

26 ELECTRONIC SERIAL NUMBER CHECK

Dialogue 26.1:

The network generates 'ESNREQ' according to the criteria and with the format stated in Appendix A.



Billett

Repond

Product Name ET/SYS PES	Product Name ET/SYS PES	St. No. 53/1056-A 296 5171/2 Ue	
Document Name ET/SYSC STT <i>ST</i>		Issue Date 1990-02-23	Rev. A MTS09C.2
Description Cantel Mobitex		Title MOBITEX Network layer for terminals Appendix C. Logical description	
<p><u>ABSTRACT</u></p> <p>This document contains the logical description for the network layer for <u>mobile terminals</u> connected to the MOBITEX system.</p>			
<p>Sidebars</p> <p>Reprod</p>			

Cantel Mobitex

53/1056-A 296 5171/2 Ue

1990-02-23 A MTS09C.2

TABLE OF CONTENTS

1	GENERAL	3
1.1	DATA FLOW DIAGRAM	3
1.2	TERMINOLOGY	4
1.3	RETURNED MPAK WITH CODE	8
1.4	STATES	9
1.5	STATE DIAGRAM	10
1.6	QUEUE HANDLING	11
2	LOGICAL DESCRIPTION	12
2.1	Start of program	12
2.1.1	P LOOK FOR EMERGENCY	14
2.2	P MPAK FROM APP	15
2.2.1	P CHECK FORMAT	18
2.2.2	P CHECK AND SEND DTESERV	18
2.2.3	P CHECK AND SEND CSUBCOM	19
2.3	P MPAK TO RETRANSMIT	20
2.4	P REC MPAK FROM LINK	21
2.4.1	P UNKNOWN HANDLING NORMAL	21
2.4.2	P REC MPAK DTESERV FROM LINK NORMAL	22
2.4.2.1	P GET REC MAN	24
2.4.3	P REC MPAK CSUBCOM FROM LINK	24
2.4.3.1	P REC MPAK CSUBCOM FROM LINK_IDLE	25
2.4.3.2	P UNKNOWN HANDLING CSUBCOM	26
2.4.3.3	P REC MPAK CSUBCOM FROM LINK DIE	26
2.4.3.4	P REC MPAK CSUBCOM FROM LINK_WAIT	27
2.4.3.5	P REC MPAK CSUBCOM FROM LINK_SPEECH	28
2.5	P MPAK TRANSMITTED	29
2.6	P MPAK NOT TRANSMITTED	30
2.7	P HOOK ON HANDLING	31
2.8	P TIMEOUT HANDLING	32
2.9	P HOOK OFF HANDLING	33
2.10	P ROAMING HANDLING	33
2.11	P ACTIVATION HANDLING	34
2.12	P ACTIVATION HANDLING LINK	34
2.13	P ACTIVATION TIMEOUT HANDLING	34
2.14	P POWER OFF HANDLING	35
2.15	P MANUAL MODE ON HANDLING	35
2.16	P BUFFER_FULL HANDLING	36
3	MOBITEX TERMINAL SPECIFICATION REFERENCE LIST	37

Blockout

Supra


Cantel Mobitex™

Rev. No. 53/1056-A 296 5171/2 Ue
 Revision Date 1990-02-23 1 Rev. A File No. MTS09C.2

1 GENERAL

1.1 DATA FLOW DIAGRAM

The data flow diagram below shows the interaction between the network layer and the other two layers; the data link layer and the application layer.



Signals to/from Data Link Layer.

- 1- MPAK transmitted, MPAK_not_transmitted, MPAK_received, roaming, activation
- 2- MPAK to transmit, MPAK to retransmit, speech_on, speech_off, order to return MPAK, group_list_information, area_list_information

Signals to/from Application Layer.

- 3- MPAK_received, returned_MPAK_with_code, die, live, buffer_full
- 4- MPAK to transmit, hook_on, hook_off, power_off, manual_mode_on, MPAK_to_retransmit

Block:

Repro:

Cantel Mobitex™		Doc No	53/1056-A 296 5171/2 Ue
		Issue Date	1990-02-23
		Rev	A
		File No	MTS09C.2
1.2 TERMINOLOGY			
P_ / F_	In this logical description, all procedures starts with "P_", and all functions with "F_".		
input_signal	The network layer has an input queue. A signal from this input queue is called "input_signal".		
wait_for_input_signal	The network layer is waiting until an input_signal is available.		
save_signal	Restoring the signal into the queue. This is done when you expect a certain signal. By repeating input_signal and save_signal, you can search in the input queue for certain signals. All saved signals are available when an input_signal follows after an input_signal without any save_signal between. See chapter 'Queue handling'.		
ignore_signal	No further handling of this signal, except that the signal should be deleted.		
groupulist	Area where group MAN are stored. This list should be stored also during power off.		
flexlist	Area where personal subscription MAN are stored. This list should be stored also during power off.		
permanent_list	Total area to be continuously stored. In this area terminal MAN, serial number, group list, flexlist, die_state and live state are stored. The checksum is calculated based on this list.		
groupulist_received_flag	Indication of a correct permanent list and that a MPAR:GROUPLIST is received or not.		
active_delay_power_up	Activation delay concerning power-up and manual radio mode. See RI-06.		
active_delay_lost_contact	Activation delay concerning lost contact. See RI-06.		
power_off_ready	Flag to indicate that the network layer is ready to be closed.		

Cantel Mobitex -

53/1056-A 296 5171/2 Ue
1990-02-23 A MTS09C.2

manual_mode Flag to indicate that the mobile station is in manual mode.

buffer_full_flag Indication of buffer full.

emergency_flag Indication of an activated emergency. When application layer receive an emergency signal, this flag is raised. Now the network layer can handle the priority of emergency in the terminal.

Bildschirm

Reprint

A.2925153G

Catel Mobitex		Doc No.	Rev	Rev	Rev
		53/1056-A	296	5171/2	Use
		Doc Date	1 Rev	2 Rev	3 Rev
		1990-02-23	A		MTS09C.2

1.2	SIGNALS
MPAK_to_transmit	MPAK received from the application layer or MPAK to the data link layer to be transmitted.
MPAK_received	MPAK received by the data link layer or MPAK to be sent to the application layer.
MPAK_transmitted	MPAK successfully transmitted by the data link layer.
MPAK_not_transmitted	MPAK not transmitted by the data link layer.
MPAK_to_retransmit	MPAK from the application layer to the data link layer to be retransmitted (special treatment in the data link layer).
roaming	Order to the network layer to send an MPAK:ROAM.
activation	Start activation timeout (after power-on or lost contact with base) given in R1-06.
speech_on	Order to the data link layer to set mode speech_on.
speech_off	Order to the data link layer to set mode speech_off.
order_to_return_MPAK	Order to the data link layer to stop sending an MPAK, and return the MPAK to the network layer.
group_list_information	Group list information to the data link layer.
area_list_information	Area list information to the data link layer.
returned_MPAK_with_code	Returned MPAK with code information from the network layer. The code shows why the MPAK was returned.
Booth	
Reprod	

A:292 51333

Cantel Mobitex-

53/1056-A 296 S171/2 Use

System Date
1990-02-23

Rev
A

File Name
MTS09C.2

hook_on	Hook on signal from the application layer.
hook_off	Hook off signal from the application layer.
die	A signal informing that the network layer has received an MPAK:DIE. All user traffic is stopped and returned to the application layer.
live	A signal informing that the network layer has received an MPAK:LIVE. User traffic from the application layer can be handled.
buffer_full	Queue for incoming messages is full. Incoming and outgoing traffic from/to the MOBITEK network is stopped. The network layer tries to send MPAK:INACTIVE. Application layer is informed. When the message buffer has space for at least 6 messages, according to specification RI-09, the buffer_full_flag is reset and incoming and outgoing traffic is resumed.
power_off	The application layer wants to turn the network layer off. The network layer tries to send an MPAK:INACTIVE.
power_off_timeout	Internal timeout to indicate that the network layer is ready to be turned off.
manual_mode_on	The application layer wants to turn over to manual radio mode. The network layer tries to send an MPAK:INACTIVE.
manual_mode_on_timeout	Internal timeout to indicate that the network layer is ready to turn over to manual radio mode.

Build:

Report

A 292 4133 3

Cantel Mobitex

Doc No: 53/1056-A 296 5171/2 Ue
 Doc Date: 1990-02-23 Rev: A S. P. MTS09C.2

1.3 RETURNED MPAK WITH CODE

CODE	MEANING
SENT	This MPAK has been correctly sent by the data link layer.
NOT_SENT	This MPAK has not been correctly sent by the data link layer.
NOT_SENT_SPEECH	This MPAK has not been sent because of speech state in the network layer.
NOT_SENT_DIE	This MPAK has not been sent because of die state in the network layer.
NOT_SENT_BUFFER_FULL	This MPAK has not been sent because of buffer_full state in the network layer.
INCORRECT	Received MPAK from the application layer, do not have a correct format or is not allowed to be sent.
PERSONAL_MAN_EXIST	Present personal subscription MAN already exist in the flexlist.
PERSONAL_MAN_NOT_EXIST	Present personal subscription MAN does not exist in the flexlist.
FLEXLIST_FULL	The maximum number of MAN in the flexlist is exceeded.

Builds:

Reprod:

A 297 51530


Cantel Mobitex		Doc. No. 53/1056-A 296 5171/2 Ue	
		System Date 1990-02-23	Rev. A F. No. MTS09C.2
1.4 STATES			
idle	Idle state		
die_state	A received MPAK:DIE has ordered the mobile to this state. No outgoing user traffic is allowed. A received MPAK:LIVE orders the mobile to idle state.		
sending_during_die	Only MPAK of class DTESERV and MPAK:DISCON (CSUBCOM) can be sent during die_state.		
link_busy	The data link layer can only handle one packet at a time. In the present state, the data link layer is busy.		
sending_conreq	The data link layer is busy sending speech request.		
stop_sending	The network layer has ordered the data link layer to stop sending present packet. The network layer is waiting until the data link layer is ready.		
wait_for_hook_off_normal	A normal speech request is received and the network layer is waiting for response from the application layer.		
wait_for_hook_off_fast	A fast speech request is received and the network layer is waiting for response from the application layer.		
wait_for_hook_off_group	A group speech request is received and the network layer is waiting for response from the application layer.		
sending_conrea	The data link layer is busy sending a hook_off signal (MPAK:CONREA).		
speech_normal	The network layer is in speech state.		
speech_group	The network layer is in group speech state.		
sending_discon	The data link layer is busy sending a hook_on signal(MPAK:DISCON).		
Buildout			
Region			

A 101 5153.3

Cantel Mobitex

No. 53/1056-A 296 5171/2 Ue
System Date 1990-02-23 Rev A File MTS09C.2

1.5 STATE DIAGRAM



WAIT_FOR HOOK OFF XXX can be in three different states depending on the received speech request, as follows:

STATE

WAIT_FOR_HOOK_OFF_NORMAL

WAIT_FOR_HOOK_OFF_FAST

WAIT_FOR_HOOK_OFF_GROUP

WHEN RECEIVING

CONREQ, ADDCONREQ, SOSCONREQ or EXTCONREQ

CONFAST, ADDCONFAST or SOSCONFAST

CONORD

Block

Diagram

Cantel Mobitex

53/1056-A 296 5171/2 Ue

1990-02-23 A MTS09C.2

1.6 QUEUE HANDLING

input queue:

2

1

<----- input_queue_pointer

Input_signal:

3

2

1

<----- input_queue_pointer+1

-----> signal available for user

Save_signal:

3

2

1

<----- input_queue_pointer+1

<----- save_input_queue_pointer

Input_signal and save_signal:

3

2

1

<----- input_queue_pointer+2

<----- save_input_queue_pointer+1

<----- save_input_queue_pointer

Input_signal :

4

3

2

1

<----- input_queue_pointer+3

-----> signal available for user

<----- save_input_queue_pointer+1

<----- save_input_queue_pointer

Input_signal :

4

2

1

<----- input_queue_pointer+1

-----> signal available for user

Bilbores

Repro

A-292 51153

Cantel Mobitex

Doc No	53/1056-A	296	5171/2	Ue
Version Date	1990-02-23	1 Rev	A	TS. P. 4
				MTS09C.2

2 LOGICAL DESCRIPTION

2.1 Start of program

This program have two different modes, MOBITEK mode and MANUAL mode. In MANUAL mode, the network layer is stopped. When MOBITEK mode is activated from MANUAL mode the network layer should be restarted.

NETWORK LAYER

```

P_activation handling
next_state = idle
emergency_flag = FALSE
IF permanent_list is not correct THEN
    make MPAK BORN
    send MPAK to transmit to LINK
    next_state = link busy
    reset grouplist and flexlist
    set NOT grouplist_received_flag
ENDIF
LOOP
    IF manual mode THEN
        MOBITEK_network_layer inactivated
        activated = FALSE
        handle manual mode
    ELSE
        wait for input signal
        IF emergency_flag THEN
            P_look_for_emergency
        ENDIF
        CASE signal
            WHEN MPAK to transmit from APP
                P_MPAK_FROM_APP
            WHEN MPAK to retransmit from APP
                P_MPAK_TO_RETRANSMIT
            WHEN MPAK received from LINK
                P_REC_MPAK_FROM_LINK
            WHEN MPAK transmitted from LINK
                P_MPAK_TRANSMITTED
            WHEN MPAK not transmitted from LINK
                P_MPAK_NOT_TRANSMITTED
            WHEN hook_on from APP
                P_HOOK_ON_handling
            WHEN hook_off from APP
                P_HOOK_OFF_handling
            WHEN hook_off_timeout

```

Author:

Repro:

A 331 31533

Cantel Mobitex

St. No. 53/1056-A 296 5171/2 Je
 Service Date 1990-02-23 User A. P. P. A
 MTS09C.2

```

P_timeout_handling

WHEN roaming from LINK
P_roaming_handling

WHEN activation from LINK
P_activation_handling_link

WHEN activation_timeout
P_activation_timeout_handling

WHEN power_off from APP
P_power_off_handling

WHEN manual_mode_on
P_manual_mode_on_handling

WHEN power_off_timeout
set power_off_ready

WHEN manual_mode_on_timeout
set manual_mode

WHEN buffer_full
P_buffer_full_handling

ENDCASE
ENDIF
ENDLOOP
END_NETWORK_LAYER
  
```

Blockout

Report

A 20251529

<h2 style="margin: 0;">Cantel Mobitex</h2>	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="padding: 2px;">St. No.</td> <td colspan="3" style="padding: 2px;">53/1056-A 296 5171/2 Ue</td> </tr> <tr> <td style="padding: 2px;">Datum</td> <td style="padding: 2px;">1990-02-23</td> <td style="padding: 2px;">Tid</td> <td style="padding: 2px;">A</td> </tr> <tr> <td style="padding: 2px;">F. v. d.</td> <td colspan="3" style="padding: 2px;">MTS09C.2</td> </tr> </table>	St. No.	53/1056-A 296 5171/2 Ue			Datum	1990-02-23	Tid	A	F. v. d.	MTS09C.2		
St. No.	53/1056-A 296 5171/2 Ue												
Datum	1990-02-23	Tid	A										
F. v. d.	MTS09C.2												

```

2.1.1  P_LOOK_FOR_EMERGENCY
P_look_for_emergency
    emergency_signal = FALSE
    WHILE NOT emergency_signal THEN
        CASE MPAK.type
            WHEN SOS,SOSINFO,SOSACK,SOSCONREQ,SOSCONFAST
                emergency_signal = TRUE
            WHEN OTHERWISE
                save_signal
                input_signal
        ENDCASE
    ENDWHILE
END_P_look_for_emergency

```

Bidskott	
Reprocc	

A 292 51533

Cantel Mobitex

Doc No: 53/1056-A 296 5171/2 Ue
 Date: 1990-02-23 Iss: A Ver: WTS09C.2

2.2 P_MPAK_FROM_APP

```

P_MPAK_FROM_APP
IF NOT buffer_full_flag THEN
CASE next_state
  WHEN idle
    CASE MPAK.class
    WHEN PSUBCOM,PSOSCOM
      P_check_format
      IF format = true THEN
        send MPAK to transmit to LINK
        next_state = LINK_BUSY
      ELSE
        send returned_MPAK_with_code:INCORRECT to APP
      ENDIF
    WHEN CSUBCOM
      P_check_format
      IF format = true THEN
        P_check_and_send_CSUBCOM
      ELSE
        send returned_MPAK_with_code:INCORRECT to APP
      ENDIF
    WHEN DTESERV
      P_check_format
      IF format = true THEN
        P_check_and_send_DTESERV
      ELSE
        send returned_MPAK_with_code:INCORRECT to APP
      ENDIF
    ENDCASE
  WHEN die_state
    IF MPAK.class = DTESERV THEN
      P_check_format
      IF format = true THEN
        P_check_and_send_DTESERV
      ELSE
        send returned_MPAK_with_code:INCORRECT to APP
      ENDIF
    ELSE
      send returned_MPAK_with_code:NOT_SENT_DIE
    ENDIF
  WHEN
    wait_for_hook_off_normal,
    wait_for_hook_off_fast,
    wait_for_hook_off_group
    IF MPAK.class = CSUBCOM THEN
      P_check_format
      IF format = true THEN
        CASE MPAK.type
        WHEN CONREA
          P_hook_off_handling
        WHEN DISCON
          P_hook_on_handling
        WHEN OTHERWISE

```

Blocker

Report

A 292 51333

Cantel Mobitex

Doc No: 53/1056-A 296 5171/2 Ue
 Document Date: 1990-02-23 Title: A File No.: MTS09C.2

```

      send returned_MPAK_with_code:NOT_SENT_SPEECH
    ENDCASE
  ELSE
    send returned_MPAK_with_code:INCORRECT to APP
  ENDIF
ELSE
  IF MPAK.class = PSOSCOM THEN
    save_signal
    make hook on signal
    P HOOK_ON_handling
  ELSE
    send returned_MPAK_with_code:NOT_SENT_SPEECH to APP
  ENDIF
ENDIF
WHEN sending_conreq,sending_conrea,speech_normal,speech_group
IF MPAK.class = CSUBCOM THEN
  P check_format
  IF format = true THEN
    CASE MPAK.type
    WHEN DISCON
      P hook on handling
    WHEN OTHERWISE
      send returned_MPAK_with_code:NOT_SENT_SPEECH
    ENDCASE
  ELSE
    send returned_MPAK_with_code:INCORRECT to APP
  ENDIF
ELSE
  IF MPAK.class = PSOSCOM THEN
    CASE next_state
    WHEN sending_conreq,sending_conrea
      save_signal
      send order to return MPAK to LINK
      next_state = stop_sending
    WHEN speech_normal,speech_group
      save_signal
      make hook on signal
      P HOOK_ON_handling
    ENDCASE
  ELSE
    send returned_MPAK_with_code:NOT_SENT_SPEECH
  ENDIF
ENDIF
WHEN OTHERWISE
  save_signal
ENDCASE
ELSE
  CASE MPAK.class
  WHEN PSUBCOM,PSOSCOM
    P check_format
    IF format = true THEN
      send MPAK to transmit to LINK
      next_state = LINK_BUSY
    ELSE
      send returned_MPAK_with_code:INCORRECT to APP
    ENDIF
  ENDIF

```

Boisart

Repro

Cantel Mobitex

53/1056-A 296 5171/2 Ue

1990-02-23 A MTS09C.2

```

WHEN OTHERWISE
    send returned_MPAK_with_code:NOT_SENT_BUFFER_FULL
ENDCASE
ENDIF
END_P_MPAK_FROM_APP
    
```

Budget

Reprod

A.092 5153.0

Cantel Mobitex -

Doc No	53/1056-A 296 5171/2 Ue
Doc Date	1990-02-23
Rev	A
F. No	MTS09C.2

2.2.1 F_CHECK_FORMAT**F_check_format**

This routine checks and completes the format of this MPAK to be correct according to RI-09 Appendix A.

A correct MPAK will be returned with format = TRUE.

An incorrect MPAK will be returned with format = FALSE.

END_F_check_format

2.2.2 P_CHECK_AND_SEND_DTESERV**P_check and send_DTESERV**

CASE MPAK.type

WHEN LOGINREQ

IF MPAK.type_dependent in our flexlist THEN
send returned_MPAK_with_code:PERSONAL_MAN_EXIST to APP

ELSE

IF more space in our flexlist
MPAK.sender = MCU MAN
send MPAK_to_transmit to LINK
next_state = LINK_BUSY

ELSE

send returned_MPAK_with_code:FLEXLIST_FULL

ENDIF

ENDIF

WHEN VICESOSRX,SOSRX

IF MPAK.sender in our flexlist THEN
send MPAK_to_transmit to LINK
next_state = LINK_BUSY

ELSE

send returned_MPAK_with_code:PERSONAL_MAN_NOT_EXIST to APP

ENDIF

WHEN LOGOUT

remove MPAK.sender from our flexlist
MPAK.type_dependent = MCU MAN
send MPAK_to_transmit to LINK
next_state = LINK_BUSY

WHEN ACTIVE,INACTIVE

send MPAK_to_transmit to LINK
next_state = LINK_BUSY

WHEN OTHERWISE

send returned_MPAK_with_code:INCORRECT to APP

ENDCASE

END_P_check_and_send_DTESERV

Bulker

Repro

Cantel Mobitex -

53/1056-A 296 5171/2 Ue

1990-02-23 A MTS09C.2

2.2.3 P_CHECK_AND_SEND_CSUBCOM

P_check and send CSUBCOM

```

_CASE MPAK.type
  WHEN CONREQ,ADDCONREQ,SOSCONREQ,EXTCONREQ,
    CONFAST,ADDCONFAST,SOSCONFAST
    MPAK.line = 0
    MPAK.connection_identity = next MPAK.connection_identity
    SPEECH_REG.part_here = MPAK.sender
    SPEECH_REG.other_part = MPAK.addressee
    SPEECH_REG.line = MPAK.line
    SPEECH_REG.conn_id = MPAK.connection_identity
    send MPAK_to_transmit to LINK
    next_state = sending_conreq

  WHEN DISCON
    send MPAK DISCON with
      MPAK.sender = SPEECH_REG.part_here
      MPAK.addressee = SPEECH_REG.other_part
      MPAK.line = SPEECH_REG.line
      MPAK.connection_identity = SPEECH_REG.conn_id
    send MPAK_to_transmit to LINK
    next_state = sending_discon

  WHEN OTHERWISE
    ignore_signal

  ENDCASE
END_P_check_and_send_CSUBCOM

```

Boeken

Examen

A 292 51533

Cantel Mobitex

53/1056-A 296 5171/2 Ue
 1990-02-23 A MTS09C.2

2.3 P_MPAK_TO_RETRANSMIT

P_MPAK_to_retransmit

```

CASE next_state
WHEN idle
  CASE MPAK.class
  WHEN PSUBCOM,PSOSCOM
    P check format
    IF format = true THEN
      send MPAK_to_retransmit to LINK
      next_state = LINK_BUSY
    ELSE
      send returned_MPAK_with_code:INCORRECT to APP
    ENDIF
  WHEN OTHERWISE
    send returned_MPAK_with_code:INCORRECT to APP
  ENDCASE
WHEN die_state
  send returned_MPAK_with_code:NOT_SENT_DIE
WHEN
  wait_for_hook_off_normal,
  wait_for_hook_off_fast,
  wait_for_hook_off_group
  IF MPAK.class = PSOSCOM THEN
    save_signal
    make hook on signal
    P HOOK_ON_handling
  ELSE
    send returned_MPAK_with_code:NOT_SENT_SPEECH to APP
  ENDIF
WHEN sending_conreq,sending_conrea,speech_normal,speech_group
  IF MPAK.class = PSOSCOM THEN
    CASE next_state
    WHEN sending_conreq,sending_conrea
      save_signal
      send order_to_return_MPAK to LINK
      next_state = stop_sending
    WHEN speech_normal,speech_group
      save_signal
      make hook on signal
      P HOOK_ON_handling
    ENDCASE
  ELSE
    send returned_MPAK_with_code:NOT_SENT_SPEECH
  ENDIF
WHEN OTHERWISE
  save_signal
ENDCASE
END P_MPAK_to_retransmit

```

Bildkart

Regio

A 192 01333

Cantel Mobitex

33/1056-A 296 5171/2 Ue

1990-02-23 A MTS09C.2

2.4 P_REC_MPAK_FROM_LINK

P_REC_MPAK_FROM_LINK

```

activated = TRUE
CASE MPAK.class
WHEN PSUBCOM,PSOSCOM
  IF F.get rec man = MCU_MAN or in flexlist or in grouplist THEN
    send MPAK_received To APP
  ELSE
    P unknown_handling_normal
  ENDIF
WHEN CSUBCOM
  P_REC_MPAK_CSUBCOM_FROM_LINK
WHEN DTESERV
  IF F.get rec man = MCU_MAN or in flexlist or in grouplist THEN
    CASE MPAK.state
    WHEN ok,from mail
      P_REC_MPAK_DTESERV_FROM_LINK_NORMAL
    WHEN OTHERWISE
      CASE MPAK.type
      WHEN LOGINREQ,SOSRX,VICESOSRX
        send MPAK_received to APP
      WHEN OTHERWISE
        ignore signal
      ENDCASE
    ENDCASE
  ELSE
    P unknown_handling_normal
  ENDIF
ENDCASE
END_P_REC_MPAK_FROM_LINK

```

2.4.1 P_UNKNOWN_HANDLING_NORMAL

P_unknown_handling_normal

```

CASE next_state
WHEN idle
  set MPAK.UNKNOWN_F = 1
  send MPAK_to_transmit to LINK
  next_state = link_busy
WHEN die_state
  set MPAK.UNKNOWN_F = 1
  send MPAK_to_transmit to LINK
  next_state = sending_during_die
WHEN OTHERWISE
  save signal
ENDCASE
END_P_unknown_handling_normal

```

Bidart

Reprot

Cantel Mobitex

Doc No
53/1056-A 296 5171/2 Ue

Issue Date Rev F.A
1990-02-23 A MTS09C.2

2.4.2 P_REC_MPAK_DTESERV_FROM_LINK_NORMAL

P_REC_MPAK_DTESERV_FROM_LINK_NORMAL

```

CASE MPAK.type
  WHEN LOGINRA
    Add personal subscription MAN to the flexlist
    send MPAK received to APP
  WHEN LOGINREF
    send MPAK received to APP
  WHEN LOGOUTORD
    remove personal subscription MAN from the flexlist
    send MPAK received to APP
  WHEN DIE
    IF next_state = idle or die_state THEN
      next_state = die_state
      send die to APP
    ELSE
      save_signal
    END
  WHEN LIVE
    IF next_state = idle or die_state THEN
      next_state = idle
      send live to APP
    ELSE
      save_signal
    END
  WHEN GROUPLIST
    replace grouplist
    set grouplist received flag
    send MPAK received to APP
    send group list information to data link layer
  WHEN AREALIST
    send area list information to data link layer

```

Bolkert

Repro

A 292 51533

Cantel Mobitex -

No. 53/1056-A 296 5171/2 Ue		
Creation Date	Rev	File
1990-02-23	A	MTS09C.2

```

WHEN ROAMORD,FLEXREQ,INFOREQ,ESNREQ
  IF next_state = idle or die_state THEN
    CASE MPAK.type
      WHEN ROAMORD      make MPAK.type ROAM
      WHEN FLEXREQ      make MPAK.type FLEXLIST
      WHEN INFOREQ      make MPAK.type INFO
      WHEN ESNREQ       make MPAK.type ESNINFO
    ENDCASE
    send MPAK_to transmit to LINK
    CASE next_state
      WHEN idle      next_state = link busy
      WHEN die_state next_state = sending_during_die
    ENDCASE
  ELSE
    save_signal
  ENDIF
WHEN FLEXLIST
  replace flexlist.
  send MPAK_received to APP
WHEN TIME
  send MPAK_received to APP
WHEN OTHERWISE
  ignore signal
ENDCASE MPAK
END_P_REC_MPAK_DTESERV_FROM_LINK_NORMAL

```

Björn

Repro

CanTel Mobitex		No. No	53/1056-A 296 5171/2 Ue
		System Date	1990-02-23
		Rev	A
		P. P. S.	MTS09C.2
<p>2.4.2.1 F_GET_REC_MAN</p> <pre> F_get_rec_man CASE MPAK.state WHEN ok,from_mail F_get_rec_man = MPAK.addressee WHEN OTHERWISE F_get_rec_man = MPAK.sender ENDCASE MPAK.state END_F_get_rec_man </pre>			
<p>2.4.3 P_REC_MPAK_CSUBCOM_FROM_LINK</p> <pre> P_REC_MPAK_CSUBCOM_FROM_LINK CASE next_state WHEN idle P_REC_MPAK_CSUBCOM_FROM_LINK_IDLE WHEN link_busy,sending_during_die,stop_sending save_signal WHEN die_state P_REC_MPAK_CSUBCOM_FROM_LINK_DIE WHEN wait_for_hook_off_normal, wait_for_hook_off_fast, wait_for_hook_off_group P_REC_MPAK_CSUBCOM_FROM_LINK_WAIT WHEN speech_normal,speech_group P_REC_MPAK_CSUBCOM_FROM_LINK_SPEECH WHEN sending_conreq CASE MPAK.type WHEN CONREQ,ADDCONREQ,SOSCONREQ,EXTCONREQ, CONFAST,ADDCONFAST,SOSCONFAST,CONORD save_signal send_order_to_return_MPAK_to_LINK next_state = stop_sending WHEN OTHERWISE ignore_signal ENDCASE MPAK WHEN sending_conrea IF MPAK.type DISCON THEN send_MPAK_received_to_APP send_order_to_return_MPAK_to_LINK next_state = stop_sending ELSE ignore_signal send_order_to_return_MPAK_to_LINK next_state = stop_sending ENDIF WHEN sending_discon save_signal send_order_to_return_MPAK_to_LINK next_state = stop_sending ENDCASE END_P_REC_MPAK_CSUBCOM_FROM_LINK </pre>			
Bus:art			
Reprod			

A 292 5153.3

Cantel Mobitex

Doc No
53/1056-A 296 5171/2 Ue
Design Date
1990-02-23 Rev
A P. No
MTS09C.2

2.4.3.1 P_REC_MPAK_CSUBCOM_FROM_LINK_IDLE

P_REC_MPAK_CSUBCOM_FROM_LINK_IDLE

```

CASE MPAK.type
WHEN CONREQ,ADDCONREQ,SOSCONREQ,EXTCONREQ
CASE MPAK.state
WHEN ok
IF F_get_rec_man = MCU_MAN or in flexlist
start 60 second timer for hook off
SPEECH_REG.part here = MPAK.addressee
SPEECH_REG.other_part = MPAK.sender
SPEECH_REG.line = MPAK.line
SPEECH_REG.conn_id = MPAK.connection_identity
send MPAK_received to APP
next_state = wait_for_hook_off_normal
ELSE
P unknown_handling_csubcom
ENDIF
WHEN OTHERWISE
send speech_off to LINK
ENDCASE MPAK.state
WHEN CONFAST,ADDCONFAST,SOSCONFAST
CASE MPAK.state
WHEN ok
IF F_get_rec_man = MCU_MAN or in flexlist
start 10 second timer for hook off
SPEECH_REG.part here = MPAK.addressee
SPEECH_REG.other_part = MPAK.sender
SPEECH_REG.line = MPAK.line
SPEECH_REG.conn_id = MPAK.connection_identity
send MPAK_received to APP
next_state = wait_for_hook_off_fast
send speech_on to LINK
ELSE
P unknown_handling_csubcom
ENDIF
WHEN OTHERWISE
send speech_off to LINK
ENDCASE MPAK.state
WHEN CONORD
CASE MPAK.state
WHEN ok
IF F_get_rec_man in grouplist
start 60 second timer for hook off
send MPAK_received to APP
next_state = wait_for_hook_off_group
send speech_on to LINK
ELSE
send speech_off to LINK
ENDIF
WHEN OTHERWISE
send speech_off to LINK
ENDCASE MPAK.state

```

Builds

Report

A 3751533

Cantel Mobitex

Doc No: 53/1056-A 296 5171/2 Ue
 Issue Date: 1990-02-23 Rev: A File No: MTS09C.2

```

WHEN OTHERWISE
  send speech_off to LINK
ENDCASE MPAK
END_P_REC_MPAK_CSUBCOM_FROM_LINK_IDLE
  
```

2.4.3.2 P_UNKNOWN_HANDLING_CSUBCOM

```

P_unknown_handling_csubcom
  send speech_on to LINK
  make MPAK DISCON with
    MPAK.sender = received_MPAK.addressee
    MPAK.addressee = received_MPAK.sender
    MPAK.line = received_MPAK.line
    MPAK.connection_identity =
      received_MPAK.connection_identity
    MPAK.UNKNOWN_F = 1
  send MPAK_to_transmit to LINK
  next_state = sending_discon
END_P_unknown_handling_csubcom
  
```

2.4.3.3 P_REC_MPAK_CSUBCOM_FROM_LINK_DIE

```

P_REC_MPAK_CSUBCOM_FROM_LINK_DIE
CASE MPAK.type
  WHEN CONREQ,ADDCONREQ,SOSCONREQ,EXTCONREQ,
    CONFST,ADDCONFST,SOSCONFST
    CASE MPAK.state
      WHEN ok
        send speech_on to LINK
        make MPAK DISCON with
          MPAK.sender = received_MPAK.addressee
          MPAK.addressee = received_MPAK.sender
          MPAK.line = received_MPAK.line
          MPAK.connection_identity =
            received_MPAK.connection_identity
        IF P_get_rec_man = MCU_MAN or in_flexlist
          send MPAK_to_transmit to LINK
        ELSE
          set UNKNOWN_F = 1 in MPAK DISCON
          send MPAK_to_transmit to LINK
        ENDDIF
        next_state = sending_during_die
      WHEN OTHERWISE
        send speech_off to LINK
    ENDCASE MPAK.state
  WHEN OTHERWISE
    send speech_off to LINK
END_P_REC_MPAK_CSUBCOM_FROM_LINK_DIE
  
```

Diagrams

Repro

A 292 51503

Cantel Mobitex

No. 53/1056-A 296 5171/2 Ue

Date 1990-02-23

Rev A

F. F. MTS09C.2

2.4.3.4 P_REC_MPAK_CSUBCOM_FROM_LINK_WAIT

P_REC_MPAK_CSUBCOM_FROM_LINK_WAIT

CASE MPAK.type

WHEN DISCON

reset hook_off_timeout
 send speech_off to LINK
 send MPAK_received to APP
 next_state = idle

WHEN CONORD

ignore signal
 IF next_state < > wait_for_hook_off_group THEN
 reset hook_off_timeout
 send speech_off to LINK
 next_state = idle
 make MPAK_DISCON
 send MPAK_received to APP

ENDIF

ENDCASE

END_P_REC_MPAK_CSUBCOM_FROM_LINK_WAIT

Student

Revised

A 530 5155.2

Cantel Mobitex

Doc No 53/1056-A 296 5171/2 Ue
 Date Issued 1990-02-23 A P.O. No. MTS09C.2

2.4.3.5 P_REC_MPAK_CSUBCOM_FROM_LINK_SPEECH

```
P_REC_MPAK_CSUBCOM_FROM_LINK_SPEECH
CASE MPAK.type
  WHEN CONREQ,ADDCONREQ,SOSCONREQ,EXTCONREQ,
    CONFST,ADDCONFST,SOSCONFST
    CASE MPAK.state
      WHEN no_transfer,illegal,congest,error,busy
        send speech_off to LINK
        send MPAK_received to APP
        next_state = idle
      WHEN OTHERWISE
        ignore_signal
        make MPAK DISCON
        send MPAK_received to APP
        send speech_off to LINK
        next_state = idle
      ENDCASE MPAK.state
    WHEN DISCON
      send MPAK_received to APP
      send speech_off to LINK
      next_state = idle
    WHEN CONORD
      ignore_signal
      IF next_state < > speech_group THEN
        make MPAK DISCON
        send MPAK_received to APP
        send speech_off to LINK
        next_state = idle
      ENDIF
    WHEN OTHERWISE
      ignore_signal
      make MPAK DISCON
      send MPAK_received to APP
      send speech_off to LINK
      next_state = idle
    ENDCASE
END P_REC_MPAK_CSUBCOM_FROM_LINK_SPEECH
```

Budkart

Reproa

A 29151533

Cantel Mobitex

No. 54-
53/1056-A 296 5171/2 Ue
Revision Date 1 day
1990-02-23 A
P. P. #
MTS09C.2

2.5 P_MPAK_TRANSMITTED

P_MPAK_TRANSMITTED

```

_activated = TRUE
CASE MPAK.class
WHEN PSUBCOM,PSOSCOM,DTESEV
CASE next_state
WHEN link_busy
next_state = idle
WHEN sending_during_die
next_state = die_state
ENDCASE
IF MPAK.UNKNOWN_F = 0 THEN
IF MPAK.class = DTESEV THEN
CASE MPAK.type
WHEN LOGINREQ,SOSRX,VICESOSRX
send returned_MPAK_with_code:SENT to APP
WHEN INACTIVE
IF power_off THEN
set power_off_ready
ENDIF
IF manual_mode on received THEN
set manual_mode
ENDIF
ENDCASE
ELSE
send returned_MPAK_with_code:SENT to APP
IF (MPAK.class = PSUBCOM) AND (buffer_full_flag) THEN
make MPAK INACTIVE
send MPAK to transmit to LINK
next_state = link_busy
ENDIF MPAK.class
ENDIF MPAK.class
ENDIF MPAK.UNKNOWN_F
WHEN CSUBCOM
CASE MPAK.type
WHEN CONREQ,ADDCONREQ,SOSCONREQ,EXTCONREQ,
CONFAST,ADDCONFAST,SOSCONFAST
send speech on to LINK
send returned_MPAK_with_code:SENT to APP
next_state = speech_normal
WHEN CONREA
send speech on to LINK
send returned_MPAK_with_code:SENT to APP
next_state = speech_normal
WHEN DISCON
send speech off to LINK
send returned_MPAK_with_code:SENT to APP
IF next_state = sending_during_die THEN
next_state = die_state
ELSE
next_state = idle
ENDIF
ENDCASE MPAK
ENDCASE MPAK.class
END P_MPAK_TRANSMITTED

```

Backup

Repeat

A 296 5153-3

Cantel Mobitex

No. 56
53/1056-A 296 5171/2 Ue
Datum: Date Rev Pz. File
1990-02-23 A MTS09C.2

2.6 P_MPAK_NOT_TRANSMITTED

P_MPAK_NOT_TRANSMITTED

```

CASE MPAK.class
  WHEN PSUBCOM,PSOSCOM,DIESERV
    CASE next_state
      WHEN link_busy
        next_state = idle
      WHEN sending_during_die
        next_state = die_state
      WHEN stop_sending
        next_state = idle
    ENDCASE
    IF MPAK.UNKNOWN_F = 0 THEN
      IF MPAK.class = DIESERV THEN
        CASE MPAK.type
          WHEN LOGINREQ,SOSRX,VICESOSRX
            send returned_MPAK_with_code:NOT_SENT to APP
          WHEN INACTIVE
            IF power_off THEN
              set power_off_ready
            ENDIF
            IF manual_mode_on received THEN
              set manual_mode
            ENDIF
          ENDCASE
        ELSE
          send returned_MPAK_with_code:NOT_SENT to APP
        ENDIF MPAK.class
      ENDIF MPAK.UNKNOWN_F
    WHEN CSUBCOM
      CASE MPAK.type
        WHEN CONREQ,ADDCONREQ,SOSCONREQ,EXTCONREQ,
          CONFAST,ADDCONFAST,SOSCONFAST
          IF next_state = sending_conreq THEN
            send speech_off to LINK
          ENDIF
          next_state = idle
        WHEN CONREA
          send speech_off to LINK
          next_state = idle
        WHEN DISCON
          send speech_off to LINK
          IF next_state = sending_during_die THEN
            next_state = die_state
          ELSE
            next_state = idle
          ENDIF
        ENDCASE MPAK
        send returned_MPAK_with_code:NOT_SENT to APP
      ENDCASE MPAK.class
    END P_MPAK_NOT_TRANSMITTED
  
```

Buschart

Reprint

A 292 51552

Cantel Mobitex

Doc No. 53/1056-A 296 5171/2 Ue

Creation Date 1990-02-23 Rev A

File No. MTS09C.2

2.7 P_HOOK_ON_HANDLING

P_HOOK_ON_handling

```

_CASE next_state
  WHEN wait_for_hook_off_normal,
        wait_for_hook_off_fast,
        wait_for_hook_off_group,
        reset_hook_off_timeout,
        P_timeout_handling

  WHEN sending_conreq,sending_conrea
        save_signal
        send_order_to_return_MPAK_to_LINK
        next_state = stop_sending

  WHEN speech_normal
        make_MPAK_DISCON_with
        MPAK.sender = SPEECH_REG.part_here
        MPAK.addressee = SPEECH_REG.other_part
        MPAK.line = SPEECH_REG.line
        MPAK.connection_identity = SPEECH_REG.conn_id
        send_MPAK_to_transmit_to_LINK
        next_state = sending_discon

  WHEN speech_group
        send_speech_off_to_LINK
        next_state = idle

  WHEN idle
        IF line_connection_request_received THEN
            make_MPAK_DISCON_with
            MPAK.sender = SPEECH_REG.part_here
            MPAK.addressee = SPEECH_REG.other_part
            MPAK.line = SPEECH_REG.line
            MPAK.connection_identity = SPEECH_REG.conn_id
            send_MPAK_to_transmit_to_LINK
            next_state = sending_discon
        ELSE
            ignore_signal
        ENDIF
  WHEN OTHERWISE
        ignore_signal
  ENDCASE next_state
END_P_HOOK_ON_handling

```

Bildart:

Regred

Cantel Mobitex

No. 53/1056-A 296 5171/2 Ue
 Date 1990-02-23 Rev A P. No. MTS09C.2

2.8 P_TIMEOUT_HANDLING

```
P_timeout_handling
CASE next_state
WHEN wait_for_hook_off_normal,wait_for_hook_off_fast
  send speech on to LINK
  make MPAK DISCON with
    MPAK.sender = SPEECH_REG.part_here
    MPAK.addressee = SPEECH_REG.other_part
    MPAK.line = SPEECH_REG.line
    MPAK.connection_identity = SPEECH_REG.conn_id
  send MPAK to transmit to LINK
  next_state = sending_discon

WHEN wait_for_hook_off_group
  send speech off to LINK
  next_state = idle

WHEN OTHERWISE
  ignore_signal
ENDCASE next_state
END_P_timeout_handling
```

2.9 P_HOOK_OFF_HANDLING

```
P_HOOK_OFF_handling
CASE next_state
WHEN wait_for_hook_off_normal
  reset hook_off timeout
  make MPAK CONREA with
    MPAK.sender = SPEECH_REG.part_here
    MPAK.addressee = SPEECH_REG.other_part
    MPAK.line = SPEECH_REG.line
    MPAK.connection_identity = SPEECH_REG.conn_id
  send MPAK to transmit to LINK
  next_state = sending_conrea

WHEN wait_for_hook_off_fast
  reset hook_off timeout
  next_state = speech_normal

WHEN wait_for_hook_off_group
  reset hook_off timeout
  next_state = speech_group

WHEN OTHERWISE
  ignore_signal
ENDCASE next_state
END_P_HOOK_OFF_handling
```

Boldest

Repro

Cantel Mobitex

No. No

53/1056-A 296 5171/2 Ue

Date: Date

1990-02-23

Ref

A

Y. P.

MTS09C.2

2.10 P_ROAMING_HANDLING

```

P_roaming_handling
IF next_state = idle or die_state THEN
  IF grouplist_received_flag THEN
    make MPAK ROAM
  ELSE
    make MPAK BORN
  ENDIF
  send MPAK_to_transmit to LINK
CASE next_state
WHEN idle
  next_state = link_busy
WHEN die_state
  next_state = sending_during_die
ENDCASE
ELSE
  save_signal
ENDIF
END P_roaming_handling

```

Slide

Page

A 292 51533

Cantel Mobitex

No. 53/1056-A 296 5171/2 Ue						
<table border="1"> <tr> <td>Issue Date</td> <td>1990-02-23</td> <td>File No.</td> <td>A</td> <td>File No.</td> <td>MTS09C.2</td> </tr> </table>	Issue Date	1990-02-23	File No.	A	File No.	MTS09C.2
Issue Date	1990-02-23	File No.	A	File No.	MTS09C.2	

2.11 P_ACTIVATION_HANDLING

```

P_activation_handling
  IF NOT buffer_full_flag THEN
    activated = FALSE
    start activation timer with 'active_delay_power_on'
  ENDIF
END_P_activation_handling

```

2.12 P_ACTIVATION_HANDLING_LINK

```

P_activation_handling_link
  IF NOT buffer_full_flag THEN
    activated = FALSE
    start activation timer with 'active_delay_lost_contact'
  ENDIF
END_P_activation_handling_link

```

2.13 P_ACTIVATION_TIMEOUT_HANDLING

```

P_activation_timeout_handling
  IF next_state = idle or die_state THEN
    IF NOT activated THEN
      make MPAA ACTIVE
      send MPAA to transmit to LINK
    CASE next_state
      WHEN idle
        next_state = link_busy
      WHEN die_state
        next_state = sending_during_die
    ENDCASE
  ENDIF
ELSE
  save_signal
ENDIF
END_P_activation_timeout_handling

```

Blanket

Reprod

Cantel Mobitex		No. 53/1056-A 296 5171/2 Ue Revision Date 1990-02-23 Rev. A	P. 1: P. 2 MTS09C.2
<p>2.14 P_POWER_OFF_HANDLING</p> <pre> P_power_off_handling power_off received start power_off timer CASE next_state WHEN idle make MPAK INACTIVE send MPAK to transmit to LINK next_state = link_busy WHEN die_state make MPAK INACTIVE send MPAK to transmit to LINK next_state = sending_during_die WHEN speech_normal,speech_group,wait_for_hook_off_normal, wait_for_hook_off_fast,wait_for_hook_off_group, sending_conreq,sending_discon,sending_conreq disconnect the speech (according to current state) make MPAK INACTIVE send MPAK to transmit to LINK next_state = link_busy WHEN OTHERWISE save_signal ENDCASE END P_power_off_handling </pre> <p>2.15 P_MANUAL_MODE_ON_HANDLING</p> <pre> P_manual_mode_on_handling manual_mode_on received start manual_mode_on_timer CASE next_state WHEN idle make MPAK INACTIVE send MPAK to transmit to LINK next_state = link_busy WHEN die_state make MPAK INACTIVE send MPAK to transmit to LINK next_state = sending_during_die WHEN speech_normal,speech_group,wait_for_hook_off_normal, wait_for_hook_off_fast,wait_for_hook_off_group, sending_conreq,sending_discon,sending_conreq disconnect the speech (according to current state) make MPAK INACTIVE send MPAK to transmit to LINK next_state = link_busy WHEN OTHERWISE save_signal ENDCASE END P_manual_mode_on_handling </pre>			

A J0751532

Cantel Mobitex

Doc No.	53/1056-A 296 5171/2 Ue	
Issue Date	1990-02-23	Rev A
EC No.	MTS09C.2	

2.16 P_BUFFER_FULL_HANDLING

```

P_buffer_full_handling
CASE next_state
WHEN idle
    make MPAK INACTIVE
    send MPAK to transmit to LINK
    next_state = link_busy
WHEN die_state
    make MPAK INACTIVE
    send MPAK to transmit to LINK
    next_state = sending_during_die
WHEN speech_normal,speech_group,wait_for_hook_off_normal,
    wait_for_hook_off_fast,wait_for_hook_off_group,
    sending_conrea,sending_discon,sending_conreq
    disconnect the speech (according to current state)
    make MPAK INACTIVE
    send MPAK to transmit to LINK
    next_state = link_busy
WHEN OTHERWISE
    save signal
ENDCASE

send buffer_full to APP
set buffer_full_flag

END_P_buffer_full_handling
    
```

Bildschirm

Diagramm

A 502 5153-3

Cantel Mobitex

53/1056-A 296 5171/2 Ue

1990-02-23 A MTS09C.2

3 MOBITEK TERMINAL SPECIFICATION REFERENCE LIST

This document includes a number of references, made to other sections in the terminal specification. The list below shows these references, together with the page(s) they are made on. Please note that a section could be referred to several times on the same page.

R1-06, 4, 6
R1-09, 7, 18

Below are the reference designations listed.

Reference	Section
R1-01	Arrangement of the documents
R1-02	MOBITEK System description
R1-03	General description of terminals
R1-04	Terminology
R1-05	References
R1-06	Network operator information
R1-08	Application layer
R1-09	Network layer
R1-11	Interface requirements, fixed terminals
R1-12	Other requirements, fixed terminals
R1-16	Link layer, mobile terminals
R1-17	Physical layer, mobile terminals
R1-18	Radio equipment, mobile terminals
R1-19	Other interfaces, mobile terminals
R1-20	Other requirements, mobile terminals

Figures

Pages

Systeme: Prosim:		Feldnummer: Subjekt: Prosim:		REQUIREMENT SPECIFICATION		1(7)
1988 ET/SYS PES		ET/SYS PES		Nr. 54		1
Dokument: Chalkade - Die registerbezogene				6/1056 - A 296 5171 Ue		
ET/SYSC STT ST				Datum: 1990-02-26		Rev. E
				Pl. Nr.		MTS11HDLC.1
Bezeichnung:				Titel:		
				MOBITEX		
				HDLC interface		
				Fixed terminal		

Cantel Mobitex

ABSTRACT

This document is a specification of the interface for a fixed terminal with HDLC interface, connected to the MOBITEX network.

Cantel Mobitex

Doc No	6/1056 - A 296 5171 Ue	
Version Date	1990-02-26	E
File Name	MTS11HDLC.1	

TABLE OF CONTENTS

1	INTRODUCTION	3
1.1	GENERAL	3
2	PHYSICAL LAYER	4
2.1	GENERAL	4
2.2	BITRATE	4
3	LINK LAYER	5
3.1	GENERAL	5
3.2	SUB-SET OF HDLC	5
3.2.1	Clarification	5
3.2.1.1	Commands and responses	5
3.2.1.2	Frame size	5
3.2.1.3	The use of the address field	6
3.2.1.4	FRMR responses	6
3.2.1.5	TEST frames	6
3.3	OPERATING MODES FOR THE LINK LAYER	7
3.4	CONNECTION AND DISCONNECTION PROCEDURE	8
3.5	TIME-OUT	8
3.6	RECOVERY FROM FAULT CONDITION	8
4	MOBITEX TERMINAL SPECIFICATION REFERENCE LIST	9

Signature

Raymond

A 292 5133.3

Cantel Mobitex

6/1056 - A 296 5171 Ue		
Date	Rev	File
1990-02-26	E	MTS11HDLC.1

1 INTRODUCTION

1.1 GENERAL

The designation "terminal" for a fixed terminal in the MOBITEK network corresponds to DTE in CCITT recommendations and secondary station in HDLC.

CCITT recommendation X.21 bis is used at the physical layer and HDLC is used at the link layer. The network layer consists of MPAK's according to reference R1-09.

Signature

Rayon

A 292 5153

Cantel Mobitex -

Sr No	6/1056 - A 296 5171 Ue
Start Date	1990-02-26
Rev	E
File No	MTS11HDLCL1

2 PHYSICAL LAYER

2.1 GENERAL

Connection is in accordance with CCITT recommendation X.21 bis.

2.2 BITRATE

For information about permitted bitrate transmission rates, please refer to reference R1-06.

Bullseye

Support

A 292 5155-3

Cantel Mobitex

6/1056 - A 296 5171 Ue

1990-02-26

E

MTS11HDLCL1

3 LINK LAYER

3.1 GENERAL

The design of the link layer follows ISO standards "High level data link control" (HDLC). See ISO 3309-1984, ISO 4335-1984 and ISO 7809-1984 for reference.

3.2 SUB-SET OF HDLC

HDLC is a comprehensive catalogue of standards for link control. The UNC 12 class, i.e. "Unbalanced operation, normal response mode" with added test function, of procedure is used for the link layer.

The MOBITEIX network is the primary station and the fixed terminal is the secondary station.

3.2.1 Clarification

3.2.1.1 Commands and responses

The following commands and responses are obtained with the above class:

Command from network	Response from fixed terminal
I	I
RR	RR
RNR	RNR
SNRM	UA
DISC	DM
TEST	FRMR
	TEST

3.2.1.2 Frame size

A frame can be up to 566 octets including start and stop flag. This will allow 560 octets in an information field in an I frame.

Enduser

Report

Cantel Mobitex

No. 6/1056 - A 296 5171 Ue	
Date 1990-02-26	Rev E
F. P. MTS11HDLCL	

3.2.1.3 The use of the address field

The address field comprises one octet. The address in the address field shall be adjustable. The factory set address shall be 11000000 (bit 1...8).

Address 11111111 is defined as the all-station address and thus all receiving data stations shall accept and action the associated frame. If the P bit is set in such a frame, the terminal shall reply with its own address as reply address.

3.2.1.4 FRMR responses

The information field in an FRMR response shall be padded with zeros so the length will be 3 octets.

3.2.1.5 TEST frames

TEST frames can contain an information field. The maximum length of that field is the same as for I-frames.

TEST frames can be transmitted and received both in NRM and NDM.

Blanket

Reprint

A 292 51530

Cantel Mobitex

SP. No. 6/1056 - A 296 5171 Ue		
Issued Date 1990-02-26	Rev E	P. No. MTS11HDL C.1

3.3 OPERATING MODES FOR THE LINK LAYER

The link layer shall be able to assume the following modes:

- o Normal response mode (NRM) according to ISO 4335 item 5.1.1.
- o Normal disconnected mode (NDM) according to ISO 4335 items 5.2 and 5.2.1.

A terminal's capacity in NDM is limited to:

- accepting the mode setting commands (SNRM or DISC)
- accepting and responding to a test command
- transmitting DM or TEST at a respond opportunity

A terminal may only change to NRM from NDM by accepting an SNRM command from the network.

A terminal can change from NRM to NDM by accepting a DISC command from the network or through manual restart of the link control. NDM shall be the initial mode when power is switched on or when restarting the terminal.

Bildzeit

Reprod

A 296 51350

Cantel Mobitex

No. 6/1056 - A 296 5171 Ue

Date 1990-02-26 Rev E P. P. MTS11HDLC.1

3.4 CONNECTION AND DISCONNECTION PROCEDURE

The link is connected in accordance with ISO 7809 item 3.4.1.1. The network transmits SNRM to the terminal. If there is no reply, the SNRM is retransmitted until an UA reply is received.

Normal disconnection of the link is in accordance with ISO 7808, item 3.4.1.2. If there is no reply from the terminal, DISC is retransmitted. This is repeated no more than 10 times or until an UA reply is received. The link is then assumed to be disconnected and the connection at the lower level can be broken.

If there are no frames to send, the link layer shall send flags continuously as soon as the physical layer is in data transmission mode.

3.5 TIME-OUT

When the terminal receives a correct frame with the P bit set to "1" (one), the reply shall commence within 50 ms. The time is calculated from when the last bit of the command's closing flag is received until the first bit of the response is transmitted.

If several frames are transmitted in sequence, the time between them shall not exceed 50 ms. This time is calculated from the last bit of a frame's closing flag to the first bit of the next frame's opening flag.

The terminal has no time-out function for recovery in the event of a link fault. The terminal however may have time-out function to inform the operator about a link fault. The time-out may not be less than 45s in NRM and 120 s in NDM.

3.6 RECOVERY FROM FAULT CONDITION

All recovery from a fault condition is carried out by the network. The terminal is first ordered to NDM and then to NRM.

Printed

Reprint

Cantel Mobitex™

6/1056 - A 296 5171 Ue	
Issue Date 1990-02-26	Rev E
P. F. # MTSL1LHDL.C.1	

4 MOBITEK TERMINAL-SPECIFICATION REFERENCE LIST

This document includes a number of references, made to other sections in the terminal specification. The list below shows these references, together with the page(s) they are made on. Please note that a section could be referred to several times on the same page.

RI-05, 4
RI-09, 3

Below are the reference designations listed.

<u>Reference</u>	<u>Section</u>
RI-01	Arrangement of the documents
RI-02	MOBITEK System description
RI-03	General description of terminals
RI-04	Terminology
RI-05	References
RI-06	Network operator information
RI-08	Application layer
RI-09	Network layer
RI-11	Interface requirements, fixed terminals
RI-12	Other requirements, fixed terminals
RI-15	Link layer, mobile terminals
RI-17	Physical layer, mobile terminals
RI-18	Radio equipment, mobile terminals
RI-19	Other interfaces, mobile terminals
RI-20	Other requirements, mobile terminals

The following external references are made in this document:

CCITT recommendations series X, 1984 Edition (Red Book) X.21 bis

ISO-standards:

ISO 3309-1984(E)
ISO 4335-1984(E)
ISO 7809-1984(E)

Bulkart

Reprod

Contract - Project 1988 ET/SYS PES	Publication - Report response ET/SYS PES	No. No 1056 - A 296 5491 Ue	
Declarer Outlines - Document approval ET/SYSC STT 577		Document Date 1990-02-26	Pl. File MTS11X25.1
Description Cantel Mobitex -		Title MOBITEX X.25 interface Fixed terminal	
<p><u>ABSTRACT</u></p> <p>This document is a specification of the interface for a fixed terminal with X.25 interface, connected to the MOBITEX network.</p>			
<div style="border: 1px solid black; height: 500px; width: 100%;"></div>			
<div style="border: 1px solid black; height: 50px; width: 100%;"></div>			
<div style="border: 1px solid black; height: 50px; width: 100%;"></div>			

Cantel Mobitex

Nr. No.	1056 - A 296 5491 Ue
Datum Jahr	1990-02-26 C
PC F.	MTS11X25.1

TABLE OF CONTENTS

1	INTRODUCTION	3
1.1	GENERAL	3
2	PHYSICAL LAYER	4
2.1	GENERAL	4
2.2	BITRATE	4
3	LINK LAYER	5
4	PACKET LAYER	6
4.1	Diagnostic codes	8
5	MOBITEX NETWORK LAYER	10
6	MOBITEX TERMINAL SPECIFICATION REFERENCE LIST	11

Blickort

Repro

A 292 5153-3

Cantel Mobitex

No. 1056 - A 296 5491 Use

Date: 1990-02-26 Rev. C

Is for MTS11X25.1

1 INTRODUCTION

1.1 GENERAL

The designation 'terminal' for a fixed terminal in the MOBITEK network corresponds to DTE in CCITT recommendations for X.25 packet layer and link layer.

Connection of a terminal with X.25-interface can be done directly to the MOBITEK network or through an X.25 network.

CCITT recommendation X.21 bis is used at the physical layer, LAPB is used at the link layer and X.25 is used at the packet layer.

The user data in X.25 packet layer should contain MPAKs as described in reference R1-09.

Booklet

Reprod

A 292 5155-3

Cantel Mobitex -

Ser No	1056 - A 296 5491	Ue
Serial Date	1990-02-26	C
P. P. A	MTS11X25.1	

2 PHYSICAL LAYER

2.1 GENERAL

Connection is in accordance with CCITT recommendation X.21 bis.

2.2 BITRATE

For information about permitted bitrate transmission rates, please refer to reference R1-06.

Bulkart

Reprod

A 992 31533

Cantel Mobitex -

No. Rev.		1056 - A 296 5491 Ue
Date	Rev	1990-02-26 C
F. File		MTS11X25.1

3 LINK LAYER

The design of the link layer follows LAPB, Link Access Procedure Balanced, according to CCITT recommendation X.25.

The extended format modulo 128 is not supported.

The multilink procedure MLP is not supported.

Timeout period is T1=3 seconds.

Maximum number of outstanding frames are K=7.

Number of retransmission attempts are N2=10.

Bidkort

Sagrad

A 292 51543

Cantel Mobitex

No. 1056	- A 296 5491	Ue
Execution Date 1990-02-26	Ver C	EC File MTS11X25.1

4 PACKET LAYER

The design of the packet layer follows CCITT recommendation X.25 for DTE with the following restrictions:

When the terminal is using direct connection there is only one logical channel. The logical channel group number should be zero and the logical channel number should be one.

When connection is made through an X.25 network, maximum number of logical channels are 8.

The delivery-bit should be set to zero in all data packets.

The qualifier-bit is ignored by the MOBITEK network.

The sequence numbering scheme of the data packets is performed modulo 8.

The standard default value for the window size is two packets. It is possible to change the default window size to 1, 3, 4, 5, 6 or 7 packets.

The standard default value for the packet size is 128 octets. It is possible to change the default packet size to 32, 64, 256, or 512 octets.

Interrupt, reject and registration packets are not supported.

The following facilities are supported:

- Flow control parameter negotiation.
- Non standard default packet size.
- Non standard default window size.
- Reverse charging. (See note 1.)
- Reverse charging acceptance. (See note 1.)

A connected terminal can communicate with MOBITEK through a permanent virtual circuit (PVC) or through a virtual circuit (VC).

Indices

Regime

A 292 51432

Cantel Mobitex

Doc No
1056 - A 296 5491 Ue

Issue Date
1990-02-26 C

File No
MTS11X25.1

If no packets, in either direction, has been transmitted on the logical channel during X (default 4 and possible to change) minutes a virtual call will be cleared by the MOBITEK network if the connection is VC.

Note 1 : Only used when connected through an X.25 network.

The packet call request/incoming call and call accepted/call connected should contain both calling DTE address and called DTE address (optional in CCITT X.25).

Bladders

Reprod

A 296 51333

Cantel Mobitex

Doc No	1056 - A 296 5491 Ue
Issue Date	1990-02-26
Rev	C
File No	MTS11X25.1

4.1 Diagnostic codes

Coding of the restarting cause field and the diagnostic code field in a restart packet, used by the MOBITEK network and the connected terminal.

cause	diag.	explanation
00		local procedure error
17		invalid packet type for state r1
52		time expired for restart indication
07		network operational

Coding of the clearing cause field and the diagnostic code field in a clear packet, used by the MOBITEK network and the connected terminal.

cause	diag.	explanation
0		dte originated
0		dte clearing
01		number busy
72		call collision
03		invalid facility request
65		facility code not allowed
66		facility parameter not allowed
19		local procedure error
20		invalid packet type for state p1
21		invalid packet type for state p2
22		invalid packet type for state p3
24		invalid packet type for state p4
26		invalid packet type for state p6
33		unidentifiable packet
38		packet too short
41		restart with nonzero in bits 1-4 in octet 1 or nonzero in bits 1-8 in octet 2
49		time expired for incoming call
50		time expired for clear indication
51		time expired for reset indication
67		invalid called address
68		invalid calling address
69		invalid facility length

Uddm:

Reprod

Cantel Mobitex

Doc. No. 1056 - A 296 5491 Ue
Docum. Date 1990-02-26 Rev. C Pl. No. MTS11X25.1

Coding of the resetting cause field and the diagnostic code field in a reset packet, used by the MOBITEK network and the connected terminal.

<u>cause</u>	<u>diagn.</u>	<u>explanation</u>
05		local procedure error
	01	invalid p(s)
	02	invalid p(r)
	27	invalid packet type for state d1
	32	packet type not allowed (registration or interrupt packet)
	35	invalid packet type on pvc channel
	37	reject packet not subscribed
	41	restart with nonzero in bits 1-4 in octet 1 or nonzero in bits 1-8 in octet 2
	51	time expired for reset indication

Coding of the diagnostic code field in a diagnostic packet, used by the MOBITEK network and the connected terminal.

<u>diagn.</u>	<u>explanation</u>
36	packet on unassigned logical channel
38	packet too short
40	invalid general format identifier
50	time expired for clear indication
51	time expired for reset indication
52	time expired for restart indication

Block:

Diagram

Cantel Mobitex-

No. No	1056 - A 296 5491 Ue	
Issue Date	Rev	PC File
1990-02-26	C	MTS11X25.1

5 MOBITEK NETWORK LAYER

The MPAK should be placed in the user data field in one or more X.25 data packets. An MPAK should be handled as a complete packet sequence, according to CCITT's X.25 recommendation # 4.3.5.

Note: The D-bit should always be set to zero in communication with the MOBITEK network.

If the transmission of an MPAK is interrupted by a restart, reset or clear procedure the whole MPAK should be retransmitted.

Blockout

Reprod

A 292 51550

Cantel Mobitex

Rev. No.	1056 - A 296 5491 Ue	
Version - Date	Rev	File No.
1990-02-26	C	MTS11X25.1

6 MOBITEK TERMINAL SPECIFICATION REFERENCE LIST

This document includes a number of references, made to other sections in the terminal specification. The list below shows these references, together with the page(s) they are made on. Please note that a section could be referred to several times on the same page.

RI-06, 4
RI-09, 3

Below are the reference designations listed.

Reference	Section
RI-01	Arrangement of the documents
RI-02	MOBITEK System description
RI-03	General description of terminals
RI-04	Terminology
RI-05	References
RI-06	Network operator information
RI-08	Application layer
RI-09	Network layer
RI-11	Interface requirements, fixed terminals
RI-12	Other requirements, fixed terminals
RI-16	Link layer, mobile terminals
RI-17	Physical layer, mobile terminals
RI-18	Radio equipment, mobile terminals
RI-19	Other interfaces, mobile terminals
RI-20	Other requirements, mobile terminals

The following external references are made in this document:

CCITT recommendations series X, 1984 edition (Red book) X.25 and X.21 bis

Bildart

Reprod

A 297 5153-3

Uppgavs-Prepared 1988 ET/SYS PES	Färdigställning Subject response ET/SYS PES	Sty No 1056 - A 296 5490 Ue
Dokument Godkännat - Doc response approved ET/SYSC STT 577	Datum - Date 1990-02-26	Rev C
Benämning Cantel Mobitex -	Titel MOBITEX BSC interface Fixed terminal	
<p><u>ABSTRACT</u></p> <p>This document is a specification of the interface for a fixed terminal with binary synchronous communication (BSC) interface, connected to the MOBITEX network.</p>		
<div style="border: 1px solid black; height: 500px; width: 100%;"></div>		
<div style="border: 1px solid black; height: 50px; width: 100%;"></div>		
<div style="border: 1px solid black; height: 50px; width: 100%;"></div>		

Cantel Mobitex

No. 20	1056 - A 296 5490 Ue
Version Date	1990-02-26 C
File Name	MTS11BSC.1

TABLE OF CONTENTS

1	INTRODUCTION	3
1.1	GENERAL	3
2	PHYSICAL LAYER	4
2.1	GENERAL	4
2.2	BITRATE	4
3	LINK LAYER	5
4	NETWORK LAYER	6
5	SPECIFICATION OF BSCPAK	7
5.1	BSCPAK, COMMON COMPONENTS	7
5.2	BSCPAK COMPONENTS	8
6	TRANSLATION BETWEEN ASCII AND EDCDIC	15
7	MOBITEX TERMINAL SPECIFICATION REFERENCE LIST	17

Subpart

Reprint

A 292 51334

Cantel Mobitex-

Doc No	1056 - A 296 5490 Ue	
Date	1990-02-26	Rev C
Doc No	MTS11BSC.1	

1 INTRODUCTION

1.1 GENERAL

The designation "terminal" for a fixed terminal in the MOBITEK network corresponds to DTE in CCITT recommendations.

CCITT recommendation X.21 bis is used at the physical layer. The link layer is IBM's BSC (binary synchronous communication), see chapter 2.

The network layer is a character oriented MPAK (BSCPAK), see chapter 4.

Bildart

Reproce

A 292 5153G

Cantel Mobitex

Doc. No.	1056 - A 296 5490	Ue
Issue Date	1990-02-26	C
Yr. For	MTS11BSC.1	

2 PHYSICAL LAYER

2.1 GENERAL

Connection is in accordance with CCITT recommendation X.21 bis.

2.2 BITRATE

For information about permitted bitrate transmission rates, please refer to reference R1-06.

Revised

Revised

A 102 51353

Cantel Mobitex

1056 - A 296 5490 Ue

1990-02-26 C

MTS11BSC.1

3 LINK LAYER

The design of the link layer follows IBM General Information - Binary Synchronous Communications, GA27-3004 with the following restrictions:

Point-to-point connection is used. The Mobitex network has a retry timeout of 3 seconds.

ITB and RVI will be handled by the Mobitex network when received, but is never transmitted.

Transparent mode is not handled by the Mobitex network.

SOH can be received but the content of the header is not interpreted. SOE is never transmitted.

The Mobitex network retransmits max 15 times.

Revised

Reprod

A 296 51350

Cantel Mobitex

No. 1056 - A 296 5490 Ue			
<table border="1"> <tr> <td>Version 1990-02-26</td> <td>Rev C</td> <td>File MTS11BSC.1</td> </tr> </table>	Version 1990-02-26	Rev C	File MTS11BSC.1
Version 1990-02-26	Rev C	File MTS11BSC.1	

4 NETWORK LAYER

The network layer use BSCPAK. A BSCPAK is a character-oriented MPAK, MPAKs are bit-oriented and are described in reference R1-09.

BSCPAK is EBCDIC-coded, see chapter 6.

All MPAK, except MPAK DATA, HPDATA and EXTPAK can be translated to BSCPAK.

Sendlist is not handled.

All numeric fields are right adjusted with preceding zeroes.

BSCPAK shall be handled in the same way as corresponding MPAK.

Maximum length for a BSCPAK is 548 octets (BSCPAK TEXT without sendlist).

A BSCPAK may be divided into several blocks, each of which ends with ETB except the last one which ends with ETX.

The content of the text field in a BSC-block is a BSCPAK (or part of BSCPAK) in either direction, to or from the Mobitex network.

STX precedes and ETX ends a BSCPAK.

Bildkort

Revised

Cantel Mobitex

No. 1056 - A 296 5490 Ue

System Date 1990-02-26

C

P. 1.1 MTS11BSC.1

5 SPECIFICATION OF BSCPAK

BSCPAK shall be handled, according to reference R1-09, in the same way as corresponding MPAK. Below is a description of the translation between bit-oriented MPAK and the character oriented BSCPAK.

All BSCPAKs consist of one BSCPAK header and one part with typedependent components.

All characters in a BSCPAK shall be in EBCDIC code.

5.1 BSCPAK, COMMON COMPONENTS

BSCPAK-field	octet	comment
sender	1-8	only digits
addressee	9-16	only digits
class	17	only digits
extern_F	18	0 or 1
type	19-20	only digits
mailbox_F	21	0 or 1
digital_F	22	0 or 1
sendlist_F	23	0
unknown_F	24	0 or 1 (0 from Mobitex)
reserve_F	25	0
trafstate	26	0 ... 7 (0 to Mobitex)

Length 26 octets.

Ex. sender = 123456

octet 1

0

0

1

2

3

4

5

octet 8

6

Octet 1 will be transmitted first.

Bidkort:

Reprod

Cantel Mobitex

No.	1056 - A 296 5490	Ue
Date	1990-02-26	Rev
	C	File
		MTS11BSC.1

5.2 BSCPAK COMPONENTS

The following components are described in this chapter:

TEXT
STATUS
SOSINFO
SOSACK
CONREQ
SOSCONREQ
ADDCONREQ
CONGRA
CONORD
CONREA
DISCON
EXTCONREQ
CLOOFON
CLOOFF
LOGINREQ
LOGINRA
LOGINREF
LOGOUT
LOGOUTORD
ACTIVE
INACTIVE
DIE
LIVE
VICESOSRX
SOSRX
GROUPLIST
FLEXREQ
FLEXLIST
TIME

Bidder

Reprint

Cantel Mobitex

St. No. 1056 - A 296 5490	Ue
Current Date 1990-02-26	Rev C
T. File MTS11BSC.1	

* TEXT without adress list:

BSCPAK-field	octet	comment
bscpak-header	1-26	
time	27-36	decimal digits (YYMMDDHHMM)
text	37-	all characters included in Mobitex textcode (EBCDIC-coded), 1-512 characters

Length 37-548 octets.

* STATUS without adress list:

BSCPAK-field	octet	comment
bscpak-header	1-26	
time	27-36	decimal digits (YYMMDDHHMM)
status code	37-39	only digits 000 ... 255

Length 39 octets.

* SOSINFO

BSCPAK-field	octet	comment
bscpak-header	1-26	
time	27-36	decimal digits (YYMMDDHHMM)
static emergency information	37-	all characters included in Mobitex textcode (EBCDIC-coded), 0-256 characters
dynamic emergency information	37-	all characters included in Mobitex textcode (EBCDIC-coded), 0-256 characters

Length 36-548 octets.

* SOSACK

BSCPAK-field	octet	comment
bscpak-header	1-26	
time	27-36	decimal digits (YYMMDDHHMM)
emergency acknowledgement status	37-39	decimal digits 000..255

Length 39 octets.

Bulkart

Reprod

Cantel Mobitex-

Doc No	1056 - A 296 5490 Ue
Issue Date	1990-02-26
Rev	C
File No	MTS11BSC.1

* CONREQ

BSCPAK-field	octet	comment
bscpak-header	1-26	
line number	27-29	decimal digits 000..255 (000 from terminal)
connection identity	30-32	decimal digits 000..255

Length 32 octets.

* SOSCONREQ

BSCPAK-field	octet	comment
bscpak-header	1-26	
line number	27-29	decimal digits 000..255 (000 from terminal)
connection identity	30-32	decimal digits 000..255

Length 32 octets.

* ADDCONREQ

BSCPAK-field	octet	comment
bscpak-header	1-26	
line number	27-29	decimal digits 000..255 (000 from terminal)
connection identity	30-32	decimal digits 000..255
additional information	33-52	all characters included in Mobitex textcode (EBCDIC- coded)

Length 52 octets.

* CONGRA

BSCPAK-field	octet	comment
bscpak-header	1-26	
line number	27-29	decimal digits 000..255 (000 from terminal)
connection identity	30-32	decimal digits 000..255

Length 32 octets.

Backert

Haynes

A.292 41593

Cantel Mobitex

Doc No
1056 - A 296 5490 Ue
Doc Date
1990-02-26
Rev
C
Doc No
MTS11BSC.1

* CONORD

BSCPAK-field	octet	comment
bscpak-header	1-26	
line number	27-29	decimal digits 000..255 (000 from terminal)
connection identity	30-32	decimal digits 000..255

Length 32 octets.

* CONREA

BSCPAK-field	octet	comment
bscpak-header	1-26	
line number	27-29	decimal digits 000..255 (000 from terminal)
connection identity	30-32	decimal digits 000..255

Length 32 octets.

* DISCON

BSCPAK-field	octet	comment
bscpak-header	1-26	
line number	27-29	decimal digits 000..255 (000 from terminal)
connection identity	30-32	decimal digits 000..255

Length 32 octets.

* EXTCONREQ

BSCPAK-field	octet	comment
bscpak-header	1-26	
line number	27-29	decimal digits 000..255 (000 from terminal)
connection identity	30-32	decimal digits 000..255
subscr. no. in ext. network	33-52	decimal digits

Length 52 octets.

* CLOOPON

BSCPAK-field	octet	comment
bscpak-header	1-26	
line number	27-29	decimal digits 000..255 (000 from terminal)

Length 29 octets.

Bulkshort

Reprod

Cantel Mobitex

No. 1056 - A 296 5490 Ue						
<table border="1"> <tr> <td>Station Date</td> <td>1990-02-26</td> <td>Rev</td> <td>C</td> <td>File</td> <td>MTS11BSC.1</td> </tr> </table>	Station Date	1990-02-26	Rev	C	File	MTS11BSC.1
Station Date	1990-02-26	Rev	C	File	MTS11BSC.1	

* CLOOPOFF

BSCPAK-field	octet	comment
bscpak-header	1-26	
line number	27-29	decimal digits 000..255 (000 from terminal)

Length 29 octets.

* LOGINREQ

BSCPAK-field	octet	comment
bscpak-header	1-26	
MAN	27-34	only decimal digits
password	35-42	all characters included in Mobitex textcode (EBCDIC- coded)

Length 42 octets.

* LOGINGRA

BSCPAK-field	octet	comment
bscpak-header	1-26	
MAN	27-34	only decimal digits

Length 34 octets.

* LOGINREF

BSCPAK-field	octet	comment
bscpak-header	1-26	
MAN	27-34	only decimal digits

Length 34 octets.

* LOGOUT

BSCPAK-field	octet	comment
bscpak-header	1-26	
MAN	27-34	only decimal digits

Length 34 octets.

Student

Reprod

Cantel Mobitex-

Doc. No.	1056 - A 296 5490	Doc.	Ue
Issue Date	1990-02-26	Issue	C
Doc. Title	MTS11BSC.1		

* LOGOUTORD

BSCPAK-field	octet	comment
bscpak-header	1-26	
MAN	27-34	only decimal digits

Length 34 octets.

* ACTIVE

BSCPAK-field	octet	comment
bscpak-header	1-26	

Length 26 octets.

* INACTIVE

BSCPAK-field	octet	comment
bscpak-header	1-26	

Length 26 octets.

* DIE

BSCPAK-field	octet	comment
bscpak-header	1-26	

Length 26 octets.

* LIVE

BSCPAK-field	octet	comment
bscpak-header	1-26	

Length 26 octets.

* VICESOSRX

BSCPAK-field	octet	comment
bscpak-header	1-26	

Length 26 octets.

* SOSRX

BSCPAK-field	octet	comment
bscpak-header	1-26	

Length 26 octets.

Bitkart

Reprod

Cantel Mobitex

Ver No
1056 - A 296 5490 Ue
Doc Date 1990-02-26 Rev C Fl. For MTS11BSC.1

* GROUPLIST

BSCPAK-field	octet	comment
bscpak-header	1-26	
number of MAN	27-28	1..15
MAN 1	29- 36	only decimal digits
MAN 2	37- 44	only decimal digits
MAN 3	45- 52	only decimal digits
MAN 4	53- 60	only decimal digits
MAN 5	61- 68	only decimal digits
MAN 6	69- 76	only decimal digits
MAN 7	77- 84	only decimal digits
MAN 8	85- 92	only decimal digits
MAN 9	93-100	only decimal digits
MAN 10	101-108	only decimal digits
MAN 11	109-116	only decimal digits
MAN 12	117-124	only decimal digits
MAN 13	125-132	only decimal digits
MAN 14	133-140	only decimal digits
MAN 15	141-148	only decimal digits

Length 148 octets.

* FLEXREQ

BSCPAK-field	octet	comment
bscpak-header	1-26	

Length 26 octets.

* FLEXLIST

BSCPAK-field	octet	comment
bscpak-header	1-26	
number of MAN	27	1..7
MAN 1	28-35	only decimal digits
MAN 2	36-43	only decimal digits
MAN 3	44-51	only decimal digits
MAN 4	52-59	only decimal digits
MAN 5	60-67	only decimal digits
MAN 6	68-75	only decimal digits
MAN 7	76-83	only decimal digits

Length 83 octets.

* TIME

BSCPAK-field	octet	comment
bscpak-header	1-26	
time	27-36	decimal digits (YYMMDDHHMM)

Length 36 octets.

Wizards

Reprod

Cantel Mobitex

St. No.	1056 - A 296 5490 Ue	
Current Date	1990-02-26	Rev. C
		File No. MTS11BSC.1

6 TRANSLATION BETWEEN ASCII AND EBCDIC

ASCII EBCDIC

09	05
0A	25
0C	0C
0D	0D
20	40
21	5A
22	7F
23	7B
24	5B
25	6C
26	50
27	7D
28	4D
29	5D
2A	5C
2B	4E
2C	6B
2D	60
2E	4B
2F	61
30	F0
31	F1
32	F2
33	F3
34	F4
35	F5
36	F6
37	F7
38	F8
39	F9
3A	7A
3B	5E
3C	4C
3D	7E
3E	6E
3F	6F
40	7C
41	C1
42	C2
43	C3
44	C4
45	C5
46	C6
47	C7
48	C8
49	C9
4A	D1
4B	D2
4C	D3
4D	D4
4E	D5

Reprint

Reprint

A 292 51533

Cantel Mobitex		Sr. No		1056 - A 296 5490 Ue	
		Date - Date		1990-02-26 C	
		F. No		MTS11BSC.1	
4F	D6				
50	D7				
51	D8				
52	D9				
53	E2				
54	E3				
55	E4				
56	E5				
57	E6				
58	E7				
59	E8				
5A	E9				
5B	4A				
5C	E0				
5D	4F				
5E	5F				
5F	6D				
60	79				
61	81				
62	82				
63	83				
64	84				
65	85				
66	86				
67	87				
68	88				
69	89				
6A	91				
6B	92				
6C	93				
6D	94				
6E	95				
6F	96				
70	97				
71	98				
72	99				
73	A2				
74	A3				
75	A4				
76	A5				
77	A6				
78	A7				
79	A8				
7A	A9				
7B	C0				
7C	6A				
7D	D0				
7E	A1				

Bidkare

Regrod

A 292 51533

Cantel Mobitex -

Doc No 1056 - A 296 5490 Ue		
Current Date 1990-02-26	Rev C	P. F. n MTS11BSC.1

7 MOBITEK TERMINAL SPECIFICATION REFERENCE LIST

This document includes a number of references, made to other sections in the terminal specification. The list below shows these references, together with the page(s) they are made on. Please note that a section could be referred to several times on the same page.

RI-06, 4
RI-09, 6, 7

Below are the reference designations listed.

<u>Reference</u>	<u>Section</u>
RI-01	Arrangement of the documents
RI-02	MOBITEK System description
RI-03	General description of terminals
RI-04	Terminology
RI-05	References
RI-06	Network operator information
RI-08	Application layer
RI-09	Network layer
RI-11	Interface requirements, fixed terminals
RI-12	Other requirements, fixed terminals
RI-16	Link layer, mobile terminals
RI-17	Physical layer, mobile terminals
RI-18	Radio equipment, mobile terminals
RI-19	Other interfaces, mobile terminals
RI-20	Other requirements, mobile terminals

The following references are made in this document:

CCITT recommendations series V, 1984 Edition (Red books) X.21 bis.

IBM General Information - Binary Synchronous Communications, GA27-3004.

Blanket

Reprod

Upper: Prepared 1988 ET/SYS PES	Facilities: Subject responsible ET/SYS PES	Sr. No. 1056 - A 296 5516 Ue	
Deliver: Delivered - Opt. response: approved ET/SYSC STT 57		System Date 1990-02-26	Rev D
Designation*		File MOBITEX MASC interface Fixed terminal	
<h1>Cantel Mobitex</h1>			
<p>ABSTRACT</p> <p>This document is a specification of the interface for a fixed terminal with MOBITEK Asynchronous Communication (MASC) interface, connected to the MOBITEK network.</p>			
<div> <div>Build:</div> <div>Revised:</div> </div>			

Cantel Mobitex -

No. 1056 - A 296 5516 Ue	
Version Date 1990-02-26	Rev D
File Name MTS1LMASC.1	

TABLE OF CONTENTS

1	INTRODUCTION	3
1.1	GENERAL	3
2	PHYSICAL LAYER	4
2.1	GENERAL	4
2.2	BITRATE	4
3	LINK LAYER	5
3.1	GENERAL	5
3.2	FRAMES USED IN MASC	5
3.3	TIMEOUT	6
3.4	START WITH NO SUBSCRIPTION NUMBER	6
4	MOBITEX TERMINAL SPECIFICATION REFERENCE LIST	7

BuildKort

Regres

A 292 5153-3

Cantel Mobitex

No. 1056 - A 296 5516 Ue		
DATE: 1990-02-26	REV: D	FILE: MTS11MASC.1

1 INTRODUCTION

1.1 GENERAL

The designation "terminal" for a fixed terminal in the MOBITEK network correspond to DTE in CCITT recommendations.

CCITT recommendation V.24 is used at the physical layer and MASC interface is used at the link layer (reference R1-19 is used for link layer MASC). The network layer consists of MPAK's according to reference R1-09.

Revised

Revised

A 292 51533

Cantel Mobitex

Ser. No.		1056 - A 296 5516		Ue
Datum / Date		1 Rev	F. No.	
1990-02-26		D	MTS11MASC.1	

2 PHYSICAL LAYER

2.1 GENERAL

Connection is in accordance with CCITT recommendation V.24/V.28.

Note: The physical layer of MASC is not directly compatible with the physical layer in the masc interface of a mobile terminal.

However this can be done by connecting the following signals in the mobile unit.

105	<input type="checkbox"/>
106	<input type="checkbox"/>
107	<input type="checkbox"/>
108/2	<input type="checkbox"/>
109	<input type="checkbox"/>

2.2 BITRATE

For information about permitted bitrate transmission rates, please see reference RI-06.

Brickens

Reprod

A 101 51553

Cantel Mobitex

Doc No 1056 - A 296 5516 Ue
 Syntex Date 1990-02-26 Rev D File MTS11MASC.1

3 LINK LAYER

3.1 GENERAL

The link layer sends, controls and acknowledge information between network and terminal. When faults are detected, the link layer handles retransmission.

The design of the link layer follows PROTOCOL FOR MASC TYPE TERMINALS, which is described in reference R1-19.

The data in information frame is MOBITEK packets (MPAK) which are described in reference R1-09.

3.2 FRAMES USED IN MASC

There are two different types of frames, control frames and information frames (see reference R1-19).

The following control frames are used:

- ACK Acknowledgement
- NACK Negative acknowledgement
- RACK Request for repetition of the latest sent ACK
- SENS Communication link control
- SACK Acknowledgement of a received SENS

Note: The network will not send the frame SENS by default.

Information frames are used with the following commands:

- B parameters in machine interface
- M send/receive MPAK
- E answer to an invalid command
- F P terminal MAN request and answer
- F Q masc device identity

Business

Report

Cantel Mobitex -

Rev No	1056 - A 296 5516 Ue	
Drawn Date	Rev	File Name
1990-02-26	D	MTS11MASC.1

3.3 TIMEOUT

The masc interface uses two timers, which are described in reference R1-19.

Note: The network will handle the "30 seconds timeout" as follows:
If no answer is received within 30 seconds, the network will return the frame to the sender. The network will then try to start up the line with a B-command.

3.4 START WITH NO SUBSCRIPTION NUMBER

The terminal has the possibility to ask the network about the valid subscription number. When the line is in the connected mode, the terminal can ask the network about MOBITEK subscription number.

The terminal sends the F P command and receives the answer F PMAN from the network. The terminal will also receive an identification of the network in the F Q command.

The commands F P and F Q are described in reference R1-19.

Bildern

Reprod

A 292 51330

Cantel Mobitex

No. 1056 - A 296 5516 Ue	
Date - Date 1990-02-26	Rev D
Ft. File MTS1LMASC.1	

4 MOBITEK TERMINAL SPECIFICATION REFERENCE LIST

This document includes a number of references, made to other sections in the terminal specification. The list below shows these references, together with the page(s) they are made on. Please note that a section could be referred to several times on the same page.

RI-06, 4
RI-09, 3, 5
RI-19, 3, 5, 6

Below are the reference designations listed.

<u>Reference</u>	<u>Section</u>
RI-01	Arrangement of the documents
RI-02	MOBITEK System description
RI-03	General Description of terminals
RI-04	Terminology
RI-05	References
RI-06	Network operator information
RI-08	Application layer
RI-09	Network layer
RI-11	Interface requirements, fixed terminals
RI-12	Other requirements, fixed terminals
RI-16	Link layer, mobile terminals
RI-17	Physical layer, mobile terminals
RI-18	Radio equipment, mobile terminals
RI-19	Other interfaces, mobile terminals
RI-20	Other requirements, mobile terminals

The following external references are made in this document:

CCITT recommendations series V, 1984 Edition (Red books) V.24 and V.28

Indicate

Reprod

A 296 51553

REQUIREMENT SPECIFICATION 1(7)

PROJECT NAME ET/SYS PES	FUNCTIONAL DESCRIPTION ET/SYS PES	No. 1056 - A 296 5454 Ue	
CHARACTERISTICS OF IMPLEMENTATION ET/SYSC STT <i>ST</i>		DATE GEN 1990-02-27 C	P. File MES11MPAD.1
<p>Cantel Mobitex</p>		<p>MOBITEX Asynchronous interface Fixed terminal MPAD</p>	
<p><u>ABSTRACT</u></p> <p>This document describes the connection of an asynchronous terminal to the MPAD service in the MOBITEK network.</p>			
<p>Blanket</p>			
<p>Reprod</p>			

A 292 51320

Cantel Mobitex

Spec No		1056 - A 296 5454 Ue
Revision	Date	1990-02-27 C
File Name		MTS11MPAD.1

TABLE OF CONTENTS

1	INTRODUCTION	3
1.1	GENERAL	3
2	PHYSICAL LAYER	4
2.1	GENERAL	4
2.2	TERMINAL EQUIPMENT	4
2.3	PRINTER EQUIPMENT (optional)	4
2.4	BITRATE	4
3	PROTOCOL FOR TERMINAL	5
3.1	CONTROL SEQUENCES FROM TERMINAL TO MPAD	6
3.2	CONTROL SEQUENCES FROM MPAD TO TERMINAL	6

Endorse

Revised

Cantel Mobitex-

N. S.
1056 - A 296 5454 Ue

Doc. Date
1990-02-27 C

F. P. A
MTS11MPAD.1

1 INTRODUCTION

1.1 GENERAL

The MPAD communicates with the terminal one character at a time with a start-stop protocol. The purpose with the MPAD service is to let customers use a standard terminal for communication with the MOBITEK network.

The designation "terminal" for a fixed terminal in the MOBITEK network corresponds to DTE in CCITT recommendations.

Bildart

Reprod

A 296 5454

Cantel Mobitex

No. 59	1056 - A 296 5454	Ue
Origin Date	1990-02-27	C
File No.	MTS11MPAD.1	

2 PHYSICAL LAYER

2.1 GENERAL

Connection is in accordance with CCITT recommendations V.24/V.28.

2.2 TERMINAL EQUIPMENT

An asynchronous terminal of start-stop type for serial data transmission is used. The communication uses 1 start bit, 8 data bits, 1 stop bit and no parity. The screen should be 24 lines x 80 columns. The terminal should have an advanced video option installed to use the reversed video facility.

If the MPAD-connected terminal has a printer port or auxiliary port, a printer can be connected to this port. Messages to/from the terminal can be directed to this printer if the terminal can interpret the printer-port setting commands described in chapter 3.

2.3 PRINTER EQUIPMENT (optional)

The printer should have at least 24 columns, preferably 80 columns width. The transmission rate and communication type depends on the available printer-port on the terminal. The printer should be able to use the same character-set as the terminal, see chapter 3.

2.4 BITRATE

For information about permitted transmission rates, please refer to reference R1-06.

Budget

Report

A 292 51533

Cantel Mobitex

No.	1056 - A 296 5454	Use
System Date	1990-02-27	File No.
	C	MTS11MPAD.1

3 PROTOCOL FOR TERMINAL

The terminal should comply with ANSI/VT100 according to the following specifications that is a subset of ANSI X3.41 1974 and ANSI X3.64 1979.

The terminal should be able to :

- * transmit and receive all characters described in MOBITEX text code (please refer to reference R1-06).
- * transmit ASCII-character 127 (DEL).
- * receive ASCII-character 7 (bell) and then give an audible signal.
- * receive ASCII-character 10 (LF) and then do a line-feed.
- * receive ASCII-character 13 (CR) and then do a carriage return.
- * generate the control sequences described in chapter 3.1
- * interpret the control sequences described in chapter 3.2

Bidders

Report

A 292 51539

Cantel Mobitex -

N.°	1056 - A 296 5454 Ue
Docum. Date	1990-02-27
Rev	C
F. File	MTS11MPAD.1

3.1 CONTROL SEQUENCES FROM TERMINAL TO MPAD

The following control sequences should preferably be generated by arrow-marked keys.

```
ESC O A      (arrow up)
ESC O B      (arrow down)
ESC O C      (arrow right)
ESC O D      (arrow left)
```

The following control sequences should preferably be generated by the keys on an auxiliary keypad.

```
ESC O p      (0)
ESC O q      (1)
ESC O r      (2)
ESC O s      (3)
ESC O t      (4)
ESC O u      (5)
ESC O v      (6)
ESC O w      (7)
ESC O x      (8)
ESC O y      (9)
ESC O m      (dash)
ESC O l      (=lowercase L)(comma)
ESC O n      (period)
ESC O M      (ENTER)
ESC O P      (PF1)
ESC O Q      (PF2)
ESC O R      (PF3)
ESC O S      (PF4)
```

3.2 CONTROL SEQUENCES FROM MPAD TO TERMINAL

```
ESC =        Set terminal in keypad application mode
ESC 7        Save cursor
ESC 8        Restore cursor
ESC [ 7 m    Set reverse video
ESC [ 0 m    All video attributes off
ESC [ 5 i    Enter printer controller mode
ESC [ 4 i    Exit printer controller mode
ESC [ 0 k    Erase line after cursor
ESC E        Next line
ESC [ 20 h   Set new line mode
ESC [ x;y H  Move cursor to line x and column y
ESC [ ? 1 (=one) h   Set cursor key mode
ESC [ 2 J    Erase all of the display
```

Buildout

Reprod

A 292 5153-3

Cantel Mobitex

1056 - A 296 5454 Ue

1990-02-27 C

MTS11MPAD.1

4 MOBITEX TERMINAL SPECIFICATION REFERENCE LIST

This document includes a number of references, made to other sections in the terminal specification. The list below shows these references, together with the page(s) they are made on. Please note that a section could be referred to several times on the same page.

RI-06, 4, 5

Below are the reference designations listed.

<u>Reference</u>	<u>Section</u>
RI-01	Arrangement of the documents
RI-02	MOBITEX System description
RI-03	General description of terminals
RI-04	Terminology
RI-05	References
RI-06	Network operator information
RI-08	Application layer
RI-09	Network layer
RI-11	Interface requirements, fixed terminals
RI-12	Other requirements, fixed terminals
RI-16	Link layer, mobile terminals
RI-17	Physical layer, mobile terminals
RI-18	Radio equipment, mobile terminals
RI-19	Other interfaces, mobile terminals
RI-20	Other requirements, mobile terminals

The following external references are made in this document:

CCITT recommendations series V, 1984 Edition (Red books) V.24 and V.28

ANSI X3.41 1974

ANSI X3.64 1979

Budget

Report

A 292 51533

Uppgöts Projekt 1988 ET/SYS Pes	Fachbereichsteil Identifizierung ET/SYS Pes	Nr.-No 1056 - A 296 5176 Ue	
Deutscher Codebuch Der regionalen Identifizierung ET/SYSC STT <i>ST</i>		Datum - Date 1990-02-26 C	PC-File MTS12.1
Bemerkung Cantel Mobitex		Titel MOBITEX Other requirements, Fixed terminals	
<p><u>ABSTRACT</u></p> <p>This document specifies general requirements for fixed terminals, connected to the MOBITEX network.</p>			
<p>Stückzahl</p> <p>Reprod</p>			

A 292 5153/3

Cantel Mobitex™

No. 1056 - A 296 5176 Ue
Date: 1990-02-26 Rev: C File: MTS12.1

TABLE OF CONTENTS

1	GENERAL	3
2	ELECTRICAL SAFETY	3
3	SPECIFICATION OF LINE CONNECTION	3
4	MOBITEX TERMINAL SPECIFICATION REFERENCE LIST	4

Blanket

Reproducible

A 292 51503

Cantel Mobitex

No. 1056 - A 296 5176 Ue
 Section Date 1 Rev 1 P. 1
 1990-02-26 C MTS12.1

1 GENERAL

A fixed terminal is connected with a line interface for packet switching and line connection for line connection traffic (primarily speech). If the fixed terminal is connected to the mains, there are certain requirements for electrical safety.

2 ELECTRICAL SAFETY

For information about electrical safety requirements, please refer to R1-06.

3 SPECIFICATION OF LINE CONNECTION

A fixed terminal should permit line connection traffic as a complement to message traffic. For this to be possible, it is necessary to have a real time connection between terminal and network in addition to the message traffic interface. A connection of this type can be used for transmitting speech for example.

For information about line connection requirements, please refer to R1-06.

TYPE OF CONNECTION: 4 wire speech connection with one speech direction per line pair.

CONNECTION: ISO DIS 8877 plug of European or U.S. type.

FREQUENCY RANGE: 300 - 3400 Hz

RECEIVER LEVEL DIRECTION -15 -- -30 dBm

SENDER LEVEL DIRECTION -10 -- -23 dBm

SIGNAL/NOISE RATION REC./SEND.: Greater than 40 dB

Blanket

Report

A 292 11533

Cantel Mobitex -

No	1056 - A 296 5176 Ue
Revision	1990-02-26 C
File	MTS12.1

4 MOBITEX TERMINAL SPECIFICATION REFERENCE LIST

This document includes a number of references, made to other sections in the terminal specification. The list below shows these references, together with the page(s) they are made on. Please note that a section could be referred to several times on the same page.

R1-06, 3

Below are the reference designations listed.

<u>Reference</u>	<u>Section</u>
R1-01	Arrangement of the documents
R1-02	MOBITEX System description
R1-03	General description of terminals
R1-04	Terminology
R1-05	References
R1-06	Network operator information
R1-08	Application layer
R1-09	Network layer
R1-11	Interface requirements, fixed terminals
R1-12	Other requirements, fixed terminals
R1-16	Link layer, mobile terminals
R1-17	Physical layer, mobile terminals
R1-18	Radio equipment, mobile terminals
R1-19	Other interfaces, mobile terminals
R1-20	Other requirements, mobile terminals

Midwest

Expend

A 297 51553

Cantel Mobitex -

No. 24

Revision Date

Rev

File No.

EXPLANATION AND MODIFICATIONS

This chapter has been newly added. It is an addendum providing a preliminary specification of additional requirements for portable terminals designed for operation on the Mobitex network. The primary motivation for this addendum is the need to provide a low power operating mode for portable units, to extend the operating time of their self-contained batteries. Because enhancements have been made to network signalling protocols over the air interface, these additional requirements will have some effect on the operation of mobile units as well. A careful review of this chapter is therefore required of all terminal designers and manufacturers.

Since the addendum document was printed, several changes have been made to the protocol. They will be included in a future revision of the ERTEL - provided specification. These changes, which should be applied to the MTS 15.1 document immediately following, are detailed below so that this very important new information can be brought to the attention of interested parties in a timely manner.

1. Section 3.5, page 8: the first paragraph should be changed to read:

If the terminal has lost consecutive <SVP6> signals over a period less than 60 seconds, it should remain in the operating state to synchronize again. If the terminal has not succeeded in synchronizing within 60 seconds, it should initiate the roaming procedure.

2. Section 3.6, page 12: the two paragraphs under the heading "Evaluation of other base stations" should be changed to read:

The evaluation of base stations on the CURRENT-SYSTEM-CHANNEL should be based on the average received signal strength over a time period indicated in <SVP6> (default value, 60 seconds).

The integration time for evaluating base stations on other channels is indicated in <SVP6> (default value, 3 RSSI-PERIODS).

3. Section 3.8.1, page 13: the second paragraph under the heading "UP LINK TRAFFIC" should be changed to read:

For uplink traffic the terminal should enter the OPERATING state and then follow the normal access rules, i.e., wait for a <FRI> signal and then choose a random slot in which to transmit.

4. Section 3.10, page 17: This section deals with voice operation and may be disregarded.

0142421

.00

A 292 5153G

Cantel Mobitex -

St. No.		
Start Date	Rev.	FC F.d

5. Section 4, pages 25 and 28: Note that the <SVP5> and <SVP6> may contain up to 186 MANs each. A parameter will be added in the currently unused portion of the primary block of <SVP5> and <SVP6> to indicate the number of MANs in the mail list or traffic list, respectively.

6. Section 4, pages 28 and 29: parameters will be added in the currently unused portion of the primary block of <SVP6> to indicate signal strength evaluation times for the CURRENT-SYSTEM-CHANNEL (default 60 seconds) and other channels (default 3 RSSI-PERIODS). (See item 2. above).

7. Section 4, page 29: the entry for "TRANSACTION-TIME" should be changes to read:

States the time the terminal should stay in OPERATING state after (1) reception of a message from the network, and (2) transmission of a message to the network. (0-255) X 250 ms. Default value: 40 (10 seconds). TRANSACTION-TIME starts after transmitting or recieving an <ACK>, respectively.

8. Section 6, pages 35 and 36: the following three items listed as design recommendations have been changed to design requirements, and their functionality must be included in portable units:

Automatic change to mobile terminal operation (page 35)

User notification of 'lost contact' (page 36)

Display RSSI to user before transmitting (page 36)

The remaining three items - manual selection of operating mode, prevention from automatic quick channel monitoring, and manual initiation of channel monitoring - continue to be design recommendations.

ADDITIONAL INFORMATION

In the "INFO" MPAK (See MTS 09A.2, pages 107 and 108), portable terminals will be defined as terminal type number 4. The INFO MPAK will also now include a parameter indicating the operating mode of the portable unit (mode = mobile terminal mode; mode 1 = battery saving mode).

In the MASC Interface (see MTS 19A.2), new commands will be added to accommodate portable terminals. Details will be provided later.

Bidkort

Regros

A 192 51303

00000000	ADDENDUM PROTOCOL FOR HAND-HELD PORTABLE TERMINALS FOR USE IN MOBITEK
<p style="text-align: center;"><u>P R E L I M I N A R Y S P E C I F I C A T I O N .</u></p> <p><u>ABSTRACT</u></p> <p>This document specifies additional requirements for hand-held portable terminals to be connected to the MOBITEK system.</p> <p>An interface for hand-held portable terminals, where power conservation is one prime objective, is defined.</p> <p>This document should be considered as an ADDENDUM to the MOBITEK Terminal Specification (MTS) for 8 kbps mobile terminals, LZBA 703 1001, R1A.</p>	

BidSource

 spread

A 222 51533

1056 - A 296 6084 Ue		
Drawn Date	Rev	P. File
90-05-11	PA3	MTS15.1

TABLE OF CONTENTS

1	INTRODUCTION	3
2	GENERAL DESCRIPTION	3
3	OPERATING PRINCIPLES	5
3.1	START UP PROCEDURE	5
3.2	STATES	5
3.3	TRAFFIC LIST	6
3.4	MAIL LIST	6
3.5	SYNCHRONIZATION TO THE NETWORK	7
3.6	ROAMING	10
3.7	FLEET DIVISION OF HAND-HELD PORTABLES	13
3.8	MESSAGE TRANSACTIONS	13
3.8.1	UP LINK TRAFFIC	13
3.8.2	DOWN LINK TRAFFIC	14
3.9	ACTIVATION/INACTIVATION	16
3.10	LINE CONNECTION	17
4	ADDITIONAL FRAMES - DATA LINK LAYER	18
5	ADDITIONAL MPAK - NETWORK LAYER	32
6	DESIGN RECOMMENDATIONS	35
7	MOBITEX TERMINAL SPECIFICATION REFERENCE LIST	37

Booklet

Reprint

A 296 6084 Ue

1056 - A 296 6084 Ue	
DATE: 90-05-11	Rev: PA3 MTS15.1

1 INTRODUCTION

This document specifies additional requirements for hand-held portable terminals to be connected to the MOBITEK system.

It should be considered as an ADDENDUM to the complete MOBITEK Terminal Specification for 8 kbps mobile terminals, LZBA 703 1001, RLA.

If certain requirements are made for hand-held portables these are made in this document. It could either be new additional requirements or new requirements that replaces ones that are made in the specification for ordinary mobile terminals.

2 GENERAL DESCRIPTION

A hand-held portable terminal is basically a mobile terminal and should therefore conform to the requirements for mobile terminals, but with the additional ability to go into low power drain operating mode and wakeup when required to receive messages from the network.

When the hand-held has received its messages it goes asleep again.

One limitation for portables in this mode is that messages to these terminals may be delayed during the time when the portable is asleep.

Whenever a hand-held wants to send a message it immediately wakes up, waits for a free-signal and sends the message. The terminal then stays awake for a period of time in order to be able to receive a quick message response.

The roaming procedure is essentially the same as for ordinary mobiles, but is controlled from separate sweep-parameters for hand-held terminals. The hand-held terminals performs the base evaluation during its awake time.

Richard

Reprod

A 296 6084 Ue

No. 1056 - A 296 6084 Ue	
Date 90-05-11	Rev PA3 MTS15.1

This protocol for hand-held terminals defines four new subtypes of the sweep-signal, <SVP>. These subtypes are numbered from 3 to 6.

<SVP3> - Sweep frame of subtype 3

Includes roaming parameters and channel list used by hand-held terminals. <SVP3> corresponds to <SVP1> used by mobile terminals.

<SVP4> - Sweep frame of subtype 4

Contains channel numbers and channel types used in fleet division procedure. <SVP4> corresponds to <SVP2> used by mobile terminals.

<SVP5> - Sweep frame of subtype 5

Contains a list of terminal MAN that has messages stored in the network mailbox.

<SVP6> - Sweep frame of subtype 6

Contains a list of terminal MAN or Group MAN that will have traffic from the network during this sweep cycle.

This sweep frame also contains timing parameters for synchronization and message transfer.

Revised

Revised

A 727 51330

1056 - A 296 6084 Ue	
Date Recd 90-05-11	File # PA3 MTS15.1

3 OPERATING PRINCIPLES

3.1 START UP PROCEDURE

When the portable is powered up for the first time and/or when it has lost synchronization with the network or lost important information/parameters, it should consider itself to be in normal mobile terminal mode and act according to that.

When the hand-held has found a system channel on a base station to use, received the relevant parameters from the base and synchronized to it, the terminal should send MPAK ROAM or ACTIVE according to the roaming procedure.

The hand-held always has the possibility to go to normal mobile terminal mode, e.g. when the terminal is put in a power charger or for a major data transaction session when you want to be active all the time. In order to inform the network of this change of mode, the hand-held sends a new MPAK called MODE.

3.2 STATES

There are two different states that a hand-held terminal could enter when it is in the low power drain mode; STANDBY state or OPERATING state.

The STANDBY state should be considered as a 'sleeping' mode where only time keeping functions for synchronizing the terminal to the base station are in operation.

In the OPERATING state the terminal should be considered as fully operational.

Revised

Reprod

A 296 51333

		1056 - A 296 6084 Ue	
Docu. No.	Rev.	F. P. No.	
90-05-11	PA3	MTS15.1	

3.3 TRAFFIC LIST

The hand-held terminal is notified in a TRAFFIC LIST that traffic will sent to the terminal.

The TRAFFIC LIST contains the TERMINAL-MAN or the GROUP-MAN of those terminals that should remain in the OPERATING state in order to be available for the down-link traffic from network.

The TRAFFIC LIST is part of a new <SVP>-frame of SUBTYPE 6, denoted <SVP6>-frame.

Terminals not included in the TRAFFIC LIST may directly go back to STANDBY state in order to save battery.

3.4 MAIL LIST

Messages not acknowledged by the terminal may be stored in the network mailbox according to the conditions describes in RI-09, 8kbps MTS.

In order to inform terminals that have messages in the network mailbox, the MAIL LIST is introduced.

The MAIL LIST contains a list of those terminal MAN having messages in the mailbox. The MAIL LIST is within the <SVP>-frame of subtype 5, denoted <SVP5>.

Booked

Reserved

A 292 513302

1056 - A 296 6084 Ue		
90-05-11	PA3	MTS15.1

3.5 SYNCHRONIZATION TO THE NETWORK

Hand-held terminals using the this battery saving protocol cyclically goes from the STANDBY state to the OPERATING state.

The terminal must be synchronized to the <SVP6> (TRAFFIC LIST) sent from the network. The <SVP6> frame is sent periodically from the network on the system channels where hand-held terminals can operate and use the battery saving protocol.

The <SVP6> also contains the parameter TIME-TO-NEXT indicating the remaining period of time from this <SVP6> to the next time the terminal should enter the OPERATING state.

TIME-TO-NEXT = time from first bit (bit 1) in the framehead of the received <SVP6> to the next time the terminal should enter the OPERATING state.

The <SVP6> also contains the parameter CYCLE-TIME which is the nominal cycle time between the start of two operating states.

The length of the CYCLE-TIME parameter is a compromise between response-time requirements and power consumption requirements of the terminal.

Normally the terminal uses the TIME-TO-NEXT parameter in the <SVP6> to synchronize to the next time to enter the OPERATING state. If one or more of the <SVP6> frames are lost, the terminal should use the CYCLE-TIME parameter in order not to lose synchronization.

Once the terminal has entered the OPERATING state it remains in this state until it receives an <SVP6> frame with a TRAFFIC LIST where the terminal is not included. The <SVP6> is terminating the transmission of the sweep frames.

If the network is going to send other sweep frames when the terminals are in the OPERATING state, they will be sent prior the <SVP6> frame.


If none of the <SVP3> to <SVP6> has been received within 2 seconds from the transition to the OPERATING state, the terminal could return to STANDBY.

After the reception of every <SVP3> to <SVP5> the terminal stays in OPERATING state for another 2 seconds or till it receives an <SVP6>.

If the hand-held consider itself as having lost synchronization to the network, e.g. lost of a number of consecutive <SVP6>, it should stay in OPERATING state to synchronize again.

Example 1 :

Terminal uses TIME-TO-NEXT for synchronizing.




OPR = terminal in OPERATING state

STB = terminal in STANDBY state

Example 2:

Terminal is using the CYCLE-TIME when <SVP6> is lost to keep synchronization.




OPR = terminal in OPERATING state

STB = terminal in STANDBY state

Example 3:

Multiple sweep frame could be sent during the OPERATING state.




1056 - A 296 6084 Ue		
Serial Date	Lab	File No
90-05-11	PA3	MTS15.1

Example 4 :


Terminal does not receive any sweep frame within 2 seconds from the start of the OPERATING state and returns to STANDBY.

Base

Example 5:

The terminal receives a <SVP3> but the <SVP6> is not received so the OPERATING state is terminated by the 2 second timeout. The timeout is counted from the reception of the <SVP3> frame.

Base <SVP3>




1056 - A 296 6084 Ue
90-05-11 PA3 MTS15.1

Example 2 :

If SCAN TIME = 1 ... 255, the terminal monitors other channels according to the channel list information the mobile has derived in the <SVP3> or from the default list.

The start of the scan period is only critical in that sense that the terminal must not leave the system channel and monitor another channel when it should be in OPERATING state.

The terminal should not leave CURRENT_SYSTEM_CHANNEL and monitor other channels during the sweep cycle if it is addressed in the TRAFFIC LIST.



- m = monitor CURRENT_SYSTEM_CHANNEL
- s = scan other system channels
- r = RSSI PERIOD
- OPR = terminal in OPERATING state
- STB = terminal in STANDBY state

Please see the chapter ROAMING in R1-16 for further information.

Revised:
Revised:

No. 1056 - A 296 6084 Je		
Station Date 90-05-11	Rev PA3	P. 1.1 MTS15.1

Criteria for leaving base :

The same criteria for leaving the CURRENT BASE applies for a hand-held terminal as the mobile terminal but with the parameters in the <SVP3> frame. The fifth criteria (item -5-) is not valid for hand-held terminals.

Please see the chapter ROAMING in RI-16 for further information.

Evaluation of other base stations :

The evaluation of base stations on the CURRENT SYSTEM-CHANNEL, should be based on the averaged received signal strength from at least 60 seconds or some other suitable integration time.

When evaluating other channels than the CURRENT SYSTEM CHANNEL, roaming-values from at least three (3) RSSI_PERIODS should be averaged.

Quick channel monitoring :

In quick channel monitoring when the SCAN_TIME = 0 and when the terminal has found a channel with a roaming value > GOOD_BASE, the terminal should remain on the channel for at least 5 seconds during the measuring of received signal strength. Please refer to 'quick channel monitoring' part (item -4-) of the ROAMING chapter in RI-16.

At Power On

When the hand-held terminal is switched on it should use the stored CURRENT_SYSTEM_CHANNEL and the CURRENT_BASE.

If there is no CURRENT_BASE stored the terminal directly starts the quick channel monitoring procedure using the default list of system channels. When a CURRENT_SYSTEM_CHANNEL and a CURRENT_BASE has been found and the MPAAK ROAM has been sent to the network, the terminal synchronizes to the <SVP6>-frames.

Bildart

Regeed

A 5711.13.3

1056 - A 296 6084 Ue	
Form No. 90-05-11	PA3 MTS15.1

3.7 FLEET DIVISION OF HAND-HELD PORTABLES

In order to assign a certain system channel (and/or access channel) to hand-held terminals or parts of the fleet of the hand-held terminals a <SVP>-frame of SUBTYPE 4 is introduced, denoted <SVP4>-frame. The <SVP4>-frame should be interpreted in same way as the <SVP2>-frame for mobile terminals, described in 8kbps MTS section R1-16.

3.8 MESSAGE TRANSACTIONS

3.8.1 UP LINK TRAFFIC

The access requirements for up-link traffic from a hand-held terminal are basically the same as for a mobile terminal.

A hand-held terminal that is going to transmit a message to the network enters the OPERATING state directly and waits for a valid <PRI>-frame from the network according to the 8kbps MTS.

When the terminal makes an access request for data using the <ABD>-frame, the terminal should follow the 8kbps MTS dialogues and remain in OPERATING state till the <NRM>-frame is transferred successfully or when the dialogue terminates for any reason.

After the message is successfully transferred to the network the hand-held terminal remains in OPERATING state for TRANSACTION-TIME, defined in <SVP6>, before it goes back to STANDBY state. This gives a possibility for transferring an answer back to the hand-held without any delays caused by the waiting time to the next TRAFFIC LIST transmission. This function could be considered as if a 'logical down-link channel' has been opened to the terminal for TRANSACTION-TIME.

3043ar

Reprod

A 292 51553

Hand-held terminals having down-link traffic is addressed in the TRAFFIC LIST.

When the hand-held terminal receives a TRAFFIC LIST that contains one of its terminal addresses (TERMINAL MAN or GROUP MAN) it stays in OPERATING state and awaits one message.

When the message is successfully received the terminal stays in OPERATING state for TRANSACTION-TIME in order to be able to receive more down-link messages coming from the network. The parameter TRANSACTION-TIME is included in the <SVP6>-frame, and is the same as for up-link traffic.

If no message has been received within the TRANSACTION-TIME elapsed from the reception of the last message, the terminal can leave OPERATING state.

The terminal can also leave OPERATING state when it receives a TRAFFIC LIST without any of the terminal addressees.

When a hand-held terminal is ordered to another channel for down-link data transmission, <BKD> frame from network, the hand-held terminal should remain in the OPERATING state until the data transmission dialogue is completed according to the 8kbps MTS.

Terminals not included in the TRAFFIC LIST may directly go to STANDBY state in order to save battery.

Terminal is not in traffic list

Base : <SVP6> <SVP6>
 | |


Term : ┌───┐ STB ┌───┐ STB
 | |

OPR = terminal in OPERATING state
STB = terminal in STANDBY state

1056 - A 296 6084 Ue

Date Recd
90-05-11Trans
PA3File #
MTS15.1Example 2:

Terminal is in traffic list of <SVP6> and the network has one <MRM> to transmit.




TT = TRANSACTION-TIME

OPR = terminal in OPERATING state

STB = terminal in STANDBY state

Example 3:

Terminal is in traffic list of <SVP6> and the network transmits multiple <MRM> within the sweep cycle.



TT = TRANSACTION-TIME

OPR = terminal in OPERATING state

STB = terminal in STANDBY state

100kms

Legend

A 102 11510

1056 - A 296 6084 Ue	
90-05-11	PA3 MTS15.1

3.9 ACTIVATION/INACTIVATION

The hand-held terminal use of the ACTIVE/INACTIVE packet has been modified to better suit their environment and application.


Hand-held portables used in-doors will lose contact with the network much more frequently than mobile terminals. Hand-held terminals should therefore not send ACTIVE due to 'lost contact' according to the roaming procedure since this will cause considerable system signalling overhead.

Hand-held terminals should send INACTIVE / ACTIVE when switched-off and switched-on respectively.

When a hand-held terminal is addressed in the MAIL LIST it has the possibility to empty the mailbox by sending an ACTIVE packet.

Example 1:

Terminal is in mail list of <SVP5> and the network has one or more <MRM> placed in mailbox.



TT = TRANSACTION-TIME
 OPR = terminal in OPERATING state
 STB = terminal in STANDBY state
 MRM1 = MPAK ACTIVE
 MRM2 = any MPAK from mailbox

Sidebart

Ex-100

A 12/251330

1056 - A 296 6084 Ue		
Doc. No.	Rev.	File
90-05-11	FA3	MTS15.1

3.10 LINE CONNECTION

Call set-up and disconnection procedures for line connection to a hand-held terminal follows the requirements in the 8kbps MTS.

When a hand-held terminal is called from the network for a line connection, the terminal is addressed in the TRAFFIC LIST with the TERMINAL MAN or one of the GROUP MAN. The terminal remains in the OPERATING state and follows the normal procedure for call set-up described in the 8kbps MTS. The terminal can leave the OPERATING state when the call is disconnected, according to the dialogues in the 8kbps MTS.

When a hand-held terminal initiates a call set-up for a line connection, the terminal enters OPERATING state before sending the line connection request, and stays in this state until the call is disconnected, according to the 8kbps MTS.

3060000

3060000

		1056 - A 295 6084 Ue	
		90-05-11	MTS15.1

4 ADDITIONAL FRAMES - DATA LINK LAYER

FRAME TYPE <SVP>, Sweep signal

APPLICATION The sweep signal is a periodically recurring signal from BASE. An <SVP> is transmitted by BASE for two reasons:

- 1) <SVP> marks the start of a sweep cycle.
- 2) <SVP> contains system parameters.

<SVP> has 2 different subtypes for mobile terminals and 4 subtypes for hand-held portable terminals :

SUBTYPE

- 1 states the values of system parameters for mobile terminals
- 2 states the frequency of different channel types for mobile terminals
- 3 subtype only for hand-held terminals using the battery saving protocol described in this document. This subtype contains the system parameters for the hand-held terminals.
- 4 states the frequency of different channel types for hand-held terminals.
- 5 includes the MAIL LIST for terminals (may be used both by mobile terminals and hand-held terminals)
- 6 includes the TRAFFIC LIST and the timing parameters for hand-held terminals

Note 1: <SVP> of subtype 1 and 2 are not described in this Addendum. Please refer to 8kbps MTS R1-16.

Note 2: For <SVP5> and <SVP6>, the hand-held should use correctly received following blocks, even though the whole frame may not be correct.

Block:

Report:

A 295 61630

A 22 515/3

		1056 - A 296 6084 Ue	
		90-05-11	MTS15.1
SVPTYP	States the <SVP> subtype, value 00000011 in this case.		
TXPOW	States the decrease in output power (0-255 dB below nominal level) to be used by the hand-held terminal. The default value of 0 is used until this signal is received.		
RSSI_PROC	States the method of the signal strength measurement: 0 = FRAME 1 = CONTINUOUS The default value is FRAME.		
RSSI_PERIOD	Time used by the roaming algorithm (0-255 *20 ms). Default value: 148 (2 960 ms).		
MAX_REP	States the value of the variable Max_rep.		
BASEST	States status of base station.		
SCAN_TIME	States the length of a period (0-255 *100 ms) when the hand-held terminal scans other system channels. Default value: 30 (3 seconds).		
BAD_BASE	Used by the roaming algorithm. 0-255 dBuV. Default value: 15.		
GOOD_BASE	Used by the roaming algorithm. 0-255 dBuV. Default value: 15.		
BETTER_BASE	Used by the roaming algorithm. 0-255 dB. Default value: 10.		

B.22a

B.22b

A 296 51533

1056 - A 296 6084 Ue

Date Recd	1 Rec	2 Rec
90-05-11	PA3	MTS15.1

FOLLOWING BLOCKS

If any, they contain a list of system channels to be used in base station monitoring. A frame with a list containing new system channels completely overrides the previous frame. The channel list has the following format (as described in the MAIN DOCUMENT):

FOLLOWING BLOCK #1

01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16
number of channels								0	0	0	0	0	0	0	0

17								32	33						48
channel #1 - UPFREQ								channel #1 - DOFREQ							

49								64	65						80
channel #2 - UPFREQ								channel #2 - DOFREQ							

81								96	97						112
channel #3 - UPFREQ								channel #3 - DOFREQ							

113								128	129						144
channel #4 - UPFREQ								channel #4 - DOFREQ							

145															160
PARITY															

The number of following blocks depends on the size of the list. The maximum number of channels in the list is stated in reference R1-06.

Continues with following block #2 on the next page.

Bidders

Reprod

A 292 6153

1056 - A 296 6084	Ue
90-05-11	PA3 MTS15.1

FOLLOWING BLOCK #2

01	16 17	32
channel #5 - UPFREQ	channel #5 - DOFREQ	
33	48 49	64
channel #6 - UPFREQ	channel #6 - DOFREQ	
.	.	.
129	144 145	160
channel #9 - UPFREQ	PARITY	

FOLLOWING BLOCK #3

01	16 17	32
channel #9 - DOFREQ	channel #10 - UPFREQ	
33	48 49	64
channel #10 - DOFREQ	channel #11 - UPFREQ	

etc.

Bulker:

Reprod

A 292 5133-1

A 292 54507

CHTYP States the type of channel:

```

1      Local system channel opened
2      Not used (ignore that order)
3      Local system channel closed
      (return to previous system
      channel)
4      Access channel opened
5      Access channel closed

```

DOFREQ Frequency number for down frequency, i.e.
the frequency on which BASE transmits.

641,827

5-11105

- contains a list of terminal MAN that has messages stored in the network mailbox

[illegible]

States the <SVP> subtype, value 00000101 in this case.

No. 1056 - A 296 6084 Ue		
Serial Date 90-05-11	Rate PA3	File No. MTS15.1

FOLLOWING BLOCKS

Containing a list of terminal
MAN that has been stored in the
network mailbox.

FOLLOWING BLOCK #1

01	-----	24
MAN 1		
25	-----	48
MAN 2		
49	-----	72
MAN 3		
73	-----	96
MAN 4		
97	-----	120
MAN 5		
121	-----	144
MAN 6		
145	-----	160
PARITY		

The number of following blocks depends on the size of the
list.

Continues with following block #2 on the next page.

Bulldoz

Rayrod

A 202 61330

1056 - A 296 6084 Ue

90-05-11 PA3 MTS15.1

FOLLOWING BLOCK #2

01	-----	24
MAN 7		

25	-----	48
MAN 8		

49	-----	72
MAN 9		

73	-----	96
MAN 10		

97	-----	120
MAN 11		

121	-----	144
MAN 12		

145	-----	160
PARITY		

etc.

Block

Repeat

A 296 6084 Ue

- contains the timing parameters used in synchronization and message transactions

[illegible]

Reprinted

SVPTYP States the <SVP> subtype, value 00000110 in this case.	
CYCLE-TIME States the cycle time between two OPERATING states (0-255 x 250 ms).	
TIME-TO-NEXT States the time to the next <SVP6> frame (0-255 x 250 ms).	
TRANSACTION-TIME States the time the terminal should stay in OPERATING state after 1) reception of a message from the network and 2) transmission of a message to the network (0-255 x 250 ms). Default value: 80 (20 seconds).	

A 292 A, No 1

Containing a list of terminal
MAN or group MAN that are going
have down-link traffic during
this sweep cycle.

The diagram illustrates a 160-bit data stream structure. It is divided into six segments, each 24 bits long, followed by a final 16-bit parity segment. The segments are labeled MAN 1 through MAN 6, and the final segment is labeled PARITY. The bit positions are marked at the start and end of each segment: 01, 24, 25, 48, 49, 72, 73, 96, 97, 120, 121, 144, 145, and 160.

Segment	Start Bit	End Bit	Label
1	01	24	MAN 1
2	25	48	MAN 2
3	49	72	MAN 3
4	73	96	MAN 4
5	97	120	MAN 5
6	121	144	MAN 6
7	145	160	PARITY

Continues with following block #2 on the next page.

សំណួរ

1056 - A 296 6084 Ue		
Date: 90-05-11	Page: PA3	File: MTS15.1

FOLLOWING BLOCK #2

01		24
MAN 7		

25		48
MAN 8		

49		72
MAN 9		

73		96
MAN 10		

97		120
MAN 11		

121		144
MAN 12		

145		160
PARITY		

etc.

Block:

Signal:

A 296 6084

No. 1056 - A 296 6084 Ue	
Date: 90-05-11	Rev: PA3
F. 1.5 MTS15.1	

5 ADDITIONAL MPAK - NETWORK LAYER

A new MPAK is included for terminals using the battery saving protocol. The MPAK is used to inform the network that the terminal has changed from battery saving mode to operate as a normal mobile terminal and vice versa.

The new MPAK is within the packet class DTESERV (3) and has the packet type = 24.

MODE (mode information):

Designated sender:

The hand-held portable terminal.

Designated addressee:

The network.

Raised flags:

No raised flags.

Criteria for generating the packet:

When hand-held portable terminal changes from the battery saving protocol to operate as a mobile terminal this packet is used to inform the network.

The same packet is sent to the network, but with a different mode identifier, when the terminal enters the battery saving protocol from being operating as a mobile terminal.

Dr. G. G. G.

Report

No. 1056 - A 296 6084 Ge	
Date Recd. 90-05-11	File# PA3 MTS15.1

The network's normal action when receiving the packet:

The network registers how the terminal operates, and forwards down-link traffic to the terminal in accordance to this. If terminal is using the battery saving protocol, the terminal is addressed in the TRAFFIC LIST.

If the terminal is operating as a mobile terminal the network sends traffic immediately to the terminal.

The terminal's normal action when receiving the packet:

The terminal does not normally receives this packet.

Length of the packet:
9 octets.

SECRET

SECRET

A 292 61 10.3

N. No.		1056 - A 296 6084 Ue	
Issue Date	Rev	F. No.	
90-05-11	PA3	MTS15.1	

MODE as generated by the terminal:

MPAK-COMMON COMPONENT:

octet 1-3:

sender: the terminal

octet 4-6:

addressee : the Mobitex Network

octet 7:

0 0 0 0 0 0 0 0

octet 8:

1 1 0 1 1 0 0 0

TYPE DEPENDENT COMPONENT:

octet 9 :

mode identifier

mode identifier :

0 = mobile terminal operation

1 = battery saving protocol operation

2-255 = reserved

B002art

Eapred

A 292 5153/3

No. 1056 - A 296 6084		Ue
Date 90-05-11	Rev PA3	P. 1.1 MTS15.1

6 DESIGN RECOMMENDATIONS

Manual selection of Battery saving operating mode - Mobile terminal operating mode

When the hand-held terminal is mounted into a battery charger in a car for example, it is recommended that terminal leaves the battery saving protocol operation and operates as mobile terminal. In that case the user or the terminal itself initiates the transmission of the MPAK MODE to the network. The MPAK MODE will then identify the operating mode the terminal uses.

Automatic change to mobile terminal operation.

If the terminal could not find any signalling required for the battery saving protocol operation (<SVP6>), but detects <SVPL> required for mobile terminal operation, the terminal could act as mobile terminal. The user should be informed of this so the terminal could be switched-off.

The MPAK MODE is sent to the network informing that the terminal has gone into mobile terminal operation.

Prevention from automatic quick channel monitoring

In order to prevent the automatic quick channel monitoring from continuously running or to prevent the terminal from repeated attempts to go into the quick channel monitoring, it is recommended that the user manually can switch the quick channel monitoring function off.

It is also recommended that the terminal has some kind of watchdog function implemented, limiting the operating time in quick channel monitoring mode.

Manual initiation of quick channel monitoring

If the hand-held terminal is implemented without automatic quick channel monitoring functions it is recommended that this function can be manually initiated.

10/11/90

Repro

A 292 31520

1056 - A 296 6084 De	
Date: 90-05-11	Rev: PA3
File: MTS15.1	

User notification of 'lost contact'

When the terminal loses contact with network, according to roaming procedure, and goes into quick scan monitoring the operator of terminal should be notified. It is also suitable if the received signal strength indication (RSSI) is displayed to the user so positioning of the terminal could be facilitated.

RSSI when transmitting

It is recommended to display the received signal strength to the user especially when the terminal is going to transmit, so the user can move the terminal to a good location.

Blanket:

Reprod

A299 51528

Doc No
1056 - A 296 6084 Ue

Docum Date Rev J. E -
90-05-11 PA3 MTS15.1

7 MOBITEK TERMINAL SPECIFICATION REFERENCE LIST

This document includes a number of references, made to other sections in the terminal specification. The list below shows these references, together with the page(s) they are made on. Please note that a section could be referred to several times on the same page.

RI-06, 21
RI-09, 6
RI-16, 10, 11, 12, 13, 18

Below are the reference designations listed.

<u>Reference</u>	<u>Section</u>
RI-01	Arrangement of the documents
RI-02	MOBITEK System description
RI-03	General description of terminals
RI-04	Terminology
RI-05	References
RI-06	Network operator information
RI-08	Application layer
RI-09	Network layer
RI-11	Interface requirements, fixed terminals
RI-12	Other requirements, fixed terminals
RI-16	Link layer, mobile terminals
RI-17	Physical layer, mobile terminals
RI-18	Radio equipment, mobile terminals
RI-19	Other interfaces, mobile terminals
RI-20	Other requirements, mobile terminals

Revert

Legend

A 292 5133-0

Updated - Prepared ET/SYS IK	Facsimile - Subject responsible ET/SYS IK	Sr. No. 9/1056 - A 296 5171/02 Ue	
Disaster/Continuity - Doc responsible ET/SYSC - STT S/T		Doc. Date 1990-02-26	Rev. A
Renaming		N. No. MTS16.2	
<h1 style="text-align: center;">Cantel Mobitex</h1>		Title	
		MOBITEK Data Link Layer, Mobile Terminal 8/16 kbps	
<p>ABSTRACT</p> <p>This document specifies the data link layer for terminals connected to the MOBITEK network.</p> <p>The mobile terminal's Data Link Layer together with the Physical Layer form a radio protocol for communication between mobile stations (MOB) and a base radio station (BASE).</p> <p>The interchange of information between BASE and MOB is in the form of frames. There are 21 different types of frames.</p> <p>A number of different access strategies are used in the protocol to permit the handling of a large number of mobile terminals on a few trunked channels. The most important aspects are:</p> <ul style="list-style-type: none"> - Time slots - Selective repetition - Priority access - Concurrent channels - Automatic roaming <p>To achieve high transmission reliability, the frames are divided into blocks where each block is coded.</p>			
<div style="display: flex; justify-content: space-between;"> <div> <p>Signature</p> <p>_____</p> <p>Approved</p> <p>_____</p> </div> <div> <p>A 292 5153/3</p> </div> </div>			

Cantel Mobitex

Doc No
9/1056 - A 296 5171/02 Ue

Doc Date Rev Fc F.e
1990-02-26 A MTS16.2

TABLE OF CONTENTS

1	INTRODUCTION	3
1.1	GENERAL	3
2	INTERACTION WITH UPPER LAYERS	4
3	FRAME STRUCTURE	5
3.1	PARTS OF THE FRAME	5
3.2	FRAME TYPES	6
4	TRAFFIC HANDLING	13
4.1	TRANSMISSION PRINCIPLES	13
4.2	ACCESS TO THE CHANNEL	14
4.2.1	Time division	14
4.2.2	Mobile fleet division	16
4.3	ROAMING	17
4.4	ADDRESSING	24
4.4.1	Addressing the base radio station	24
4.4.2	Addressing a mobile terminal	24
4.5	SEQUENTIAL NUMBERING	29
4.6	OUTPUT POWER CONTROL	31
4.7	LOGICAL DESCRIPTION	32
4.7.1	Input and decoding (DCOD)	33
4.7.2	Processing incoming frames (IFRA)	34
4.7.3	Processing outgoing frames (OPRA)	35
4.7.4	Coding and readout (CODE)	39
4.7.5	Base contact monitoring (BMON)	40
4.7.6	Packet handling (PAHA)	41
4.8	TRANSFER EXAMPLES	49
4.8.1	Transfer without response	49
4.8.2	Transfer with simple acknowledgement	50
4.8.3	Transfer with block repetition	51
4.8.4	Transfer with frame repetition	52
4.8.5	Transfer with access request	54
4.8.6	Transfer with line connection	55
4.8.7	Transfer on several channels	56
4.8.8	Line connection with hand over	57
4.8.9	Line connection with queue handling	58
4.8.10	Line connection without access request	60
4.8.11	Ending a line connection	60
4.8.12	Line connection ended by speech_off	61
5	SYSTEM PARAMETERS TO BE STORED IN THE TERMINAL	62
6	MOBITEX TERMINAL SPECIFICATION REFERENCE LIST	63

Bidkast

Reprod

A 296 51533

Cantel Mobitex

9/1056 - A 296 5171/02 Ue		
Docum. Date	Rev	File No
1990-02-26	A	MTS16.2

1 INTRODUCTION

1.1 GENERAL

The Link Layer of mobile terminals forms a link between the Network Layer and the physical radio channel with its special properties. It ensures a safe and efficient transmission path between the mobile terminal and the network, represented by the base stations. The Link Layer includes error correction facilities, access algorithms, roaming algorithms, priority facilities etc.

Billions

Reproes

A 002 51530

Cantel Mobitex

No. 9/1056 - A 296 5171/02 Ue

Issue Date 1990-02-26 1 Rev A P. 2.2 MTS16.2

2 INTERACTION WITH UPPER LAYERS

The upper layers handle packets of information, MPAK. The following figure presents the general appearance of an MPAK (it is fully described in reference R1-09).

Sender
Addressee
Type, status etc.
Type-dependent component

The Link Layer transmits the MPAK in the form of a frame. The frame structure is defined in chapter FRAME STRUCTURE. The conversion of a packet into a frame is described in APPENDIX A.

If the Link Layer is unsuccessful in transferring an MPAK to the network, it is returned to the Network Layer with this information. The Network Layer can then request a new attempt by sending the MPAK back to the Link Layer.

Disksort

Reproe

A 292 21533


Cantel Mobitex

9/1056 - A 296 5171/02 Ue
 1990-02-26 A MTS16.2

3 FRAME STRUCTURE

3.1 PARTS OF THE FRAME

The transmission of digital information over the radio channel is performed by transmitting frames. A frame comprises a limited number of bits which are transmitted in an uninterrupted sequence. The frame consists of the following parts:



The frame head is described in detail in reference R1-17. The information and parity fields of the following blocks are described in APPENDIX A, together with the primary block.

Repro

Repro

A 002 51533

Cantel Mobitex

9/1056 - A 296 5171/02 Ue
 1990-02-26 A MTS16.2

3.2 FRAME TYPES

There are 21 different frame types:

	<u>Name</u>	<u>Designation</u>	<u>Transmitted by</u>	
			<u>BASE</u>	<u>MOB</u>
1	M frame	<MRM>	Yes	Yes
2	Acknowledgement	<ACK>	Yes	Yes
3	Negative acknowledgement	<NAK>	Yes	Yes
4	Repetition request	<REB>	Yes	Yes
5	Repetition reply	<RES>	Yes	Yes
6	Access request, data	<ABD>	No	Yes
7	Access request, speech	<ABT>	No	Yes
8	Access request, emergency	<ABL>	No	Yes
9	Access permission, data	<ATD>	Yes	No
10	Access permission, speech	<ATT>	Yes	No
11	Access permission, emergency	<ATL>	Yes	No
12	Change channel, data	<BKD>	Yes	No
13	Change channel, speech	<BKT>	Yes	No
14	Free signal	<PRI>	Yes	No
15	Sweep signal	<SVP>	Yes	No
16	Silence order	<TST>	Yes	No
17	Activity request	<AKT>	Yes	No
18	No access permission, speech	<NAT>	Yes	No
19	Change base station, speech	<BET>	Yes	No
20	Wait for channel, speech	<VKT>	Yes	No
21	Cancel access request, speech	<AAT>	No	Yes

Bottom

Reprod

A 292 51503

Cantel Mobitex

No. 9/1056 - A 296 5171/02 Ue

Form Date 1 Rev
1990-02-26 AFile No
MTS16.2

The following pages give a brief description of each frame type. Refer to Appendix A "Frames" for a complete definition of frame types.

1 M-frame <MRM>

An <MRM> is used to transfer packets (MPAKs). The packet formats are defined in reference R1-09.

2 Acknowledgement <ACK>

An <ACK> acknowledges a correctly received frame.

<ACK> indicates that all blocks in the frame have been correctly received. It includes the sequential number of the received frame.

3 Negative acknowledgement <NAK>

A <NAK> requests repetition of the entire <MRM>.

<NAK> indicates that the primary block has been correctly received, but that the following blocks have been lost. It contains the sequential number of the received primary block. <NAK> results in a complete repetition of the lost <MRM>.

Note that if the number of blocks in <MRM> was 3 or more, <REB> is used instead of <NAK>.

4 Repetition request <REB>

A <REB> requests repetition of erroneous blocks in an <MRM> or <RES>.

If it is found during reception that certain blocks in a frame are not correct, a request for these blocks to be repeated can be made by transmitting a <REB>. The request contains a bit map of the blocks to be repeated. This bit map refers to the original <MRM>, even during a sequence of repetitions.

<REB> contains the sequential number of the received <MRM> and results in a <RES>.

Note that if the number of blocks in <MRM> was 2 or less, <NAK> is used instead of <REB>.

Bildschirm

Excerpt

Cantel Mobitex

9/1056 - A 296 5171/02 Ue		
Serial Date	Rev	F. P.
1990-02-26	A	MTS16.2

5 Repetition reply <RES>

A <RES> is the reply to a <REB>.

<RES> is a selective repetition of blocks from an <MRM>. The following blocks of the <RES> contain copies of blocks according to the bit map of the <REB>. <RES> contains the sequential number of the original <MRM>.

6 Access request, data <ABD>

An <ABD> is a request to transmit an <MRM>, containing "data" (defined in chapter "Addressing a mobile terminal"), whose length (number of blocks) exceeds the value of MAX_ACCESS. MAX_ACCESS is described in chapter "Time division".

If the length of the <MRM> exceeds MAX_ACCESS, access must be requested before the <MRM> may be sent.

The <ABD> states the number of blocks in the corresponding <MRM>.

7 Access request, speech <ABT>

An <ABT> is a request to transmit an <MRM>, containing "speech" (defined in chapter "Addressing a mobile terminal"), containing a request for a line connection whose length (number of blocks) exceeds the value of MAX_SPEECH. MAX_SPEECH is described in chapter "Time division".

If the length of an <MRM> with a connection request exceeds MAX_SPEECH, access must be requested before the <MRM> may be sent.

The <ABT> states the number of blocks in the corresponding <MRM>.

Beleken:

Reproes

Cantel Mobitex

Doc. No. 9/1056 - A 296 5171/02 Ue
Doc. Date 1990-02-26 Issue A File No. MTS16.2

8 Access request, emergency <ABL>

An <ABL> is a request to transmit an <MRM> containing an "emergency" (defined in chapter "Addressing a mobile terminal"), whose length exceeds the value of MAX ACCESS. MAX ACCESS is described in chapter "Time division".

If the length of the <MRM> exceeds MAX ACCESS, access must be requested before the <MRM> may be sent.

The <ABL> states the number of blocks in the corresponding <MRM>.

9 Access permission, data <ATD>

BASE replies with an <ATD> to an <ABD> from a MOB, when BASE is ready to accept an <MRM>.

When permission is granted (<ATD> received), MOB is expected to transmit an <MRM> containing a data packet.

10 Access permission, speech <ATT>

BASE replies with an <ATT> to an <ABT> from a MOB, when BASE is ready to accept an <MRM>.

When permission is granted (<ATT> received), MOB is expected to transmit an <MRM> containing a request for line connection.

11 Access permission, emergency <ATL>

BASE replies with an <ATL> to an <ABL> from a MOB, when BASE is ready to accept an <MRM>.

When permission is granted (<ATL> received), MOB is expected to transmit an <MRM> containing an emergency signal.

Block:

Page:

Cantel Mobitex

No. 9/1056 - A 296 5171/02 Ue
 Date 1990-02-26 Rev A P. 16
 MTS16.2

12 Change channel, data <BKD>

A <BKD> orders a MOB to another channel in order to transmit or receive an <MRM>, data or emergency.

Normally the terminal returns to the original channel when the <MRM> has been transmitted or received. If an error occurs on the assigned channel then MOB returns to the original channel after a timeout period stated in the <BKD>.

13 Change channel, speech <BKT>

A <BKT> orders a MOB to another channel in order to transmit or receive an <MRM> containing a request for line connection.

Normally the terminal returns to the original channel when the line connection is over. If an error occurs on the assigned channel then MOB returns to the original channel after a timeout period stated in the <BKT>.

14 Free signal <FRI>

BASE transmits a <FRI> when it is ready to handle traffic from MOB.

A free signal precedes a free cycle. A free cycle is a period of time when all of, or parts of, the total fleet of mobile terminals are collectively permitted to transmit.

15 Sweep signal <SVP>

The sweep signal is a periodically recurring signal from BASE. An <SVP> is transmitted by BASE for two reasons:

- 1 <SVP> marks the start of a sweep cycle.
- 2 <SVP> contains system parameters, such as:
 - time to next <SVP>
 - maximum number of repetitions
 - channel list
 - local system channel
 - access channel

Bidizart

Reprod

A 296 51533

Cantel Mobitex™

9/1056 - A 296 5171/02 Ue
 DATE Date Day File
 1990-02-26 A MTS16.2

16 Silence order <TST>

Silence order is used by BASE to withdraw all access permissions during a free cycle. A MOB that is already transmitting may continue to do so, but for every other MOB the access permissions for all traffic types (emergency, speech and data) are withdrawn.

Note: Please also refer to the description of the silence signal in reference RL-17. This signal has the same meaning as the <TST>-frame but uses only the frame head and thus addresses ALL mobile terminals.

17 Activity request <AKT>

An <AKT> is used by BASE to check whether a certain MOB is active. MOB replies with an <ACK> to such a frame.

18 No access permission, speech <NAT>

BASE replies with <NAT> to an <ABT> from a MOB when, for some reason, a line connection cannot be set up (e.g. no channel is available).

19 Change base station, speech <BBT>

BASE will use <BBT>

- as a response to an <ABT> when another base station is to be used for the line connection
- or
- to hand over a call in progress to another base station.

Buchan

Regard

A 296 51534

Cantel Mobitex -

Dr No	9/1056 - A 296 5171/02 Ue	
Change Date	1990-02-26	File
	A	File
		MTS16.2

20 Wait for channel, speech

<VKT>

If no channel is immediately available, BASE may place MOB in a queue of waiting calls and reply with a <VKT> to a received <ABT>. When a speech channel becomes available, BASE indicates this by transmitting a <BKT> to MOB. If there is no free channel within reasonable time, BASE ends the session by transmitting a <NAT>.

21 Cancel access request, speech

<AAT>

After having received a <VKT> from BASE, the mobile terminal may end the session by transmitting an <AAT>.

Bildschirm

Reprint

A 296 51533

Cantel Mobitex -

No. 9/1056 - A 296 5171/02 Ue
Date 1990-02-26 Rev A
Page 1 of 2 WTS16.2

4 TRAFFIC HANDLING

4.1 TRANSMISSION PRINCIPLES

Transmission is carried out through the interchange of frames between MOB and BASE. Different types of transmission cases demand different behaviours by the units involved. Some of the problems considered in this chapter are:

- Access to the channel - describes how a small number of channels can handle concurrent traffic from a large number of subscriptions at the same time.
- Keeping contact with the network - describes how the mobile unit maintains its contact with the network (roaming).
- Addressing - describes how the addressing of base radio stations, terminals and subscriptions take place.
- Sequential numbering - describes how repeated presentations of repeated frames are avoided.

Revisors

Revises

Cantel Mobitex

Doc. No.
9/1056 - A 296 5171/02 Ue
Doc. Date
1990-02-26 A
Doc. No.
MTS16.2

4.2 ACCESS TO THE CHANNEL

4.2.1 Time division

A MOB, with traffic to send, is allowed to establish contact with the base radio station in special free cycles. These cycles are initiated by BASE by transmitting a <PRI>.

This frame contains an indication of the length of the free cycle, including the following parameters:

Slot_length States the length of each individual free slot.

Free_slots States the total number of free slots in the current free cycle.

Rand_slots States the interval for the random number generator in the MOB.

Max_access States the maximum length of an <MRM>-frame, containing data or emergency, which can be sent without a preceding access request.

Max_speech States the maximum length of a frame, containing a connection request, which can be sent without a preceding access request.

In order to reduce the probability of a collision between traffic from several mobile units, the free cycle is subdivided into slots. The length of these slots (T_1) are stated by the Slot_length parameter.

slot n	slot n+1	slot n+2	slot n+3
--------	----------	----------	----------

-----|-----|-----|-----|-----> t
t t+ T_1 t+2* T_1 t+3* T_1 t+4* T_1

By the aid of an internal clock, the mobile terminal is able to detect slot boundaries. The definition of how slot boundaries are calculated is found in reference R1-17.

Bidder

Reprod

Cantel Mobitex

No. 9/1056 - A 296 5171/02 Ue
 Date 1990-02-26 Rev A File MTS16.2

The following happens in the free slots.

- 1 Traffic initiated before the start of the free cycle must be distributed at random. A random number generator selects a slot between 1 and Rand slots. Transmission begins at the start of the selected slot.
- 2 Traffic initiated during the free cycle is sent at the beginning of the next slot.
- 3 If the <MRM> to be sent is longer than MAX ACCESS or MAX SPEECH, a request for access must be made. The transmission of this request is done according to rules 1 or 2 above.

If the Data Link Layer is in the speech mode (ordered by the Network Layer), an <MRM> may be sent immediately. This is done independently of any free cycles.

Blockout

Repeat

A 296 5153

Cantel Mobitex

Doc No
9/1056 - A 296 5171/02 Ue
Doc No
1990-02-26 A
Rev
F. F. A
MTS16.2

4.2.2 Mobile fleet division

The access permission in the free cycle can be given to parts (subsets) of the mobile fleet according to the setting of corresponding fields in the free signal, <FRI>. This is used to reduce the number of access attempts in a free cycle. The following principles are used:

- Masked addressing The address and mask fields in <FRI> are used for a binary division (1, 2, 4, 8 etc) of the mobile fleet.
- Priority Is used to give access only to mobile terminals above a stated priority level.
- Traffic type, PFG Is used to give access only for stated traffic types (emergency, data or speech).

In the <SVP> a channel (receiving and transmitting frequencies) and a channel type (local system or access channel) can be given. By using the addressing facilities in the <SVP> it is possible to assign a certain system and/or access channel to the whole mobile fleet or to parts of it.

The local system channel is used in much the same way as any other system channel. It is not shared by surrounding base stations and may thus be used without interference from these.

When assigned a local system channel, the mobile terminal monitors this channel until further notice or the roaming algorithm indicates that it is no longer usable.

When assigned an access channel, the mobile terminal must use this channel when it has an <MRM> to transmit. The access rules described above also apply to this channel. After the <MRM> has been acknowledged the terminal returns to the previous (local) system channel.

Bolt

Repro

Cantel Mobitex

9/1056 - A 296 5171/02 Ue
System Date Rev Rev
1990-02-26 A MTS16.2

4.3 ROAMING

The algorithm for selection of a suitable base is called roaming. It is designed to handle a nationwide system of base radio stations on different system channels, with either frequency or time division in their signalling. The algorithm includes two methods of channel monitoring: normal and quick.

A mobile terminal measures the received signal strength from all base radio stations. To evaluate one base station the mobile terminal calculates its roaming value. The roaming value is defined as the average received signal strength. Please see reference R1-17 for further information about how to measure received signal strength.

After a <BKT> or a <BKD> has been received, the monitoring is disabled. It is resumed after the connection/session is ended, and the same table of evaluations as before the connection is used.

When the terminal is switched on, it uses the CURRENT_SYSTEM_CHANNEL and the CURRENT_BASE until this base becomes unsuitable according to the roaming algorithm. If no CURRENT_BASE has been stored, the terminal immediately starts the quick channel monitoring, using the default list of system channels.

Lists of system channels

The mobile terminal uses a list of system channels when it monitors the base radio stations or searches for a new base. It is either a permanent or a temporary default list (please refer to the chapter 'SYSTEM PARAMETERS TO BE STORED IN THE TERMINAL' and to reference R1-06) or the current list (stated in the <SVP>-frame).

The default list is used until a <SVP>-frame has been received. A <SVP>-frame with a new list of system channels completely overrides the old current list.

The default list is also used in the quick channel monitoring after an unsuccessful search of the current list has been made. Again, the default list is used only until a valid <SVP>-frame with the current list of system channels has been received from the new base station.

Buskort

Diagram

A 292 5152

Cantel Mobitex

Doc No	9/1056 - A 296 5171/02 Ue	
Issue Date	Rev	Rev. No
1990-02-26	A	MTS16.2

Measurement methods

When the mobile terminal measures the received signal strength it can use two different measurement procedures: FRAME or CONTINUOUS. Which of these it should use is stated by the parameter RSSI_PROC in the <SVP>-frame.

If RSSI_PROC states FRAME the mobile terminal measures the received signal strength of the frame heads received during the RSSI_PERIOD (stated in <SVP>).

If RSSI_PROC states CONTINUOUS the mobile terminal measures the received signal strength during the entire RSSI_PERIOD.

The parameter RSSI_PERIOD includes channel switching time, and has the default value 2 960 ms, with a tolerance of +/- 10 ms.

During monitoring of current system channel and when making the final decision before choosing a new base, the terminal measures average received signal strength during the reception of frame heads.

Block

Repro

A 292 51559

Cantel Mobitex

No. 9/1056 - A 296 5171/02 Use
 Date: 1990-02-26 A P. 16.2
 MTS16.2

Normal channel monitoring

A mobile terminal measures the received signal strength from base radio stations on the CURRENT_SYSTEM_CHANNEL and calculates a roaming value for each base station.


During each <SVP>-cycle (i.e. the time between two <SVP>-frames) the terminal leaves the CURRENT_SYSTEM_CHANNEL for a predefined period to monitor other channels and then return. These channels are chosen from the list of system channels (default or current). The start of the scan period depends on the terminal's own subscription number (MAN) being odd or even:

scan start(odd) = TIME_TO_NEXT - 10ms - 2*SCAN_TIME
 scan start(even) = TIME_TO_NEXT - 10ms - SCAN_TIME

where

SCAN_TIME = Length of predefined scan period, including channel switching time. This is stated in the <SVP>-frame and has the default value 3 seconds, with a tolerance of +/- 10 ms..
 TIME_TO_NEXT = Interval between two <SVP>-frames. This parameter is stated in the <SVP>-frame and has the default value 10 seconds.

Example:



where
 m = monitor current system channel
 s = scan other system channels
 r = RSSI PERIOD
 e = evaluation

The monitoring is cyclically repeated for all channels and every channel is monitored one RSSI_PERIOD.

For example, if the RSSI_PERIOD and SCAN_TIME have default values, the list contains 7 channels and the length of a <SVP>-cycle is 10 seconds, then the time between the scans of a specific channel from the list is 70 seconds. On the other hand, if the RSSI_PERIOD is 4 (80 ms) and SCAN_TIME is 30 (3 s) then the mobile will scan at least 30 channels during each <SVP>-cycle.

Block:

Repeat:

A 292 51350

Cantel Mobitex -

No. Xa	9/1056 - A 296 5171/02 Ue
Issue Date	1990-02-26
Rev	A
File No.	MTS16.2


Criteria for leaving CURRENT_BASE

The mobile terminal leaves CURRENT_BASE during a <SVP>-cycle if:

- 1- roaming value (CURRENT_BASE) < BAD_BASE
BAD_BASE is stated in the <SVP>-frame and its default value is 15.
- or
- 2- roaming value (best base) > roaming value (CURRENT_BASE) + BETTER_BASE.

If this criterion is fulfilled, the mobile should remain in normal channel monitoring on the current system channel for another <SVP>-cycle. During the next scan period the mobile should measure the average received signal strength of frame heads from best base. If the roaming value still fulfils the criterion, the mobile should select this base as new CURRENT_BASE and the new channel as CURRENT_SYSTEM_CHANNEL.

The following figure shows an example where this criterion applies:



The parameter BETTER_BASE is stated in the <SVP>-frame and its default value is 10.

Signature

Page no

A 297 51503

Cantel Mobitex

No. 9/1056 - A 296 5171/02 Ue
 Decree Date 1990-02-26 Rev A File No. MTS16.2

The following criteria cause the mobile to leave CURRENT_BASE immediately without waiting for the end of the <SVP>-cycle:

- 3- The terminal has made MAX_REP retransmissions without getting an acknowledgement from base. The value of MAX_REP is stated in the <SVP>-frame.
- 4- The terminal has received a <NAT> (including an order to leave the CURRENT_BASE) from base.

And the last criterion applies when no traffic is exchanged:

- 5- The terminal has not received valid <SVP>-frames within 2 <SVP>-cycles (= 2*TIME_TO_NEXT).

Any of the above criteria, except -2-, causes the mobile terminal to leave CURRENT_BASE and evaluate other bases.

Evaluation of other base stations

MOB first evaluates the best base (≠ CURRENT_BASE) from the normal channel monitoring. This is done by evaluating the:

- roaming value from the last <SVP>-cycle (on CURRENT_SYSTEM_CHANNEL)
- roaming value from the last RSSI_PERIOD of a specific channel (on the other system channels)

If the base is on the CURRENT_SYSTEM_CHANNEL and have a roaming value greater than GOOD_BASE it can be directly selected as CURRENT_BASE.

But if the new base is on a new system channel the mobile shall measure the average received signal strength during the reception of frame heads on this channel for SCAN_TIME. If the measured roaming value is greater than GOOD_BASE, the mobile should select this channel as CURRENT_SYSTEM_CHANNEL and this base as CURRENT_BASE.

Stikars:

Reprod

A 297 5155/2

Cantel Mobitex

Doc No	9/1056 - A 296 5171/02 Ue	
Docum Date	1 Rev	Pl. File
1990-02-26	A	MTSL6.2

Quick channel monitoring

If best base is not good enough, a quicker scanning procedure is adopted until a suitable base is found. MOB then scans its list of (current) system channels in the following way:

- 1- Begin with the first channel from the list.
- 2- Measure the average received signal strength for RSSI_PERIOD.
- 3- If the measured roaming value is greater than GOOD_BASE remain on this channel. Otherwise skip to step 6.
- 4- Measure the average received signal strength during the reception of frame heads on this channel for SCAN_TIME.
- 5- If the roaming value is greater than GOOD BASE select this channel as CURRENT_SYSTEM_CHANNEL, the base as CURRENT_BASE and return to normal channel monitoring. Otherwise go to step 6.
- 6- Stop scanning if all channels of the list have been scanned. Otherwise choose next channel from list and repeat steps 2-5.

After MOB has scanned a number of channels from the list (please see reference R1-06) , or the list is ended, the current system channel is scanned in the same manner. The scan of the list is then resumed, if the end of the list was not already reached.

If the complete current list of system channels has been searched without a new base having been chosen, the quick channel monitoring is restarted with the default list of system channels.

Re-establishing contact

When a new CURRENT_BASE has been chosen, an <MRM>-frame with roaming information is sent to it. If the new BASE is identical to the old CURRENT_BASE, an <MRM>-frame with activation information is sent instead.

Subject

Repro

A 392 61553

Cantel Mobitex

Doc. No.	9/1056 - A 296 5171/02 Ue
Version	1990-02-26 A
Rev	MTS16.2

Area identification

The frame header (on the physical layer) includes an area identification used to specify geographical areas. Such an area is denoted as a traffic area and is given a unique area ID by the network.

From the network layer, the data link layer receives a list including the areas subscribed to by the user. The list also shows if the areas not subscribed to are allowed to be used, with for example higher charges, or not.

From the physical layer, the data link layer receives information about incoming roam information, i.e. area ID, base ID and weighted roaming value.

During the roaming procedure (described above), the terminal will primarily evaluate roaming information from bases belonging to the subscribed traffic areas. If the terminal is allowed to traffic other areas all bases may be considered in the roaming procedure.

In case a "non-subscribed" base is chosen (possible only in quick channel monitoring), it should be notified to the application layer, as well as when the terminal returns to a "subscribed" base.

If the terminal have not yet received the list of area IDs, the roaming procedure will evaluate all base stations.

Booklet

Reprod

Cantel Mobitex

Sr. No.	9/1056 - A 296 5171/02 Ue	
Date Recd	18 Nov	F. No.
1990-02-26	A	MTS16.2

4.4 ADDRESSING**4.4.1 Addressing the base radio station**

The base radio station is only addressed in the frame head. Further details can be found in reference R1-17.

4.4.2 Addressing a mobile terminal

Transmitting The mobile terminal's subscription number (MAN) is always used as the MOB address.

Receiving When receiving, the MOB address refers to the mobile terminal's MAN, or any MAN representing a group to which the terminal belongs. (A transferred subscription is addressed in the MPAK.)

A MAN representing a group occurs only when receiving frame types <MRM>, <BKD>, <BKT>, <BBT> and together with a mask value of 0 in frame types <FRI>, <SVP>, <TST>. Masked addressing is described in detail in chapter 4.4.2.1.

Masked and priority addressing is used in frame types <SVP> and <TST>.

Masked, priority and traffic type addressing is used in frame type <FRI>.

Bidders

Repro

A 292 51503

Cantel Mobitex

9/1056 - A 296 5171/02 Ue

1990-02-26 A

MTS16.2

4.4.2.1 Masked addressing.

Masked addressing is only used in <SVP>, <FRI> and <TST>. In this addressing mode both the MASK and MOB fields of the frame are used. The MASK field indicates the number of bits from the beginning of the MOB field (most significant bits) that should not be considered (masked out) when comparing the MOB field with the terminal's MAN.

A MASK value different from 0 (zero) indicates that only the terminal's own MAN is to be compared with the relevant bits of the MOB field.

A MASK value of 0 (no bits masked out, all bits of MOB are relevant) indicates that the MOB field is to be compared with both the terminal subscription MAN and with the MANs of all current group numbers in the group list.

The terminal is considered to be addressed if all relevant bits of the MOB field are the same as the corresponding bits of one of the compared MANs.

A MASK value of 24 (decimal) indicates that all bits are masked out and that all mobile terminals are addressed.

Note: For <SVP> and <TST> signals the priority of the terminal must also comply with that of the signal.

For the <FRI> signal the priority and traffic type of the terminal must comply with that of the signal for the terminal to be addressed (except for emergency where priority is ignored).
(See below).

Blanket

Reprod

A 296 51530

Cantel Mobitex

9/1056 - A 296 5171/02 Ue
 1990-02-26 A MTS16.2

Example: Assume a frame with the following contents in the MOB and MASK fields.

(x indicates that the corresponding bit is to be ignored)

MOB field Bit no. : 1 24
 Value : 101000000000101010110010

MASK field Bit no. : 1 5
 Value : 11000 (24 decimal)

Addressed MAN Bit no.: 1 24
 Value : xxxxxxxxxxxxxxxxxxxxxxxx

All mobile terminals are addressed.

MASK field Bit no. : 1 5
 Value : 10111 (23 decimal)

Addressed MAN Bit no.: 1 24
 Value : xxxxxxxxxxxxxxxxxxxxxx0

Only mobile terminal subscriptions with MAN ending with binary 0 are addressed.

MASK field Bit no. : 1 5
 Value : 10110 (22 decimal)

Addressed MAN Bit no.: 1 24
 Value : xxxxxxxxxxxxxxxxxxxxxx10

Only mobile terminal subscriptions with MAN ending with binary 10 are addressed.

MASK field Bit no. : 1 5
 Value : 00000 (0 decimal)

Addressed MAN Bit no.: 1 24
 Value : 101000000000101010110010

The MASK value 00000 (zero) indicates that mobile terminals with the terminal subscription MAN, or any of its MAN numbers representing groups, identical to the MOB field are addressed.

Subcarrier

Reprod

Cantel Mobitex

Doc. No.
9/1056 - A 296 5171/02 Ue
Revision Date
1990-02-26 Rev
A
F. F. A
MTS16.2

4.4.2.2 Priority addressing

Priority addressing is used in the frames <SVP>, <TST> and <FRI>.

A terminal subscription belongs to one of 4 priority groups. The terminal may have two priority states within each group, normal or raised. The terminal will raise its priority if it has made MAX_REP retransmissions of the same frame without getting any acknowledgement from the base station.

PRI field	Meaning
7 111	Priority group 4, raised priority
6 110	" " normal
5 101	Priority group 3, raised priority
4 100	" " normal
3 011	Priority group 2, raised priority
2 010	" " normal
1 001	Priority group 1, raised priority
0 000	" " normal

When receiving a frame with priority addressing, the mobile terminal is addressed if its own priority is higher than or same as the received priority.

If the terminal is to transmit an emergency signal the priority level is ignored.

Blanket

Reprod

A 292 5153-3

Cantel Mobitex

9/1056 - A 296 5171/02 Ue
 1990-02-26 A WTS16.2

4.4.2.3 Traffic type addressing

Traffic type applies to the type of MPAK to be sent from the mobile terminal. The packets are separated into 3 traffic types:

emergency: MPAK class PSOSCOM
 speech: MPAK class CSUBCOM
 data: All other types of MPAK

Traffic type addressing is used only in the <FRI> frame. The traffic type to which the <FRI> applies is coded into the FFG field as follows:

Value	Emergency	Speech	Data
00	yes	no	no
01	yes	no	yes
10	yes	yes	no
11	yes	yes	yes

Note: For the frames <SVP> and <TST>, both the masked address and the priority must be correct for the terminal to be addressed.

For the <FRI> to be valid, the masked address, the priority and the traffic type criteria must be met by the terminal, except for the transmission of an emergency signal where only the masked address and traffic type criteria has to be met (priority is ignored).

Blockart

Repro

Cantel Mobitex

Doc No 9/1056 - A 296 5171/02 Ue
 Edition Date Rev P. No
 1990-02-26 A MTS16.2

4.5 SEQUENTIAL NUMBERING

The transmitting unit repeats the transmission of a frame if there is no response from the receiving unit. This means that the receiving unit can receive identical frames if its response is not detected by the transmitting unit. To avoid repeated presentation of information, certain types of frame are given sequential numbers. The principle is as follows.

- The terminal sets up a sequential register for the terminal subscription MAN (up and down sequential number) and for each of the MANs stored in GROUP_LIST (only a down sequential number for each).
- A sequential number is an integer with a value in the range (0...15). The sequential numbers are incremented cyclically 1, 2, 3...., 14, 1, 2, 3 etc. The values 0 and 15 are reserved for special purposes.
- The up sequential number applies to frames transmitted in the direction from MOB to BASE. The up sequential number is increased by one by the mobile terminal for each new <MRM>-frame transmitted.
- MOB which receives a sequentially numbered frame checks the sequential number of the frame against the stored down sequential number for the corresponding MAN. If the received sequential number is the same (and not 0, see below), the information in the frame is ignored. If the sequential number is not the same (or 0, see below), the frame is accepted and the sequential number of the received frame is stored (except for 15, see below). The number is stored when acknowledgement of the frame has been sent.
- On reception, the value 0 for a sequential number means that a sequential number check should not be carried out on the frame and that the value 0 should be stored in the terminal as the new down sequential number.
- On reception, the value 15 for a sequential number means that a sequential number check should not be carried out on the frame and that the old down sequential number remains.

Blanket

Reprod

A 102 51573

Cantel Mobitex -

No. 9/1056 - A 296 5171/02 Ue
Date: 1990-02-26 Rev: A File: MTS16.2

The up and down sequential numbers are set to 0 when not defined (e.g. at initial start up).

Down sequential numbers for group numbers are reset to 0 when roaming in on a new base station.

Also returned packets with status UNKNOWN should have a sequential number.

When the mobile is transmitting the following types of packets, the sequential number 15 should be used:

```
CSUBCOM:DISCON
CONREA
DTESERV:ACTIVE
INACTIVE
ROAM
BORN
```

Bulkout

Repro

A 296 5153.3

Cantel Mobitex

No. 9/1056 - A 296 5171/02 Ue.
 System Date 1990-02-26 Rev A Ver. File MTS16.2

4.6 OUTPUT POWER CONTROL

The MOBITE^X system allows for mobile terminals to control the output power via parameters in the system signalling, from the base radio station. Network operator requirements concerning this matter is stated in reference R1-06, as well as the nominal output power.

Requirements, such as the number of output levels to be controlled by the mobile terminal and in what steps the levels should be controlled, is also stated in reference R1-06.

The mobile terminal receives information about the output power to be used in the base station cell in question. This is stated by the parameter TXPOW in the <SVP>-frame.

Portable transmitters may have lower output power than ordinary transmitters. Note that the receiver sensitivity should be reduced or an offset should be added to the parameters GOOD_BASE and BAD_BASE used in the roaming procedure. This is done in order to keep the same ratio between the permitted transmission losses in the send and receive directions, i.e. to maintain a balanced radio path.

For example, if the power of the transmitter is 10 dB lower than the specified level, the receiver sensitivity could be reduced by 10 dB from the specified sensitivity level. Instead of reducing the sensitivity, an offset of 10 can be added to the parameters GOOD_BASE and BAD_BASE.

Blanket

Reprod


A 292 51533

Cantel Mobitex

9/1056 - A 296 5171/02 Ue
 1990-02-26 A MTS16.2

4.7 LOGICAL DESCRIPTION

The data flow diagram below shows the interaction between modules in the Data Link Layer and between this layer and the Network and Physical Layers.



- 1- MPAK transmitted, MPAK not transmitted, MPAK received, roaming, activation
- 2- MPAK to transmit, MPAK to retransmit, speech on, speech off, order to return MPAK, list of area IDs, list of group numbers

Signals to/from Physical Layer:

- 3- Received block, Sync search
- 4- Frame to send, Frame length
- 5- Slot length, Chosen slot, Slot reached, Silence, Cannot send
- 6- Current base, Frame sent
- 7- Received base, Measure_RSSI, RSSI_measured

Signals to the Application Layer:

- 8- Speech queue info, base lost, base contact, area subscribed to chosen, area not subscribed to chosen

Block:

Diagram:

Cantel Mobitex

No. 9/1056 - A 296 5171/02 Ue
 Version Date Rev. Rev. Date
 1990-02-26 A MTS16.2

4.7.1 Input and decoding (DCOD)

DCOD converts the bit stream from the physical layer into frames. It decodes the blocks of these frames and checks that the frames are addressed to the terminal.

4.7.1.1 Logical description

```

LOOP
  wait for information bits from Physical Layer
  read and decode first block
  IF first block is correct THEN
    CASE frame type
      WHEN <ACK>, <NAK>, <ATL>, <ATD>, <ATT>, <NAT> or <VKT>
        IF frame address = terminal address THEN
          send frame to OFRA
        ENDIF
      WHEN <REB>
        IF frame address = terminal address THEN
          read and decode remaining blocks of frame
          IF frame is error-free THEN
            send frame to OFRA
          ENDIF
        ENDIF
      WHEN <PRI>, <SVP> or <TST>
        IF (frame address with mask = terminal address) OR
           (mask=0 and address = a group address) THEN
          read and decode remaining blocks of frame
          IF frame is error-free THEN
            send frame to OFRA
          ENDIF
        ENDIF
      WHEN <AKT> or <RES>
        IF frame address = terminal address THEN
          read and decode remaining blocks of frame
          send frame to IFRA
        ENDIF
      WHEN <MRM>, <BKD>, <BKT> or <BBT>
        IF (frame address = terminal address) OR
           (frame address = a group address) THEN
          read and decode remaining blocks of frame
          send frame to IFRA
        ENDIF
      ENDCASE
    ENDIF
    send sync_search order to Physical Layer
  ENDLOOP
  
```

Initiators:

Replies:

Cantel Mobitex-

No. 37	9/1056 - A 296 5171/02 Ue
Docum. Date	1846
1990-02-25	A
	MTS16.2

4.7.2 Processing incoming frames (IFRA)

IFRA handles the received frames from DCOB. If a received <MRM> is not error-free, IFRA requests a repeat transmission of the faulty blocks until a correct <MRM> has been received and acknowledged.

4.7.2.1 Logical description

LOOP

wait for frame from DCOB

CASE frame type

WHEN <MRM>

IF we have <MRM> waiting for <RES> THEN
delete that <MRM>

ENDIF

IF response required THEN

IF <MRM> is error-free THEN

create <ACK> and send it to CODE

send <MRM> to PAHA

ELSE

IF <MRM> is shorter than 3 blocks THEN

create <NAK> and send it to CODE

ELSE

create <REB> and send it to CODE

store <MRM> while waiting for <RES>

ENDIF

ENDIF

ELSE

IF <MRM> is error free THEN

send <MRM> to PAHA

ENDIF

ENDIF

WHEN <RES>

retrieve stored <MRM>

IF sequential number = stored <MRM>:s sequential
number THEN

complete <MRM> with error free blocks from <RES>

IF <MRM> is error free THEN

create <ACK> and send it to CODE

send <MRM> to PAHA

ELSE

create <REB> and send it to CODE

store <MRM> while waiting for <RES>

ENDIF

ENDIF

WHEN <BKT>, <BKD> or <BBT>

IF frame is error free THEN

send frame to PAHA

ENDIF

WHEN <AKT>

create <ACK> and send it to CODE

ENDCASE

ENDLOOP

Bridgman

Report

Cantel Mobitex

9/1056 - A 296 5171/02 Ue
 1990-02-26 A MTS16.2

4.7.3 Processing outgoing frames (OFRA)

OFRA handles the sending of frames. It must wait for permission to send, decide whether an access request is to be sent first etc.

OFRA receives <MRM>-frames of traffic types emergency, speech or data from PAHA. It returns them to PAHA with a statement of whether acknowledgement of the frame has been received or not. PAHA can also request that OFRA should cease trying to transfer the frame.

If the Data Link Layer is in speech_mode, an <MRM> may be sent immediately. This is done with a timeout that is independent of any free cycles.

OFRA is capable of handling only one <MRM>-frame at a time.

4.7.3.1 Logical description.

LOOP

```
wait for input signal
CASE input signal
WHEN new <MRM> from PAHA
  IF (free cycle is running) and (priority and traffic
    type allows transmission) THEN
    choose next free slot
    store <MRM> while waiting for slot_reached
  ELSE
    IF speech_mode THEN
      send copy of <MRM> to CODE for transmission
      speech_mode_timer := 2 seconds
    ELSE
      store <MRM> while waiting for permission to send
    ENDIF
  ENDIF
  cancel_request := FALSE

WHEN STOP SEND from PAHA
  return <MRM> to PAHA with status 'discontinued'
  IF speech_queue THEN
    IF free cycle is running THEN
      choose next free slot
    ENDIF
    speech_queue := FALSE
    cancel_request := TRUE
  ENDIF

WHEN SPEECH TRUE from PAHA
  speech_mode := TRUE
  speech_queue := FALSE

WHEN SPEECH FALSE from PAHA
  speech_mode := FALSE
```

Buskort

Reprod

A 297 51510

Cantel Mobitex

No. 9/1056	- A 296	5171/02 Use
System Date 1990-02-26	1 Rev A	File No. MTS16.2

```

WHEN timeout of speech_mode_timer
  return <MRM> to PAHA With Status 'failed'

WHEN <ACK> from DCOB
  IF sequential number in <ACK> = sequential number in
    latest <MRM> THEN
    return <MRM> to PAHA with status 'OK'
    disable speech_mode_timer
  ENDIF

WHEN <NAK> from DCOB
  IF sequential number in <NAK> = sequential number in
    latest <MRM> THEN
    send copy of latest <MRM> to CODE for transmission
  ENDIF

WHEN <RES> from DCOB
  IF sequential number in <RES> = sequential number in
    latest <MRM> THEN
    create <RES> and send it to CODE for transmission
  ENDIF

WHEN <FRI> from DCOB
  update free signal parameters
  IF we have <MRM> waiting for <RES> THEN
    delete that <MRM>
  ENDIF
  IF cancel_request THEN
    choose a random free slot
  ELSE
    IF we have <MRM> to send THEN
      IF priority and traffic type allows transmission
        THEN
          IF NOT speech_queue THEN
            IF we have already repeated <MRM> MAX_REP
              times THEN
                return <MRM> to PAHA with status 'failed'
            ELSE
              choose a random free slot
              store <MRM> while waiting for slot_reached
            ENDIF
          ENDIF
        ELSE
          store <MRM> while waiting for permission to send
        ENDIF
      ENDIF
    ENDIF
  ENDIF

```

Bidkari

Regno

A 297 51530

Cantel Mobitex

Doc. No. 9/1056 - A 296 5171/02 Ue
Current Date 1990-02-26 Rev A P.F. No. MTS16.2

```

WHEN <ATD> from DCOD
  IF we have data <MRM> to send THEN
    send copy of <MRM> to CODE for transmission
  ENDIF

WHEN <ATT> from DCOD
  IF we have speech <MRM> to send THEN
    send copy of <MRM> to CODE for transmission
  ENDIF

WHEN <NAT> from DCOD
  IF we have speech <MRM> to send THEN
    IF order to leave CURRENT BASE THEN
      return <MRM> to PAHA with status 'failed'
    ELSE
      return <MRM> to PAHA with status 'no channel'
    ENDIF
  ENDIF
  speech_queue := FALSE

WHEN <ATL> from DCOD
  IF we have emergency <MRM> to send THEN
    send copy of <MRM> to CODE for transmission
  ENDIF

WHEN <SVP> from DCOD
  IF (sub type 1 or 2) and (priority is the same as or
    less than terminal priority) THEN
    send <SVP> to PAHA
  ENDIF

WHEN <TST> from DCOD
  send signal to Physical Layer that we cannot_send in
  any slot

WHEN <VRT> from DCOD
  speech_queue := TRUE
  queue_timer := timeout value
  send signal SPEECH_QUEUE_INFO to Application Layer

WHEN timeout of queue_timer
  speech_queue := FALSE

WHEN SILENCE from Physical Layer
  send signal to Physical Layer that we cannot_send in
  any slot

```

Billings

Deprec

A 191 S1593

Cantel Mobitex

No.	9/1056 - A 296 5171/02 Ue
Version	1990-02-26 A
Rev.	WTS16.2

```

WHEN SLOT REACHED from Physical Layer
IF we have <MRM> to send THEN
CASE <MRM> traffic type
WHEN emergency
IF <MRM> contains more blocks than MAX_ACCESS
THEN
create <ABL> and send to CODE for transmission
ELSE
send copy of <MRM> to CODE for transmission
ENDIF
WHEN speech
IF cancel_request THEN
cancel_request := FALSE
create <AAT> and send to CODE for transmission
ELSE
IF <MRM> with line connection request THEN
IF <MRM> contains more blocks than MAX_SPEECH
THEN
create <ABT> and send to CODE for
transmission
ELSE
send copy of <MRM> to CODE for transmission
ENDIF
ELSE
send copy of <MRM> to CODE for transmission
ENDIF
ENDIF
WHEN data
IF <MRM> contains more blocks than MAX_ACCESS
THEN
create <ABD> and send to CODE for transmission
ELSE
send copy of <MRM> to CODE for transmission
ENDIF
ENDCASE
increment counter of attempts to send
ENDIF
ENDCASE
ENDLOOP

```

Buildsheet

Reprod

Cantel Mobitex -

Doc. No.	9/1056 - A 296 5171/02 Ue		
Exam. Date	1990-02-26	Class	A
		F. No.	MTS16.2

4.7.4 Coding and readout (CODE)

CODE codes the blocks of the frame and transfers the bits to the Physical Layer.

4.7.4.1 Logical description

LOOP

Wait for frame to transmit

Code the blocks of the frame

Transfer the bits to the Physical Layer

ENDLOOP

Blockcode

Reprod

A 792 51553

Cantel Mobitex

Sp. No.	9/1056 - A 296 5171/02 Ue	
Current Date	1 Rev	File No.
1990-02-26	A	MTS16.2


4.7.5 Base contact monitoring (BMON)

BMON monitors contact with the base station(s) and works in 3 different modes:

- 1- Normal Channel Monitoring
- 2- Quick Channel Monitoring
- 3- Disabled

For further information, see chapter ROAMING.

Input signals come from the Physical Layer and from PAHA:



- 1- no_base_contact
best_BASE
- 2- set_mode_1
set_mode_2
set_mode_3
- 3- received_base

Initial:

Reprod

Cantel Mobitex -

No. 9/1056 - A 296 5171/02 Ue
 Datum Date 1990-02-26 A
 PC No. MTS16.2

4.7.6 Packet handling (PAHA)

PAHA handles the conversion between MPAKs and <MRM>-frames. It supervises the contact with BASE and informs the network when changing BASE and when returning after lost contact with the network.

PAHA is only capable of handling one MPAK at a time and it works in three different modes:

- Normal mode - Contact with a base station is established and the Network Layer may send and receive all types of MPAK.
- Speech mode - PAHA enters this mode only on order from the Network Layer. The Network Layer also decides which MPAKs that may be sent. PAHA leaves the speech mode on order from the Network Layer or when the transmission of an <MRM> has failed.
- Base search mode - When base contact is lost, PAHA enters base search mode. MPAKs from the Network Layer are not handled in this mode. When a base has been located, PAHA returns to normal mode.

The mobile terminal returns to the relevant system channel after the end of all sessions on other channels (channel_for_sending_speech, channel_for_sending_data).

Bildkort

Repro

A 292 51533

Cantel Mobitex-

No. 35		9/1056 - A 296 5171/02 Ue	
Start Date	1990-02-26	Rev	A
Rev. No.		MTS16.2	

4.7.6.1 Logical description, main program

```

IF an old base is saved THEN
  send set_mode_1 to BMON
  system_channel := current_system_channel
  OFRA_status    := free
  main_mode      := normal_mode
ELSE
  main_mode      := base_search_mode
ENDIF

```

```

LOOP
  CASE main_mode
    WHEN normal_mode
      normal
    WHEN speech_mode
      speech
    WHEN base_search_mode
      base_search
  ENDCASE
ENDLOOP

```

Bidker:

Reprod

A 292 81530

Cantel Mobitex

9/1056 - A 296 5171/02 Ue
 1990-02-26 A MTS16.2

4.7.6.2 Logical description, normal (normal_mode)

```

WHILE main_mode = normal_mode
  wait for input signal
  CASE input signal

    WHEN MPAK TO TRANSMIT from Network Layer
      create <MRM> with new up sequential number
      IF access channel opened THEN
        change to access channel
        channel := channel_for_sending_data
      ENDIF
      send <MRM> to OFRA
      OFRA_status := busy

    WHEN MPAK TO RETRANSMIT from Network Layer
      create <MRM> with old up sequential number
      IF access channel opened THEN
        change to access channel
        channel := channel_for_sending_data
      ENDIF
      send <MRM> to OFRA
      OFRA_status := busy

    WHEN SPEECH_ON from Network Layer
      main_mode := speech_mode

    WHEN RETURN MPAK from Network Layer
      send stop_send to OFRA
      wait to get frame that was in progress
      return <MRM> to Network Layer with status 'not
      transmitted'

    WHEN <SVP> from OFRA
      CASE sub type
        WHEN 1
          update parameters
        WHEN 2
          CASE type of channel
            WHEN local system channel opened
              system_channel := local
              change to new system channel
            WHEN local system channel closed
              system_channel := previous
              change to new system channel
            WHEN access channel opened
              store access channel
            WHEN access channel closed
              delete access channel
          ENDCASE
        ENDCASE
  
```

Bildschirm

Repro

A.296 51553

Cantel Mobitex -

Doc No 9/1056 - A 296 5171/02 Ue
 Date 1990-02-26 Rev A Ed Rev MTS16.2

```

WHEN <BKT> from IFRA
  IF acknowledgement of <MRM> THEN
    send <ACK> to OFRA
  ELSE
    start timer with timeout value
  ENDIF
channel := channel_for_speech
change to designated channel
send set_mode_3 to BMON

WHEN <BKD> from IFRA
  IF it is a channel change to send frame THEN
    channel := channel_for_sending_data
  ELSE
    channel := channel_for_receiving_data
  ENDIF
start timer with timeout value
change to designated channel
send set_mode_3 to BMON

WHEN timeout for change of channel
  change to system channel
  send set_mode_1 to BMON

WHEN <BBT> from IFRA
  store new parameters and change channel

WHEN <MRM> with status 'OK' from OFRA
  OFRA_status := free
  return MPAK to Network Layer with status 'transmitted'
  priority := normal
  IF channel = channel_for_sending_data THEN
    change to system channel
    send set_mode_1 to BMON
  ENDIF
  reset timer for change of channel

WHEN <MRM> with status 'failed' from OFRA
  OFRA_status := free
  return MPAK to Network Layer with status 'not
  transmitted'
  priority := raised
  main mode := base search mode
  reset timer for change of channel

WHEN <MRM> with status 'no channel' from OFRA
  OFRA_status := free
  return MPAK to Network Layer with status 'not
  transmitted'
  priority := raised
  reset timer for change of channel
  
```

Bidder

Repro

A 296 51530

Cantel Mobitex

9/1056 - A 296 5171/02 Ue
 1990-02-26 A WTS16.2

```

WHEN incoming <MRM> from IFRA
CASE incoming sequential number
WHEN 0
  check_ok := TRUE
  store new down sequential number
WHEN 15
  check_ok := TRUE
WHEN OTHERWISE
  IF different from last seq. number received THEN
    check_ok := TRUE
    store new down sequential number
  ELSE
    check_ok := FALSE
  ENDIF
ENDCASE
IF check_ok THEN
  IF channel = channel_for_receiving_data THEN
    IF response NOT required THEN
      change to system channel
      send set_mode_1 to BMON
    ENDIF
    send MPAK to Network Layer
  ELSE
    delete <MRM>
  ENDIF
  reset timer for change of channel
WHEN Frame sent from Physical Layer
IF frame = <ACK> THEN
  IF channel = channel_for_receiving_data THEN
    change to system channel
    send set_mode_1 to BMON
  ENDIF
  reset timer for change of channel
ENDIF
WHEN no base contact from BMON
IF OFRA_status = busy THEN
  send stop_send to OFRA
  wait to get frame that was in progress
  return <MRM> to Network Layer with status 'not
  transmitted'
ENDIF
main_mode := base_search_mode
ENDCASE input signal
ENDWHILE

```

Bidart

Raprot

A 292 51530

Cantel Mobitex™

Doc. No. 9/1056 - A 296 5171/02 Ue
 Date: Date 1 Rev. 1 Rev. 1 Rev. 1 Rev.
 1990-02-26 A MTS16.2

4.7.6.3 Logical description, base search (base search mode)

```
wait for input signal BEST BASE from BMON
IF roaming value > GOOD BASE THEN
  CURRENT BASE := new base
  CURRENT SYSTEM CHANNEL := new channel
  send signal ROAMING to Network Layer
  clear sequential numbers for all groups
  delete access channel
ELSE
  send signal BASE LOST to Application Layer
  send order set_mode_2 to BMON
  REPEAT
    wait for input signal BEST BASE from BMON
  UNTIL roaming value > CHOOSE BASE
  IF base = CURRENT BASE THEN
    send signal ACTIVATION to Network Layer
  ELSE
    CURRENT BASE := new base
    CURRENT SYSTEM CHANNEL := new channel
    send signal ROAMING to Network Layer
    clear sequential numbers for all groups
    delete access channel
  ENDIF
  send signal BASE_CONTACT to Application Layer
ENDIF
send set_mode_1 to BMON
main_mode := Normal_mode
```

Blanket

Reprint

A.296 5153a

Cantel Mobitex

Sr. No.	9/1056 - A 296 5171/02 Ue
System Date	1990-02-26 A
Rev.	MTS16.2

4.7.6.4 Logical description, speech (speech mode)

```

send speech_true to OFRA

WHILE main_mode = speech_mode

CASE input signal
WHEN speech_off from Network Layer
    wait 0.5 seconds
    change to system channel
    send set_mode 1 to BMON
    send speech_false to OFRA
    main_mode := normal_mode

WHEN new MPAK from Network Layer
    create <MRM> with new up sequential number
    send <MRM> to OFRA
    OFRA_status := busy

WHEN MPAK from Network Layer to be retransmitted
    create <MRM> with old up sequential number
    send <MRM> to OFRA
    OFRA_status := busy

WHEN <MRM> with status 'OK' from OFRA
    OFRA_status := free
    IF <MRM> with CSUBCOM:DISCON THEN
        change to system channel
        send set_mode 1 to BMON
        send speech_false to OFRA
        main_mode := normal_mode
    ENDIF
    return MPAK to Network Layer with status 'transmitted'

WHEN <MRM> with status 'failed' from OFRA
    change to system channel
    send set_mode 1 to BMON
    send speech_false to OFRA
    main_mode := normal_mode
    IF <MRM> with CSUBCOM:DISCON THEN
        send <MRM> to OFRA
    ELSE
        OFRA_status := free
        return MPAK to Network Layer with status 'not
        transmitted'
    ENDIF

WHEN <BBT> from IFRA
    store new parameters and change channel

```

Richard

Reprod

A 297 51532

Cantel Mobitex -

No. 9/1056 - A 296 5171/02 Ue
Date: 1990-02-26 Rev. A File: MTS16.2

```

WHEN incoming <MRM> from IFRA
CASE incoming sequential number
  WHEN 0
    send MPAK to Network Layer
    store new down sequential number
  WHEN 15
    send MPAK to Network Layer
  WHEN OTHERWISE
    IF different from last seq. number received THEN
      send MPAK to Network Layer
      store new down sequential number
    ELSE
      delete <MRM>
    ENDIF
  ENDCASE

WHEN signal from BMON
  ignore this signal
ENDCASE

ENDWHILE

```

Block:

Report

A 97 91333

Cantel Mobitex-

No. No.	9/1056 - A 296 5171/02 Ue	
Version Date	Rev	F. F. a
1990-02-26	A	MTS16.2

4.8 TRANSFER EXAMPLES

This chapter describes the most common transfer cases of the protocol.

4.8.1 Transfer without response

Transfer without response can only take place in the direction BASE to MOB.

In traffic to mobile terminal(s) BASE often addresses more than one MOB. This can apply to traffic to group numbers or frames where masked addressing occurs. In these cases MOB will not transmit a response. BASE states this by not setting the response flag in these frames.

Ex 1.1

Transfer without response, <MRM> BASE --> MOB

BASE <MRM>
MOB

-----> t

Bilker:

Beproe

A 102 41523

Cantel Mobitex

No. 9/1056 - A 296 5171/02 Ue
Date 1990-02-26 Rev A
Page 1 of 1 MTS16.2

4.8.2 Transfer with simple acknowledgement

BASE has full control over the down frequency and can transmit an <MRM>-frame at any time to a certain MOB. If the response flag is set and no incorrigible bit error has been detected in the frame, MOB should reply with <ACK>.

Ex 2.1

Transfer with response, <MRM> BASE --> MOB

BASE	<MRM>
MOB	<ACK>

t

Note that <ACK> is sent without considering slot boundaries and other access limitations.

Ex 2.2

Transfer with response, <MRM> MOB ---> BASE

BASE	<FRI>	<ACK>
MOB	<MRM>	

t

By transmitting <FRI>, BASE allows MOB to transmit <MRM>.

In this case MOB expects an acknowledgement from BASE. The lack of an acknowledgement is indicated in this case by MOB receiving a <FRI> without having previously received acknowledgement of its frame. Frame repetition follows in this case.

Free slots is defined, and thus access permission to the up channel is granted, when BASE transmits a <FRI> with an address that is applicable to MOB. Access permission is withdrawn for a certain MOB if any of the following cases arise.

- 1 BASE transmits a silence signal (see reference RI-17). This signal applies to all terminals.
- 2 BASE transmits a <TST> with an address which applies to MOB.
- 3 The free-cycle period as defined in the <FRI>-signal expires.

Bullhorn

Repro

A 297 31353

Cantel Mobitex

Doc No	9/1056 - A 296	5171/02 Ue
Doc. Date	1990-02-26	A
Rev		MTS16.2

4.8.3 Transfer with block repetition

If the receiver of an <MRM> detects that one or more of the following blocks is incorrigible, the receiver may request repetition of these blocks with a <REB>. The sender replies with a <RES>.

NOTE Block repetition occurs only on <MRM>-frames where the number of blocks is 3 or more.

EX 3.1

Transfer with block repeat, MOB ----> BASE

BASE		<REB>	<ACK>
MOB	<MRM>	<RES>	

The principle described in the figure above applies in the direction to BASE and in the direction to MOB.

Boldface

Reprod

A 292 51333

Cantel Mobitex

Doc. No. 9/1056 - A 296 5171/02 Ue
Date Issued 1990-02-26 Rev. A PS No. MTS16.2

4.8.4 Transfer with frame repetition

Frame repetition can occur for three reasons:

- 1 The receiving unit transmits a <NAK>
- 2 The receiving unit does not transmit a response
- 3 The packet type results in frame repetition

EX 4.1

Transfer with negative acknowledgement MOB ---> BASE

BASE <MRM> <MRM>
MOB <NAK> <ACK>

If the receiving unit finds that the received frame is incorrectable and is less than 3 blocks, it can notify the sender unit by transmitting a <NAK>. The transmitting unit should then repeat the message. The principle above applies in both transmission directions.

The frame is repeated immediately after an <NAK> is received, regardless of slot boundaries.

Ex 4.2

Transfer with frame repeat, MOB ---> BASE

BASE <FRI> <ACK> <FRI> <ACK>
MOB <MRM> <MRM>
-----XXXXX-----> t

In this example the first acknowledgement from BASE is destroyed by interference so that MOB retransmits the same message after the next free signal.

Subport

Repro

Cantel Mobitex

Doc No
9/1056 - A 296 5171/02 Ue
Docum Date 1990-02-26 Rev A Pg. 1 of 2
MTS16.2

Ex 4.3

Transfer with frame repeat, BASE ---> MOB

BASE < MRM > <MRM>
MOB -----> t

In this example, frame repeat is caused by the packet type demanding repeated transmission. The response flag is never set in this case.

This case occurs for MPAK to group numbers. To avoid repeated presentation of the information in the frame, the frame has got a sequential number. According to the principles for sequential numbering, MOB will ignore subsequent identical frames.

NOTE! At the restart of a base radio station, the sequential numbers for all groups are set to 0. This is done to ensure that mobiles will not loose the first message to a group. The consequence of this action will be that the first message may be presented MAX_REP + 1 times at the mobile terminal.

Billions

Repro

A 296 5171/02

Cantel Mobitex-

9/1056 - A 296 5171/02 Ue

1990-02-26 A MTS16.2

4.8.5 Transfer with access request

If an <MRM>-frame to be sent from MOB to BASE is longer than MAX ACCESS this <MRM> may not be sent during free slots. These longer frames are handled with access request, <ABD>, and access permission, <ATD>.

EX 5.1

Transfer with access request, MOB ---> BASE

```

BASE <PRI>          <ATD>          <ACK>
MOB          <ABD>          <MRM>
-----> t
  
```

The principle is that instead of MOB transmitting its <MRM>-frame, it transmits an <ABD>-frame. The reply to this request is an access permission, <ATD>. When MOB receives access permission, it immediately starts transmitting the <MRM>.

EX 5.2

Repetition with max_rep, MOB ---> BASE

```

BASE <PRI> ..<PRI> ....<PRI>
MOB          <ABD>          <ABD>
-----> t1
  
```

t1: When the number of transmitted access requests is equal to MAX_REP+1 and another <PRI> is received, the MPAK is returned to the network layer and a new base is chosen.

Subject:

Remarks:

Cantel Mobitex-

9/1056 - A 296 5171/02 Ue
1990-02-26 A MTS16.2

4.8.6 Transfer with line connection

The line connection session is described in reference R1-09. When MOB wants to send an <MRM> (containing a request for a line connection) longer than MAX_SPEECH it must request access for this. The access request results in a channel change order. On the new channel the session for frames takes place to establish the line connection. When the line connection is concluded MOB returns to the system channel.

EX 6.1

Transfer with line connection

```

BASE c1 <PRI>      <BKT> |
BASE c2            | <ATT>      <ACK> |
MOB c1             <ABT> |
MOB c2             | <MRM>      ... |
                   t1      t2 t3
                   -----> t

```

- t1: Disable roaming and start timeout with time from <BKT>.
- t2: Stop timeout.
- t3: Speech_on received from Network Layer.

Buskort:

Regres

A 392 5151/2

Cantel Mobitex-

9/1056 - A 296 5171/02 Ue
1990-02-26 A MTS16.2

4.8.7 Transfer on several channels

Transfer on several channels can be divided into two separate cases:

- 1 MOB appears on another channel because BASE has stated in a <SVP>-frame that all traffic from a mobile terminal shall be sent on a channel other than that on which the <SVP> came.
- 2 BASE transmits a <BKD>-frame as a reply to an <ABD>.

EX 7.1

Transfer on several channels

BASE c1	<FRI>	<BKD>	<ATD>	<ACK>	
BASE c2					
MOB c1	<ABD>				
MOB c2			<MRM>		
		t1		t2	t

- t1: Disable roaming and start timeout with time from <BKD>.
t2: Return to system_channel, enable roaming.

In this example, the access request from MOB resulted in a channel change order. The access permission is transmitted on channel c2. After having received an acknowledgement, MOB returns to channel c1.

Blindat?

Reproes

A 292 5153d

Cantel Mobitex

9/1056 - A 296 5171/02 Ue
 1990-02-26 A MTS16.2

4.8.8 Line connection with hand over

EX 8.1

Ordinary line connection

BASE1,c1	<FRI>	<BKT>			
BASE1,c2		<ATT>	<ACK>	...	speech
MOB, c1		<ABT>			
MOB, c2			CONREQ	...	speech
				t1	
					>t

t1: Ordinary connection established.

EX 8.2

Continued with <BBT>

BASE2,c1					
BASE2,c3			.. speech .	<ACK>
BASE1,c1					
BASE1,c2	...	<BBT>			
MOB, c1
MOB, c2				
MOB, c3		.. speech .	DISCON		
	t2	t3	t4		t5
					>t

t2: Hand over to base B2.

t3: MOB connected to base B2 on new speech channel, new system channel stored for later use.

t4: MOB breaks connection and changes to the new system channel.

t5: Connection ended.

Cantel Mobitex

9/1056 - A 296 5171/02 Ue
 1990-02-26 A MTS16.2

4.8.9 Line connection with queue handling.

If no speech channel is immediately available, BASE may place MOB in a queue of callers and reply with <VKT>.

EX 9.1

Successfully established line connection

BASE1, c1	<FRI>	<VKT>	...	<BKT>			
BASE1, c2				<ATT>	<ACK>	speech	
MOB, c1	<ABT>		...				
MOB, c2				CONREQ		speech	
			t1	t2		t3	
							----->t

t1-t2: Waiting time.

t3: Connection established.

EX 9.2

Call attempt ended by BASE

BASE1, c1	<FRI>	<VKT>	...	<NAT>		
MOB, c1	<ABT>		...			
			t1	t2	t3	
						----->t

t1-t2: Waiting time.

t3: Call attempt ended.

EX 9.3

Call attempt ended by MOB

BASE1, c1	<FRI>	<VKT>	...	<AAT>		
MOB, c1	<ABT>		...			
			t1	t2	t3	
						----->t

t1-t2: Waiting time.

t3: Call attempt ended.

B. Gant

Revised

A 292 5153A

Cantel Mobitex -

9/1056 - A 296 5171/02 Ue
 1990-02-26 A MTS16.2

EX 9.4

Call attempt ended by MOB

BASE1, c1	<FRI>	<VKT>	...	<VKT>	...	<AAT>
MOB, c1	<ABT>		t1 t2	t3 t4	t5	
						----->t

t1-t2: Waiting time.
 t3-t4: Waiting time.
 t5: Call attempt ended.

B. Albert

Reprova

A 292 5173.2

Cantel Mobitex

Doc No.
9/1056 - A 296 5171/02 Ue
Doc Date 1990-02-26 Rev A P. 1 of 2
MTS16.2

4.8.10 Line connection without access request

When MOB wants to send an <MRM> (containing a request for a line connection) shorter than or equal to MAX_SPEECH no access request is needed.

The response to the <MRM> is a channel change order that includes an acknowledgement. The line connection is immediately established on the new channel.

EX 10.1

Line connection without access request

```
BASE c1 <FRI>      <BKT>
BASE c2
MOB  c1      <MRM>
MOB  c2      .. speech ..
                                     -----> t
```

4.8.11 Ending a line connection

An <MRM> with a DISCON may be transmitted only once on the speech channel. If MOB have not received <ACK> within 2 seconds, it changes to the system channel and continues the transmission attempts according to the usual rules.

EX 11.1

Ending a line connection

```
BASE c1      <FRI>      <ACK>
BASE c2 ..speech.....|
MOB  c1      DISCON
MOB  c2 ..speech.. DISCON|
                                     t1 t2 t3
                                     -----> t
```

t1-t2: Timeout.
t2: Return to system channel, enable roaming.
t3: Connection ended.

Buttons:

Repress:


Cantel Mobitex

9/1056 - A 296 5171/02 Ue
1990-02-26 A MTS16.2

4.8.12 Line connection ended by speech_off

After the mobile terminal has received an <MRM> containing a line connection request, the session may be put to an end by the signal speech_off from the network layer. This signal is generated by a timeout (please see reference R1-09) when the operator has not answered the call.

EX 12.1



- t1: Disable roaming and start timeout with time from <BKT>.
- t2: Stop timeout.
- t3: Speech_off received from Network Layer. Return to system channel and enable roaming:

Balance:

Reserve

A 102 51553

Cantel Mobitex

9/1056 - A 296 5171/02 Ue
1990-02-26 A MTS16.2


5 SYSTEM PARAMETERS TO BE STORED IN THE TERMINAL

Certain system parameters are stored continuously (even if the terminal is powered off) in MOB to permit correct action when starting up. These are:

- The terminal subscription MAN (GROUP LIST)
- Group number list (MAX_REP)
- Maximum number of retransmissions allowed (up/down)
- Sequential numbers - terminal MAN
- Current base
- Current system channel
- A list of the area identifications that the mobile is allowed to use. Please see reference R1-06.

When switched on, all these parameters apply until a frame is received containing the current parameter values.

There is also a permanent (and possibly a temporary) default list of system channels used by the roaming algorithm. They are stored continuously and have the following general format:



A channel is defined as a pair of frequencies and all the channels of this list are given in reference R1-06.

3.1.1.1

Appendix

Cantel Mobitex

9/1056 - A 296 5171/02 Ue
1990-02-26 A MTS16.2

6 MOBITEK TERMINAL SPECIFICATION REFERENCE LIST

This document includes a number of references, made to other sections in the terminal specification. The list below shows these references, together with the page(s) they are made on. Please note that a section could be referred to several times on the same page.

RI-06, 17, 22, 31, 62
RI-09, 4, 7, 55, 61
RI-17, 5, 14, 17, 24, 50

Below are the reference designations listed.

<u>Reference</u>	<u>Section</u>
RI-01	Arrangement of the documents
RI-02	MOBITEK System description
RI-03	General description of terminals
RI-04	Terminology
RI-05	References
RI-06	Network operator information
RI-08	Application layer
RI-09	Network layer
RI-11	Interface requirements, fixed terminals
RI-12	Other requirements, fixed terminals
RI-16	Link layer, mobile terminals
RI-17	Physical layer, mobile terminals
RI-18	Radio equipment, mobile terminals
RI-19	Other interfaces, mobile terminals
RI-20	Other requirements, mobile terminals

Revised

Revised

A 296 5171/02

REQUIREMENT SPECIFICATION 1(44)

Customer - Prepared ET/SYS IK	Facility/Service - Subject description ET/SYS IK	No 91/1056 - A 296 5171/A2 Ue
Customer - Checked - For response approved ET/SYSC STT <i>STT</i>		Date 1990-02-22 A
Beginning		File MTS16A.2
<p>Cantel Mobitex</p> <p><u>ABSTRACT</u></p> <p>This document describes frame structure and coding for the Data Link Layer.</p>		
<p>Backert</p> <p>Reprod</p>		

A 296 51533

Cantel Mobitex™

Doc No
91/1056 - A 296 5171/A2 Use
Revision Date Rev
1990-02-22 A
File No
MTS16A.2

TABLE OF CONTENTS

1	INTRODUCTION	3
1.1	GENERAL	3
2	FRAME TYPES	4
3	DESCRIPTION OF GENERAL FIELDS	5
4	FRAME TYPE DESCRIPTIONS	8
4.1	FRAME TYPE <MRM>, M-frame	8
4.2	FRAME TYPE <ACK>, Acknowledgement	10
4.3	FRAME TYPE <NAK>, Negative acknowledgement	11
4.4	FRAME TYPE <REB>, Repetition request	12
4.5	FRAME TYPE <RES>, Repetition reply	14
4.6	FRAME TYPE <ABD>, Access request, data	16
4.7	FRAME TYPE <ABT>, Access request, speech	17
4.8	FRAME TYPE <ABL>, Access request, emergency	18
4.9	FRAME TYPE <ATD>, Access permission, data	19
4.10	FRAME TYPE <ATT>, Access permission, speech	20
4.11	FRAME TYPE <ATL>, Access permission, emergency	21
4.12	FRAME TYPE <BKD>, Change channel, data	22
4.13	FRAME TYPE <BKT>, Change channel, speech	24
4.14	FRAME TYPE <FRI>, Free signal	26
4.15	FRAME TYPE <SVP>, Sweep signal	28
4.16	FRAME TYPE <TST>, Silence order	35
4.17	FRAME TYPE <AKT>, Activity request	36
4.18	FRAME TYPE <NAT>, No access permission, speech	37
4.19	FRAME TYPE <BET>, Change base station, speech	38
4.20	FRAME TYPE <VKT>, Wait for channel, speech	40
4.21	FRAME TYPE <AAT>, Cancel access request, speech	41
5	CONVERTING A PACKET TO A FRAME	42
6	BLOCK CODING	43
6.1	GENERAL DESCRIPTION	43
6.2	IMPLEMENTATION	43
7	MOBITEX TERMINAL SPECIFICATION REFERENCE LIST	44

Subject

Replaces

Cantel Mobitex

No. 91/1056 - A 296 5171/A2 Ue		
Drawn Date	Rev	File
1990-02-22	A	MTS16A.2

1 INTRODUCTION

1.1 GENERAL

The mobile terminal's Data Link Layer together with the Physical Layer form a radio protocol for communication between mobile stations (MOB) and a base radio station (BASE).

The interchange of information between BASE and MOB is in the form of frames. There are 21 different types of frames.

Buildings

Revised

A 296 5171

Cantel Mobitex

No. 91/1056 - A 296 5171/A2 Ue

Station Date 1990-02-22 Rev A File MTS16A.2

2 FRAME TYPES

There are 21 different frame types:

	<u>Name</u>	<u>Designation</u>	<u>Transmitted by</u>	
			<u>BASE</u>	<u>MOB</u>
1	M frame	<MRM>	Yes	Yes
2	Acknowledgement	<ACK>	Yes	Yes
3	Negative acknowledgement	<NAK>	Yes	Yes
4	Repetition request	<REB>	Yes	Yes
5	Repetition reply	<RES>	Yes	Yes
6	Access request, data	<ABD>	No	Yes
7	Access request, speech	<ABT>	No	Yes
8	Access request, emergency	<ABL>	No	Yes
9	Access permission, data	<ATD>	Yes	No
10	Access permission, speech	<ATT>	Yes	No
11	Access permission, emergency	<ATL>	Yes	No
12	Change channel, data	<BKD>	Yes	No
13	Change channel, speech	<BKT>	Yes	No
14	Free signal	<FRI>	Yes	No
15	Sweep signal	<SVP>	Yes	No
16	Silence order	<TST>	Yes	No
17	Activity request	<AKT>	Yes	No
18	No access permission, speech	<NAT>	Yes	No
19	Change base station, speech	<BBT>	Yes	No
20	Wait for channel, speech	<VKT>	Yes	No
21	Cancel access request, speech	<AAT>	No	Yes

Student

Revised

A 296 51553

Cantel Mobitex -

91/1056 - A 296 5171/A2 Ue
 1990-02-22 A MTS16A.2


3 DESCRIPTION OF GENERAL FIELDS

In this chapter the general fields of a frame are described. Fields occurring only in specific frame types are described in conjunction with the definition of the respective frame type.

The fields are described in the following order:

- 1 MOB address of mobile terminal, or group
- 2 TYPE type of frame
- 3 BLOCK number of blocks in the frame
- 4 PARITY check sum
- 5 MASK for masked addressing
- 6 PRIOR for priority addressing
- 7a UPFREQ frequency number, up frequency
- 7b DOWFREQ frequency number, down frequency
- 8 NUMRET number of retransmissions

The most significant bit lies to the left in the field, has the lowest order number and is sent and received first in time.



MOB states the address of the mobile unit concerned. This address refers to the terminal's own subscription number, or to any number representing a group to which the terminal belongs.

Bildzeit

Repro

Cantel Mobitex

91/1056 - A 296 5171/A2 Ue
 DATE: 1990-02-22
 Rev: A
 File: MTS16A.2

TYPE 01 02 03 04 05

TYPE

TYPE is bit 28-32 of the primary block and indicates the type of frame according to the following table:

Value		Type
Decimal	Binary	designation
01	00001	<MRM>
02	00010	<ACK>
03	00011	<NAK>
04	00100	<REB>
05	00101	<RES>
06	00110	<ABD>
07	00111	<ABT>
08	01000	<ABL>
09	01001	<ATD>
10	01010	<ATT>
11	01011	<ATL>
12	01100	<BKD>
13	01101	<BKT>
14	01110	<PRI>
15	01111	<SVP>
16	10000	<TST>
17	10001	<AKT>
18	10010	<NAT>
19	10011	<BBT>
20	10100	<VKT>
21	10101	<AAT>

BLOCK 01 02 03 04 05 06 07 08

BLOCK

States the number of blocks in the frame, including primary block.

PARITY 01 02 03 . . 14 15 16

PARITY

A frame comprises one or more blocks. A block comprises a source word and a coded parity word.

Builders

Revised

Cantel Mobitex

91/1056 - A 296 5171/A2 Ue

Current Date 1990-02-22 Rev A P. No. MTS16A.2

MASK 01 02 03 04 05

MASK

A group of terminals is addressed with masked addressing. The MASK states the number of most significant bits of the MOB address that should be ignored.

PRIO 01 02 03

PRIO

PRIO	Meaning
7 111	Priority group 4, raised priority
6 110	" " " " normal
5 101	Priority group 3, raised priority
4 100	" " " " normal
3 011	Priority group 2, raised priority
2 010	" " " " normal
1 001	Priority group 1, raised priority
0 000	" " " " normal

UPFREQ 01 02 03 04 12 13 14 15 16

UPFREQ

|<-FBI-->|<---- FREQ. NO. ----->|

DOFREQ 01 02 03 . . . 12 13 14 15 16

DOFREQ

States the frequency number, UPFREQ for transmit frequency and DOFREQ for receive frequency.

Bit 1 to 3 gives FBI (frequency band and bit rate INFORMATION) and bit 4 to 16 gives the frequency number. Both the parameters are defined in reference R1-06.

NUMRET 01 02 03 04 05 06 07 08

NUMRET

States the number of retransmissions, including the current try.

Buildout

Raycon

91/1056 - A 296 5171/A2 Ue		
Date Issd 1990-02-22	Rev A	F. File MTS16A.2

4.1 FRAME TYPE <MRM>, M-frame

An <MRM> is used to transfer packets. The packet format is defined in reference R1-09.

01	02	03		22	23	24	25	26	27	28	29	30	31	32		
MOB					RE		OCTET		0		0		0		1	
33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	
OCTET				SEQUENCE				BLOCK								
49	50	51	52	53	54										144	
							INFO									
145															160	
PARITY																

OCTET States the number of valid octets in the last following block. Remaining octets of the last block are filled with "0" to give a complete block. The field contains 6 bits and is used in the following way:

26 27 33 34 35 36

OCTET

SEQUENCE States the sequential number of the frame.

RE States whether a response is to be given
to the frame. The mobile terminal shall
always set this flag to "1" on
transmission.

INFO Contains 12 octets of source data from the packet.


Cantel Mobitex -

Se. No.	91/1056 - A 296 5171/A2 Ue
Creation Date	1990-02-22 A
File No.	MTS16A.2

FOLLOWING BLOCK

APPLICATION

The packet is placed in the following blocks with 18 octets from the packet in each. The number of valid octets in the last following block is indicated in the OCTET field of the primary block. The last following block is filled with "0" in the octets which do not belong to the packet.



INFO

Contains 18 octets of source data from the packet.

Block:

Report:

N° No		91/1056 - A 296 5171/A2 Ue	
Date	Rev	PA File	
1990-02-22	A	MTS16A.2	

APPLICATION An <ACK> acknowledges a correctly received frame.

<ACK> indicates that all blocks in the frame have been correctly received. It includes the sequential number of the received frame.

01	02	03		22	23	24	25	26	27	28	29	30	31	32											
MOB							0	0	0	0	0	0	1	0											
33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48										
0	0	0	0	SEQUENCE				BLOCK																	
49	50	51	52	53	54										144										
0	0	0	0	0	0	-----									0	0	0	0	0	0					
145																									160
PARITY																									

States the sequential number of the corresponding <MRM>-frame.

No following blocks in this type of frame.

91/1056 - A 296 5171/A2 Ue	
Date: 1990-02-22	Rev: A
File: MTS16A.2	

APPLICATION A <NAK> requests repetition of the entire <MRM>.

Note that if the number of blocks in <MRM> was 3 or more, <REB> is used instead of <NAK>.

01	02	03					22	23	24	25	26	27	28	29	30	31	32				
MOB										0	0	-0	0	0	0	1	1				
33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48						
0	0	0	0	SEQUENCE					BLOCK												
49	50	51	52	53	54												144				
0	0	0	0	0	0											0	0	0	0	0	0
145																	160				
PARITY																					

States the sequential number of the corresponding <MRM>-frame.

No following blocks in this type of frame.

Review

Cantel Mobitex

No. 91/1056 - A 296 5171/A2 Ue
 Date: 1990-02-22 Rev. A FC-Fds MTS16A.2

4.4 FRAME TYPE <REB>, Repetition request


APPLICATION A <REB> requests repetition of erroneous blocks in an <MRM>.

If it is found during reception that certain blocks in a frame cannot be corrected, a request for these blocks to be repeated can be made by transmitting a <REB>. The request contains a bit map of the blocks to be repeated. This bit map refers to the original <MRM>, even during a sequence of repetitions.

<REB> contains the sequential number of the received <MRM> primary block and results in a <RES>.

Note that if the number of blocks in <MRM> was 2 or less, <NAK> is used instead of <REB>.

PRIMARY BLOCK



01000001

00000000

Cantel Mobitex

No. 91/1056 - A 296 5171/A2 Ue
 System Date 1990-02-22 Rev A P. 1.1
 MTS16A.2

SEQUENCE

States the sequential number of the corresponding <MRM>-frame.

REPMAP

Contains a bit map where each bit represents a block in the <MRM> previously received. A bit set to "1" indicates that the corresponding block is to be repeated. The bit in a REPMAP representing the primary block shall always have the value "0", since repetition of the primary block is illegal.

FOLLOWING BLOCK

No following blocks in this type of frame.

Unidirect

Reproducible

A 292 5133Q

91/1056 - A 296 5171/A2 Ue		
Issue Date	Rev	File
1990-02-22	A	MTS16A.2

APPLICATION A <RES> is the reply to a <REB>.

<RES> is a selective repetition of blocks from an <MRM>. The following blocks of the <RES> contain copies of blocks according to the bit map of the <REB>. <RES> contains the sequential number of the original <MRM>.

01	02	03		22	23	24	25	26	27	28	29	30	31	32						
MOB							0	0	0	0	0	1	0	1						
33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48					
0	0	0	0	SEQUENCE				BLOCK												
49	50	51	52	53	54										144					
0	0	0	0	0	0										0	0	0	0	0	0
145														160						
PARITY																				

SEQUENCE States the sequential number of the corresponding <MRM>-frame.

Cantel Mobitex -

Doc No	91/1056 - A 296 5171/A2 Ue	
Doc Date	Rev	F. E.
1990-02-22	A	MTS16A.2

FOLLOWING BLOCK

APPLICATION The following blocks contain copies of blocks according to the bit map of the <REB>. Only blocks requested to be repeated shall be packed into the following blocks. The order of the blocks is that stated in REPMAP.

01	02	03	04	05	06	-----	144
REPBLOCK							

145	-----	160
PARITY		

REPBLOCK The copy of a block from the original <MRM>-frame.

Business

Reprod

A 592 61533

91/1056 - A 296 5171/A2 Ue		
Drawn Date	Rev	PC File
1990-02-22	A	MTS16A.2

APPLICATION An <ABD> is a request to transmit an <MRM> whose length (number of blocks) exceeds the value of MAX ACCESS.

If the length of the <MRM> exceeds MAX_ACCESS, access must be requested before the <MRM> may be sent.

The <ABD> states the number of blocks in the corresponding <MRM>.

[illegible]

BLOCK N States the number of blocks for
 which access is requested.

FOLLOWING BLOCK No following blocks in this type
of frame.

Baron

No. No	91/1056 - A 296	5171/A2 Ue
Drawn Date	1990-02-22	Rev A
		File File MTS16A.2

APPLICATION An <ABT> is a request to transmit an <MRM> containing a request for a line connection, whose length (number of blocks) exceeds the value of MAX SPEECH.

PRIMARY BLOCK

01	02	03											22	23	24	25	26	27	28	29	30	31	32								
MOB																0	0	0	0	0	1	1	1								
33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48																
BLOCK N																BLOCK															
49	50	51	52	53	54	55	56	57															144								
NUMRET																0						0	0	0							
145																160															
PARITY																															

States the number of blocks for which access is requested.

No following blocks in this type
of frame.

91/1056 - A 296 5171/A2 Ue

Printed Date	Rev	File Path
1990-02-22	A	MTS16A.2

APPLICATION BASE replies with an <ATT> to an <ABT>
from a MOB, when BASE is ready to accept
an <MRM>.

When permission is granted, MOB is expected to transmit an <MRM> containing a request for line connection.

01 02 03 22 23 24 25 26 27 28 29 30 31 32

MOB	0 0 0	0 1 0 1 0
-----	-------	-----------

33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48
0	0	0	0	0	0	0	0	0		BLOCK					

49 50 51 52 53 54 144

0 0 0 0 0 0 0 0 0 0 0 0

145 160

PARITY

No following blocks in this type
of frame.

91/1056 - A 296 5171/A2 Ue

System Date	Rev	File File
1990-02-22	A	MTS16A.2

APPLICATION BASE replies with an <ATL> to an <ABL>
from a MOB, when BASE is ready to accept
an <MRM>.

When permission is granted, MOB is expected to transmit an <MRM> containing an emergency signal.

	0	1	0	2	0	3						2	2	2	3	2	4		2	5	6	7	8	9	2	9	3	0	3	1	3	2												
																		MOB			0			0			0			0			1			0			1			1		
3	3	3	4	3	5	3	6	3	7	3	8	3	9	4	0	4	1	4	2	4	3	4	4	5	4	6	4	7	4	8														
0																		0			0			0			0			0			0			0			BLOCK					
4	9	5	0	5	1	5	2	5	3	5	4																1	4	4															
0												0			0			0			0			0			0			0			0			0								
PARITY																																												

No following blocks in this type
of frame.

No. No.		
91/1056 - A 296 5171/A2 Ue		
Date	Rev	Fl. File
1990-02-22	A	MTS16A.2

APPLICATION A <BKD> orders a MOB to another channel in order to transmit or receive an <MRM>.

The MOB usually returns to the original channel when the <MRM> has been transmitted or received. If an error occurs on the assigned channel then MOB returns to the original channel after a timeout period stated in the <BKD>.

01	02	03		22	23	24	25	26	27	28	29	30	31	32	
MOB							0 0 0			0 1 1 0 0					
33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48
0 0 0 0 0 0 0 0								BLOCK							
49				64	65					80	81				96
BKDFL				UPFREQ				DOFREQ							
97				104	105										144
TIMEOUT				0 0				0 0 0 0 0							
145												160			
PARITY															

Back of

Cantel Mobitex

91/1056 - A 296 5171/A2 Ue
 1990-02-22 A MTS16A.2

BRDFL Indicates how the terminal is to act on the new channel.

- Bit 1 Reserved
- 2 Reserved
- 3 Reserved
- 4 Change to send <MRM>
- 5 Change to receive <MRM>
- 6..16 Reserved

UPFREQ Frequency number for up frequency, i.e. the frequency on which the terminal transmits.

DOFREQ Frequency number of down frequency, i.e. the frequency on which BASE transmits.

TIMEOUT If error, return after TIMEOUT seconds (1-255).

FOLLOWING BLOCK No following blocks in this type of frame.

Bid Kart

Tagron

A 296 5171

№ №
91/1056 - А 296 5171/А2 Пс

1990-02-22

Rev
A

File Name
MTS16A.2

APPLICATION A <BKT> orders a MOB to another channel in order to transmit or receive an <MRM> containing a request for line connection.

Normally the terminal returns to the original channel when the line connection is over. If an error occurs on the assigned channel then MOB returns to the original channel after a timeout period stated in the <BKT>..

01	02	03		22	23	24	25	26	27	28	29	30	31	32
MOB							0	0	0	0	1	1	0	1

33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48
0	0	0	0	SEQUENCE				BLOCK							

97	104	105					144
TIMEOUT	.0	0			0.0	0	0

145 _____ 160
PARITY

Revisors

Revised

Cantel Mobitex

No.	91/1056 - A 296 5171/A2 Ue
Creation Date	1990-02-22
Rev	A
File Name	MTS16A.2

SEQUENCE Only valid if BKTFL bit 6 is TRUE.

BKTFL Indicates how the terminal is to act on the new channel.

- | | |
|-------|---|
| Bit 1 | Reserved |
| 2 | Reserved |
| 3 | Reserved |
| 4 | Change to send <MRM> |
| 5 | Change to receive <MRM> |
| 6 | Acknowledgement (including sequence number) of correctly received speech <MRM>. Ignore timeout. |
| 7..16 | Reserved |

UPFREQ Frequency number for up frequency, i.e. the frequency on which the terminal transmits.

DOFREQ Frequency number of down frequency, i.e. the frequency on which BASE transmits.

TIMEOUT If error, return after TIMEOUT seconds (1-255).

FOLLOWING BLOCK

No following blocks in this type of frame.

Blockout

Blockout

A 296 5171/A2

№ 246		
91/1056 - A 296 5171/A2 Use		
Датум. Док.	Rev	Ed. File
1990-02-22	A	MTS16A.2

APPLICATION BASE transmits a <FR1> when it is ready to handle traffic from MOB.

PRIMARY BLOCK

[illegible]

Bridging

~~Secret~~

Cantel Mobitex

SF No
91/1056 - A 296 5171/A2 Ue
Date Recd Date Recd
1990-02-22 A MTS16A.2

FFG The FFG field states the type of traffic to which the free signal applies according to the following table.

Value	Emergency	Speech	Data
00	yes	no	no
01	yes	no	yes
10	yes	yes	no
11	yes	yes	yes

RAND_SLOTS The maximum number of the random number generator which selects in which slot the transmission shall start.

FREE_SLOTS The number of free slots in this free cycle.

MAX_ACCESS States the number of blocks which may be sent in an <MRM> without being preceded by an access request.

SLOT_LENGTH Current value of slot_length.

MAX_SPEECH States the number of blocks which may be sent in a line connection request without being preceded by an access request.

FOLLOWING BLOCK No following blocks in this type of frame.

Wdskans

Reprod

A 292 51513

Cantel Mobitex

Doc No	91/1056 - A 296 5171/A2 Use
Doc Date	1990-02-22 A
Doc Rev	MTS16A.2

4.15 FRAME TYPE <SVP>, Sweep signal

APPLICATION

The sweep signal is a periodically recurring signal from BASE. An <SVP> is transmitted by BASE for two reasons:

- 1 <SVP> marks the start of a sweep cycle.
- 2 <SVP> contains system parameters.

<SVP> has 2 different subtypes:

- 1 states the values of system parameters
- 2 states the frequency of different channel types

Blanket

Reprod

A 292 51533

№ №	91/1056 - A 296 5171/A2 Ue
-----	----------------------------

Date	1990-02-22	Rev	A
------	------------	-----	---

File #
MTS16A.2

- states the values of system parameters.

[illegible]

Siddhant

डेपुटी

Cantel Mobitex -

No.	91/1056 - A 296 5171/A2 Ue
Revision	1990-02-22 A
File No.	MTS16A.2

SVPTYP	States the <SVP> subtype, value 00000001 in this case.
TXPOW	States the decrease in output power (0-255 dB below nominal level) to be used by the mobile. A default value of 0 is used until this signal is received.
RSSI_PROC	States the method of the signal strength measurement: 0 = FRAME 1 = CONTINUOUS The default value is FRAME.
RSSI_PERIOD	Time used by the roaming algorithm (0-255 *20 ms). Default value: 148 (2 960 ms).
TIME_TO_NEXT	States the time in seconds to the next <SVP> frame. Default value: 10.
MAX_REP	States the value of the variable Max_rep.
BASEST	States status of base station.
SCAN_TIME	States the length of a period (0-255 *100 ms) when the terminal scans other system channels. Default value: 30 (3 seconds).
BAD_BASE	Used by the roaming algorithm. 0-255 dBuV. Default value: 15.
GOOD_BASE	Used by the roaming algorithm. 0-255 dBuV. Default value: 15.
BETTER_BASE	Used by the roaming algorithm. 0-255 dB. Default value: 10.

Most of the parameters above are further described in the MAIN DOCUMENT.

Billhart

Reprod

A 296 51550

Cantel Mobitex

Sr. No.
91/1056 - A 296 5171/A2 Ue
Contract Date
1990-02-22 A
F. No.
MTS16A.2

FOLLOWING BLOCKS

If any, they contain a list of system channels to be used in base station monitoring. A frame with a list containing new system channels completely overrides the previous frame. The channel list has the following format (as described in the MAIN DOCUMENT):

FOLLOWING BLOCK #1

01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16
number of channels									0	0	0	0	0	0	0
17								32	33						48
channel #1 - UPFREQ									channel #1 - DOFREQ						
49								64	65						80
channel #2 - UPFREQ									channel #2 - DOFREQ						
81								96	97						112
channel #3 - UPFREQ									channel #3 - DOFREQ						
113								128	129						144
channel #4 - UPFREQ									channel #4 - DOFREQ						
145															160
PARITY															

The number of following blocks depends on the size of the list. The maximum number of channels in the list is stated in reference RI-06.

Continues with following block #2 on the next page.

Bidder

Reprod

A 292 5155G

Cantel Mobitex

Doc No 91/1056 - A 296 5171/A2 Ue
 Design Date 1990-02-22 Rev A PC File MTS16A.2

FOLLOWING BLOCK #2

01	16 17	32
channel #5 - UPFREQ	channel #5 - DOPREQ	
33	48 49	64
channel #6 - UPFREQ	channel #6 - DOPREQ	
129	144 145	160
channel #9 - UPFREQ	PARITY	

FOLLOWING BLOCK #3

01	16 17	32
channel #9 - DOPREQ	channel #10 - UPFREQ	
33	48 49	64
channel #10 - DOPREQ	channel #11 - UPFREQ	

etc.

Bidder

Repro

No. No		
91/1056 - A 296 5171/A2 Ue		
Datum Date	Rev	File File
1990-02-22	A	MTS16A.2

- states the frequency of different channel types.

01 02 03 22 23 24 25 26 27 28 29 30 31 32

MOEPRIC

MASK

BLOCK

SYNOPSIS

CHATYP

UPFREQ

DOFREQ

0 0 0 0 0 0

0 0 0 0 0 0PARITY

Received

Cantel Mobitex

Sr. No.	91/1056 - A 296 5171/A2 Ue	
Issued Date	1990-02-22	Rev. No. A
Rev. No.	MTS16A.2	

SVPTYP States the <SVP> subtype, value 00000010 in this case.

CHTYP States the type of channel:

Value:

- 1 Local system channel opened
- 2 Not used (ignore that order)
- 3 Local system channel closed (return to national system channel)
- 4 Access channel opened
- 5 Access channel closed

UPFREQ Frequency number for up frequency, i.e. the frequency on which the terminal transmits.

DOFREQ Frequency number for down frequency, i.e. the frequency on which BASE transmits.

FOLLOWING BLOCK

No following blocks in this type of frame.

Bidkart

Reproel

A 092 51530

91/1056 - A 296 5171/A2 Ue		
Date	Rev	File No
1990-02-22	A	MTS16A.2

APPLICATION

Note: Please also refer to the description of the silence signal in reference RI-17. This signal has the same meaning as the <TST>-frame but uses only the frame head and thus addresses ALL mobile terminals.

[illegible]

No following blocks in this type
of frame.

Nr. No			91/1056 - A 296 5171/A2 Ue		
Datum		Bew		Fi. Pl.	
1990-02-22		A		MTS16A.2	

APPLICATION An <AKT> is used by BASE to check whether a certain MOB is active. MOB replies with an <ACK> to such a frame.

01	02	03		22	23	24	25	26	27	28	29	30	31	32				
MOB								0	0	0	1	0	0	0	1			
33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48			
0	0	0	0	0	0	0	0	BLOCK										
49	50	51	52	53	54										144			
0	0	0	0	0	0	0								0	0	0	0	0
145															160			
PARITY																		

No following blocks in this type
of frame.

91/1056 - A 296 5171/A2 Ue

Design Date	Rev	P. P. 4
1990-02-22	A	MTS16A.2

APPLICATION **BASE** replies with <NAT> to an <ABT> or a line connection request from a MOB when, for some reason, a line connection cannot be set up (e.g. no channel is available).

01	02	03				22	23	24	25	26	27	28	29	30	31	32
MOB									0	0	0	1	0	0	1	0
33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	
0	0	0	0	0	0	0	0	BLOCK								
49	50	51	52	53	54	55	56	57	144							
NATFL									0	0 0 0						
145																160
PARITY																

Contains the following orders:
Leave CURRENT_BASE.
Reserved

No following blocks in this type
of frame.

Nr. Na		
91/1056 - A 296 5171/A2 Ue		
Detain Date	Rev	PS File
1990-02-22	A	MTS16A.2

APPLICATION

- BASE will use <BBT>
 - as a response to an <ABT> when another base station is to be used for the line connection
- or
- to hand over a call in progress to another base station.

[illegible]

Cantel Mobitex

Dr No	91/1056 - A 296 5171/A2 Ue
Issue Date	1990-02-22
Rev	A
F. No	MTSL6A.2

TIMEOUT If error, return after TIMEOUT seconds (1-255).

BBTFL Indicates the terminal is to act after changing to the new base station.

- Bit 49 Reserved
- 50 Reserved
- 51 After the call, use BASE as new current base station.
- 52 After the call, return to old current base.
- 53 Change and start the call set up procedure from the beginning (new <ABT> on BASE).
- 54 Change and continue (either signalling procedure or call in progress).
- 55-64 Reserved

BASE The identity of the new base station to be used.

SPEECH UPFREQ Frequency number for transmitting speech.

SPEECH DOFREQ Frequency number for receiving speech.

NEW SYSTEM UPFREQ Frequency number for upwards traffic on the new system channel, i.e. the frequency on which the terminal transmits.

NEW SYSTEM DOFREQ Frequency number for downwards traffic on the new system channel, i.e. the frequency on which the terminal receives.

FOLLOWING BLOCK No following blocks in this type of frame.

This order is only valid if both BBTFL 3 and BBTFL 6 are raised, i.e. hand over of a call in progress.

Other combinations of BBTFL are to be included in later versions.

Signature

Reprod

Cantel Mobitex -

91/1056 - A 296 5171/A2 Ue

Date Recd	Rev	File No
1990-02-22	A	MTS16A.2

4.20 FRAME TYPE <VKT>, Wait for channel, speech

APPLICATION BASE replies with one (or more) <VKT>-frame(s) to an <ABT> from a MOB when a speech channel is not immediately available.

PRIMARY BLOCK

01	02	03		22	23	24	25	26	27	28	29	30	31	32
MOB							0	0	0	1	0	1	0	0

[illegible]

49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64
TIMEOUT								QPOS							

145 160

PARITY

TIMEOUT If the mobile terminal has not received a <BKT> or a <NAT> within TIMEOUT seconds (0-255), the <VKT> is invalidated.

QPOS States current position (1-255) in queue.
It is recommended that this parameter is
passed on to the application layer and
shown to the operator.

FOLLOWING BLOCK No following blocks in this type
of frame.

Subsists

Region

91/1056 - A 296 5171/A2 Ue		
Drawn Date	Rev	PC File
1990-02-22	A	MTS16A.2

APPLICATION MOB transmits an <AAT> when it wants to
end a call and has been placed in a queue
by BASE.

01	02	03		22	23	24	25	26	27	28	29	30	31	32	
MOB							0	0	0	1	0	1	0	1	
33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48
0	0	0	0	0	0	0	0	BLOCK							
49	50	51	52	53	54	55	56	57	144						
0	0	0	0	0	0	0	0	0	0 0 0						
145								160							
PARITY															

No following blocks in this type
of frame.

Cantel Mobitex

Std. No.
91/1056 - A 296 5171/A2 Ue


Issued Date
1990-02-22

Rev
A

File File
MTS16A.2

5 CONVERTING A PACKET TO A FRAME

<MRM>-frames conveys MPAKs over the radio channel. The primary block can accomodate 12 and each following block 18 octets from the MPAK.



When converting a packet to a frame, the first 12 octets in the packet shall be placed in the primary block of the frame. The last octets of the packet are placed in the last block. The primary block indicates how many octets in the last following block that are used. Unused octets in the last following block are filled with octets containing zeros.

In the primary block of the <MRM>-frame the Link Layer information is added. The MOB address field of the primary block shall always contain the MAN of the physical terminal concerned or, when the base station is transmitting to a group, the MAN of the addressed group. The base station identity is contained in the frame head preceding the primary block.

The addresses in the MPAK itself indicates the sub-
scriptions concerned (terminal, transferable or group). For packets to/from the terminal itself or its group numbers, the MOB address field of the primary block and the address in the MPAK are the same. For packets to/from a transferred subscription, the corresponding addresses differ.

Boldfaced

Reprova

A 296 51533

Cantel Mobitex

Doc. No.	91/1056 - A 296 5171/A2 Ue
Date	1990-02-22 A
Rev.	MTS16A.2

6 BLOCK CODING

6.1 GENERAL DESCRIPTION

The code used is a cyclic block code for burst error control. The code message consists of 144 source data bits and a block check character (CRC, i.e. parity) of 16 bits, giving a total of 160 bits in a block.

The generator polynomial defining the code is

$$g(X) = X^{16} + X^{12} + X^5 + 1$$

i.e. CRC-CCITT X.25.

The CRC is initialized to all ones, calculated from all the 144 source data bits of the block and then its one's complement is transmitted.

This code detects all (single) error bursts up to 16 bits in length and about 99,998% of all other error patterns.

6.2 IMPLEMENTATION

CRC calculations are customarily done in a multi-section shift register which feeds into an exclusive-OR gate whose output feeds back to other XOR gates located in between the sections of the shift register. The placement and quantity of XOR gates are defined by the generator polynomial.

The CRC is then transmitted after the source data of the block.

A logical arrangement identical to that used in the transmitter is also used in the receiver. Again the CRC-register is initialized to all ones, the CRC is calculated from the 144 source bits and its one's complement is compared to the received CRC. If these are different an error has been detected.

Instead of hardware logic a software algorithm may be used.

Block

Report

A 296 5150.3

Cantel Mobitex

No. 51	91/1056 - A 296 5171/A2 Ue	
Issue Date	Rev	P. F.
1990-02-22	A	MTS16A.2

7 MOBITEK TERMINAL SPECIFICATION REFERENCE LIST

This document includes a number of references, made to other sections in the terminal specification. The list below shows these references, together with the page(s) they are made on. Please note that a section could be referred to several times on the same page.

R1-06, 7, 31
R1-09, 8
R1-17, 35

Below are the reference designations listed.

<u>Reference</u>	<u>Section</u>
R1-01	Arrangement of the documents
R1-02	MOBITEK System description
R1-03	General description of terminals
R1-04	Terminology
R1-05	References
R1-06	Network operator information
R1-08	Application layer
R1-09	Network layer
R1-11	Interface requirements, fixed terminals
R1-12	Other requirements, fixed terminals
R1-16	Link layer, mobile terminals
R1-17	Physical layer, mobile terminals
R1-18	Radio equipment, mobile terminals
R1-19	Other interfaces, mobile terminals
R1-20	Other requirements, mobile terminals

Blanket

Reprod

A 292 5153G

System Program ET/SYS IK	Functional requirements ET/SYS IK	No. 1 10/1056 - A 296 5171/02 Ue
Software location. Doc. responsible ET/SYSC STR <i>ST</i>	System Date 1990-02-26 A	P. No. MTSL7.2
Description Cantel Mobitex™		Title MOBITEX Physical Layer, Mobile Terminal 8/16 kbps
<p>ABSTRACT</p> <p>This document specifies the Physical Layer for mobile terminals connected to the MOBITEX network.</p> <p>The exchange of information between base radio station and mobile is done by frames. A frame consists of a frame head and blocks.</p> <p>The frame head is added to the message sent by the Data Link Layer to establish synchronisation and identify the base station. It also includes a set of control flags.</p> <p>The blocks in a frame contain the data to/from the Data Link Layer plus parity bits for error correction.</p>		
<p>Braden</p> <p>Reyes</p>		

Cantel Mobitex-

Nr. 56	10/1056 - A 296 5171/02 Ue
Version - Date	Rev.
1990-02-26	A
Ft. F. a MTSL7.2	

TABLE OF CONTENTS

1	INTRODUCTION	3
1.1	GENERAL	3
2	THE CHANNEL	4
2.1	GENERAL CHARACTERISTICS	4
2.2	FRAME STRUCTURE	4
3	THE FRAME HEAD	5
3.1	STRUCTURE	5
3.2	SYNCHRONISATION	6
3.2.1	Bit synchronisation	6
3.2.2	Frame synchronisation	6
3.3	AREA IDENTITY, BASE IDENTITY AND CONTROL FLAGS ...	7
4	ERROR CORRECTION AND DETECTION	8
4.1	CODING	8
4.2	INTERLEAVING AND SCRAMBLING	10
5	TIME DIVISION	12
6	TRANSMISSION	13
7	RECEPTION	14
8	INTERFACE TO THE DATA LINK LAYER	15
9	MOBITEX TERMINAL SPECIFICATION REFERENCE LIST	16

Booklet

Revised

Cantel Mobitex

No. 10/1056 - A 296 5171/02 Ue	
Issue Date 1990-02-26	Rev. A MTS17.2

1 INTRODUCTION

1.1 GENERAL

The protocol in the Physical Layer describes the way the mobile terminal handles the radio channel. The logical structure of the protocol is described in this document, while hardware-related functions such as:

- method of modulation
- suitable equipment for implementation
- requirements for the equipment

are presented in reference R1-18.

Balken

Regend

A 296 51532

Cantel Mobitex

No. 30	10/1056 - A 296 5171/02 Ue
Document Date	1990-02-26
Rev	A
Pt. 1 of	MTS17.2

2 THE CHANNEL

2.1 GENERAL CHARACTERISTICS

The channel between the base radio station and the mobile terminal uses

- separate frequencies for transmission and reception,
- synchronous communication and
- frequency modulation (FM).

It is also affected by

- varying field-strength,
- random errors and burst errors caused by fading and noise and
- bit errors caused by ignition interference.

Consideration has been given to these and other factors in the design of the protocol for the Physical Layer.

2.2 FRAME STRUCTURE

The exchange of information between base station and mobile is done by frames. A frame has the following structure:

Frame head	Block #1	Block #2	...	Block #n
------------	----------	----------	-----	----------

The frame head is a very important part of the frame. It is added to the message sent by the Data Link Layer to establish synchronisation and identify the base radio station.

The blocks in a frame contain the data to/from the Data Link Layer plus parity bits for error correction.

When the number of blocks is zero, i.e. when only a frame head is sent, the term "signal" is used.

Blanket

Report

A 19751533

Cantel Mobitex

No. 20
10/1056 - A 296 5171/02 Ue
Date 1990-02-26 Rev A P. 17.2
MTS17.2

3 THE FRAME HEAD

3.1 STRUCTURE

The frame head has the following structure:

01 02 03 04 05 06 07 08 09 10 11 12 13 14 15 16

BIT SYNCHRONISATION

17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32

FRAME SYNCHRONISATION

33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48

BASE IDENTITY

AREA IDENTITY

CTRL FLAGS

49 50 51 52 53 54 55 56

PARITY BITS

The different parts of the frame head are described in the following chapters.

Bidkast

Reprod

A 5115132

Cantel Mobitex

Rev No
10/1056 - A 296 5171/02 Ue
Revision Date
1990-02-26 A
Rev No
MTS17.2

3.2 SYNCHRONISATION

3.2.1 Bit synchronisation

This preamble is provided to enable bit synchronisation in the demodulator. It consists of 16 bits with the following pattern (bit #1 is sent first):

01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16	
1	1	0	0	1	1	0	0	1	1	0	0	1	1	0	0	from BASE
0	0	1	1	0	0	1	1	0	0	1	1	0	0	1	1	from MOB

3.2.2 Frame synchronisation

The frame synchronisation is provided to establish correct code word framing. Each network has its own pattern, used as network identification number, defined in reference R1-06. In order to roam into base radio stations in other networks, it should be possible to manually change the frame synchronisation word from the application layer.

It consists of 16 bits with the following structure, with bit #1 sent first:

01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16	
X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	from BASE
X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	from MOB

If there is more than 1 bit error in the detected pattern, then frame sync is not established.

NOTE Only these 16 bits are used for frame synchronisation.

Disshort

Reprod

A 020 51530

Cantel Mobitex™

Doc No: 10/1056 - A 296 5171/02 Ue
 Date: 1990-02-26 Rev: A File: MTS17.2

3.3 AREA IDENTITY, BASE IDENTITY AND CONTROL FLAGS

The base identity (6 bits) and the area identity (6 bits) together, states the unique identity of the base radio station concerned. The most significant bit (01) in the addresses is sent first.

The base identity is followed by four control flags. They are only used in traffic from BASE to MOB. The control flags are as follows (in order of reception):

- 1 SA_flag Reserved for future use.
- 2 Set_slot_flag 0 = FALSE
1 = TRUE, reset slot clock.
- 3 Roaming_flag 0 = FALSE
1 = TRUE, this is a roaming signal, i.e. it contains only a frame head.
- 4 Silence_flag 0 = FALSE
1 = TRUE, this is a silence signal, i.e. it contains only a frame head.

01 02 03 04 05 06 07 08 09 10 11 12 13 14 15 16

BASE IDENTITY	AREA IDENTITY	CTRL FLAGS
---------------	---------------	------------

octet #1 octet #2

parity #1 parity #2

PARITY
17 18 19 20 21 22 23 24

The 8 (2*4) parity bits that follow the control flags are encoded in the same way as the blocks of the frame. Parity #1 is coded from octet #1 (see figure above) and parity #2 from octet #2.

The code corrects all single errors. In case the frame head could not be corrected, it should be rejected.

The parity bits may be ignored and the base identity and control flags read without any decoding.

Blockers

Repeat

Cantel Mobitex

SP. No. 10/1056 - A 296 5171/02 Ue
 Date Issued 1990-02-26 Rev. A P. P. 2
 MTS17.2

4 ERROR CORRECTION AND DETECTION

4.1 CODING

Each block to/from the Data Link Layer contains 20 octets of information. These are put into a matrix of the following format:

column -- 1 2 3 4 5 6 7 8 9 10 11 12 .

row 1	octet #1	parity
2	octet #2	
20	octet #20	

To each octet (column 1-8) four parity bits are added in the same row (9-12). These are encoded by a shortened (12,8) Hamming code.

The code corrects all single errors with hard decision decoding.

The code is defined by the following H-matrix:

$$H = \begin{bmatrix} 11101100 & 1000 \\ 11010011 & 0100 \\ 10111010 & 0010 \\ 01110101 & 0001 \end{bmatrix}$$

The syndrome (s) is calculated from the received code word (v) by

$$s = vH^T$$

where H^T denotes the transposed H-matrix.

Bothert

Repro

A 296 5153-3

Cantel Mobitex

10/1056 - A 296 5171/02 Use

Serial Date 1990-02-26 Rev. A File MTS17.2

The syndrome of a code word with a single error is equal to the column vector of the H-matrix corresponding to the position of this error. The syndrome table is shown below.

syndrome	corresponds to a single error in bit position
0	-
1	0000 0000 0001
2	0000 0000 0010
3	-
4	0000 0000 0100
5	0000 0001 0000
6	0000 0010 0000
7	0001 0000 0000
8	0000 0000 1000
9	0000 0100 0000
10	0000 1000 0000
11	0010 0000 0000
12	-
13	0100 0000 0000
14	1000 0000 0000
15	-

If the syndrome is 0 the code word is correct.

The following examples illustrate the coding/decoding procedure:

transmitted info	parity	received info	parity	syndrome
0000 0001	0101	0000 0001	0101	0000
0000 0101	1100	0101 0101	1100	1010
0000 0010	0110	0010 0010	0110	1011
0000 0101	1100	0000 1111	1100	1100

Block:

Pages:

Cantel Mobitex

Doc No. 10/1056 - A 296 5171/02 Ue
 Series Date 1990-02-26 Rev A F. No. MTS17.2

4.2 INTERLEAVING AND SCRAMBLING

Before transmission the code is interleaved to give protection against burst errors. The block-matrix is sent columnwise with start at position (1,1) and is received in the same way.

column -- 1 2 3 4 5 6 7 8 9 10 11 12

row 1	octet #1	parity
2	octet #2	
20	octet #20	

The code without interleaving can correct single errors. The interleaved code can thus correct a burst of 20 errors, assuming that there is no other error in the same block.

Scrambling

At transmission and reception the bits following the frame head should be added modulo-2 (exclusive-ored) with the output from the ninth stage of a binary nine-stage shift register.

The outputs of the fifth and ninth stage of the shift register should be added modulo-2 and the result fed back to the input of the first stage.

All bits in the shift register should be sent to the logical value 1 upon initialization for reception or transmission.

That is, the bits following the frame head will be exclusive-ored with the sequence:

11111111000001111011111000101...., etc.

This scrambling sequence is the recommended test sequence described in CCITT recommendation V.52, as well as the shift register on the next page.

Note: It should be possible, via a test command in MASC (reference R1-19), to order the mobile to start/stop sending the above described scrambling sequence. This should only be possible during test, not during normal operation.

Bilskart

Reprod

Cantel Mobitex

No. 10/1056 - A 296 5171/02 Ue
 System Date 1990-02-26 Rev. A File No. MTS17.2

Shift register stages during pseudo-random pattern generation.

1	2	3	4	5	6	7	8	9	Out
1	1	1	1	1	1	1	1	1	1
0	1	1	1	1	1	1	1	1	1
0	0	1	1	1	1	1	1	1	1
0	0	0	1	1	1	1	1	1	1
0	0	0	0	1	1	1	1	1	1
0	0	0	0	0	1	1	1	1	1
1	0	0	0	0	0	1	1	1	1
1	1	0	0	0	0	0	1	1	1
1	1	1	0	0	0	0	0	1	1
1	1	1	1	0	0	0	0	0	0
0	1	1	1	1	0	0	0	0	0
1	0	1	1	1	1	0	0	0	0
1	1	0	1	1	1	1	0	0	0
1	1	1	0	1	1	1	1	0	0
1	1	1	1	0	1	1	1	1	1

Burkart

Haynes


A 292 51502

Cantel Mobitex


No. 10/1056 - A 296 5171/02 Ue
 Date 1990-02-26 Rev A P. 1.1
 MTS17.2

5 TIME DIVISION

The time axis is divided into slots. The length (L) of one of these slots is given by the parameter Slot_length.



The mobile keeps a clock going to be able to detect slot boundaries. The start (t1) of the first slot in a sequence is defined by BASE transmitting a frame head with a Set_slot_flag.



The first bit of the frame head is received at time t0. Slot number n starts at:

$$t = t1 + (n-1)*L$$

where

$$L = \text{Slot_length} * (32/\text{bitrate}) \text{ seconds}$$

$$n = 1..x$$

The tolerance for determining the start of a slot is $-0.1/3 \text{ ms}$.

Bildart:

Repro:

Cantel Mobitex

Nr. 10/1056 - A 296 5171/02 Ue		
Decision Date	Rev	File
1990-02-26	A	MTS17.2

6 TRANSMISSION

When an order to transmit a frame (FRAME_TO_SEND) has come from the Data Link Layer, the Physical Layer first waits until the slot clock reaches the CHOSEN_SLOT (please also refer to chapter 8) before it:

- indicates SLOT_REACHED to the Data Link Layer
- switches the carrier on
- waits until carrier frequency and power has stabilized
- waits 5 ms (tolerance -0/+5 ms)
- sends frame head with base and area identity (from Current_base) and all control flags = 0 (i.e. FALSE)
- encodes and sends all blocks of the frame

before it switches the carrier off and indicates FRAME_SENT to the Data Link Layer. If the order CANNOT_SEND comes from the Data Link Layer before the CHOSEN_SLOT is reached, then the transmission will not be started.

Bildtext

Reprod.

A 292 51552

Cantel Mobitex

St. No.	10/1056 - A 296 5171/02 Ue
Issue Date	1990-02-26 A
Rev.	MTS17.2

7 RECEPTION

The following takes place when correct bit and frame synchronisation has been established:

```

get average signal strength during reception of
frame head *)
send Received base to Data Link Layer
IF received Base = Current_base THEN
  IF Silence_flag THEN
    send Silence to Data Link Layer
  ELSE
    IF Set_slot_flag THEN
      reset_slot_clock
    ENDIF
  REPEAT
    read block
    decode block
    send Received_block to Data Link Layer
  UNTIL Sync_search
ENDIF
ENDIF

```

On reception of the order Measure RSSI from the Data Link Layer, the average signal strength *) is measured during the time stated in the order. Thereafter an answer, RSSI_measured, is sent to the Data Link Layer.

*) The RSSI should be sampled with a frequency of 1000 samples per second.

Block

Repeat

A 296 5133d

Cantel Mobitex

No. 10/1056 - A 296 5171/02 Ue
 Date 1990-02-26 A P. 17.2
 MTS17.2

8 INTERFACE TO THE DATA LINK LAYER

Parameters received from the Data Link Layer:

- Slot_length - states the length of a single slot. The unit is (32/bitrate) seconds.
- Chosen_slot - states the slot where transmission starts.
- Current_base - states which base radio station is currently used (base and area identity).
- Frame_to_send - is a message consisting of at least one block.
- Frame_length - states the number of blocks in message.
- Sync_search - orders the Physical Layer to stop reading and enter sync search mode.
- Cannot_send - orders the Physical Layer not to send in any slot.
- Measure_RSSI - orders the Physical Layer to measure the average received signal strength, during the time stated in the order.

Parameters sent to the Data Link Layer:

- Frame_sent - indicates that a frame transmission is completed.
- Received_block - is a decoded block (w error indication).
- Received_base - states the base identity, area identity and the received signal strength in dBuV.
- Silence - indicates that we have received a silence signal.
- Slot_reached - indicates the start of the Chosen_slot.
- RSSI_Measured - the average received signal strength, during in order Measure_RSSI stated time.

Sliders

Buttons

Cantel Mobitex

Doc No
10/1056 - A 296 5171/02 Use
Revised Date
1990-02-26 A
Rev
MTS17.2

9 MOBITEK TERMINAL SPECIFICATION REFERENCE LIST

This document includes a number of references, made to other sections in the terminal specification. The list below shows these references, together with the page(s) they are made on. Please note that a section could be referred to several times on the same page.

R1-06, 6
R1-18, 3
R1-19, 10

Below are the reference designations listed.

Reference	Section
R1-01	Arrangement of the documents
R1-02	MOBITEK System description
R1-03	General description of terminals
R1-04	Terminology
R1-05	References
R1-06	Network operator information
R1-08	Application layer
R1-09	Network layer
R1-11	Interface requirements, fixed terminals
R1-12	Other requirements, fixed terminals
R1-16	Link layer, mobile terminals
R1-17	Physical layer, mobile terminals
R1-18	Radio equipment, mobile terminals
R1-19	Other interfaces, mobile terminals
R1-20	Other requirements, mobile terminals

Blanket

Pages

A 292 5153G

REQUIREMENT SPECIFICATION 1(21)

Original Form ET/UC SIS	Functional Requirements ET/UC SIS	No. 1056 - A 296 5173/04 Ue	
Drawings/Tables/Optional Additions ET/SVSC STT <i>57</i>		Drawn Date 1990-02-25 A	Rev. No. MTS18.2
Description Cantel Mobitex		Title MOBITEX Mobile radio equipment 8 kbit/s, 12.5 kHz channel spacing	

ABSTRACT

This document specifies the requirements for the radio transmitter and receiver in the MOBITEX MOBILE TERMINAL.

The document contains a functional description and a detailed specification of the technical requirements and performance of the transmitter and receiver.

The equipment specified in this document should also meet with basic requirements set up in national regulations for radio transmitters and radio receivers.

Environmental, power supply and operational control requirements are found in the document General Requirements for the Mobile Terminal.

Bilskort

Reprint

A 292 51532

Cantel Mobitex

No. 1056 - A 296 5173/04 Ue
 Date: 1990-02-25 Rev. A P. 1.1
 MTS18.2

TABLE OF CONTENTS

1	INTRODUCTION	4
1.1	GENERAL	4
2	FUNCTIONAL DESCRIPTION	5
2.1	DATA TRANSMISSION	5
2.2	SPEECH TRANSMISSION	6
2.3	TRANSMITTER CONTROL	6
2.3.1	Frequency	6
2.3.2	Carrier	6
2.3.3	Audio muting	6
2.4	RECEIVER CONTROL	7
2.4.1	Frequency	7
2.4.2	Squelch control	7
2.4.3	Signal strength indication	7
2.4.4	Audio muting	7
3	PERFORMANCE AND TECHNICAL REQUIREMENTS	8
3.1	GENERAL	8
3.1.1	Frequency range	8
3.1.2	Frequency error	8
3.1.3	Data transmission	9
3.1.3.1	Modulator	9
3.1.3.2	Demodulator	11
3.1.3.3	Start of data modulation	12
3.1.3.4	Receive/transmit switching times	12
3.1.4	Test terminals	12
3.1.5	Test modulation	12
3.2	TRANSMITTER	13
3.2.1	Carrier power	13
3.2.2	Carrier rise and fall time	14
3.2.3	Channel switching time	14
3.2.4	Frequency deviation	14
3.2.4.1	Maximum permissible deviation	14
3.2.4.2	Data modulation	14
3.2.4.3	Audio modulation	14
3.2.4.4	Audio frequency response	14
3.2.5	Adjacent channel power	15
3.2.6	Harmonic distortion	15
3.2.7	Residual modulation	15
3.2.8	Modulation due to vibration	16
3.2.9	Audio muting	16
3.3	RECEIVER	17
3.3.1	Channel switching time	17
3.3.2	Squelch opening and closing levels and delays	17
3.3.3	Signal strength indication	17
3.3.4	RF sensitivity	17
3.3.5	Adjacent channel selectivity	18

Editors:

Revised:

Cantel Mobitex -

Doc No: 1056 - A 296 5173/04 Ue
 Creation Date: 1990-02-25 I Rev: A F. File: MTS18.2

3.3.6	Spurious response rejection	18
3.3.7	Co-channel rejection	18
3.3.8	Intermodulation response	18
3.3.9	Blocking	18
3.3.10	Amplitude characteristic of the receiver	18
3.3.11	AM-suppression	18
3.3.12	Audio frequency response	18
3.3.13	Harmonic distortion	19
3.3.14	Noise and hum	19
3.3.15	Audio output due to vibration	20
3.3.16	Audio muting	20
4	MOBITEX TERMINAL SPECIFICATION REFERENCE LIST	21

Bidkern

Rapron

A 292 51503

Cantel Mobitex

No. 1056 - A 296 5173/04 Ue		
Design Date	Rev.	File No.
1990-02-25	A	MTS18.2

1 INTRODUCTION

1.1 GENERAL

The radio transceiver serves as interface between the radio path and the logic and control unit of the mobile terminal. Data and voice transmission is provided.

The transmission mode is semi-duplex, the base station operates in full duplex mode and the mobile station in two frequency simplex mode.

Digital FM modulation is used for data transmission at a speed of 8 kbit/s.

The channel spacing is 12.5 kHz.

Blanket

Repro

A 296 51532

Cantel Mobitex

1056 - A 296 5173/04 Ue

DATE

1990-02-25

REV

A

FILE

MTS18.2

2 FUNCTIONAL DESCRIPTION

2.1 DATA TRANSMISSION

The main traffic in the Mobitex network will be of the data transmission type.

A modulation type which makes it possible to utilize the radio transceiver for speech transmission as well as for data transmission has been chosen.

The modulation type is binary digital baseband filtered FM at a speed of 8 kbit/s.

There should be no squelch function during data transmissions.

During data transmissions the audio paths for speech transmissions to be muted.

The data transmission mode is used for transmission of system information, system orders and for the signalling between the base station and the mobile station as well as for the user data and text transmissions.

The data transmission mode is basically a simplex mode, data transmission takes place only in one direction at a time. Short switchover times are important as this will increase the system efficiency.

Blanket

Reprod

A 292 51533

Cantel Mobitex

Model	1056 - A 296 5173/04 Ue
Version	1990-02-25 A
File	MTS18.2

2.2 SPEECH TRANSMISSION

The speech transmission mode is only reached after a request from either a mobile or a fixed terminal.

After a request for speech communication the base station allocates a radio channel and sends an order to the mobile station to switch over to that channel (separate transmit and receive frequencies).

No squelch function is to be used during speech communication.

The muting of the audio paths is released during speech communication. If, however, a data signal is detected during the speech, the audio paths to be muted immediately. This will for example occur when a data message is received during ongoing speech conversation.

2.3 TRANSMITTER CONTROL**2.3.1 Frequency**

The transmitter frequency is controlled by the control unit.

For information about frequency band and channel numbering plan to be used, please refer to document R1-06.

2.3.2 Carrier

The carrier on/off condition is controlled by the control unit during data transmissions. During speech transmission the carrier on/off condition is controlled by the manually operated transmit/receive switch.

Requirements of dynamic output power control can be made. In such a case, these are stated in reference R1-06.

There is to be a control circuit, independent of all other logic, which prohibits the continuous transmission of carrier for longer periods than 10 minutes.

2.3.3 Audio muting

The voice signal to the transmitter to be muted during data transmissions.

Bulldoze

Reprint

Cantel Mobitex

Doc No	1056 - A 296 5173/04 Ue
Version Date	1990-02-25
Rev	A
File No	MTS18.2

2.4 RECEIVER CONTROL

2.4.1 Frequency

The receiver frequency is controlled by the control unit.

For information about frequency band and channel numbering plan to be used, please refer to document R1-06.

2.4.2 Squelch control

There must be no squelch function in the receiver.

2.4.3 Signal strength indication

The received signal strength level is used in the roaming algorithm for selection of base station.

Please refer to chapter RECEIVER in this document which includes a specification of the signal strength indication.

2.4.4 Audio muting

Whenever a data signal is detected, e.g detection of frame synchronization, the receiver voice output should be muted.

Blockart

Seppel

A 392 51523

Cantel Mobitex

Doc. No. 1056 - A 296 5173/04 Ue
 Doc. Date 1990-02-25 Rev A F. 1.2
 MTS18.2

3 PERFORMANCE AND TECHNICAL REQUIREMENTS

3.1 GENERAL

For definitions and measurement methods, please refer to Appendix A.

3.1.1 Frequency range

For information about which frequency band and channel numbering plan etc that will be used, please refer to document R1-06.

3.1.2 Frequency error

The frequency error of the transmitter and receiver shall not exceed (+)(-) 1.5 ppm.

Buikert

Reprod

Cantel Mobitex

Doc. No.	1056 - A 296 5173/04 Ue
Issue Date	1990-02-25
Rev.	A
Rev. No.	MTS18.2

3.1.3 Data transmission

3.1.3.1 Modulator




Figure 1. Block diagram of the method of modulation.

The modulation type is binary digital baseband filtered FM at a speed of 8 kbit/s. The method of modulation is shown in principle in Figure 1. The logic sequence to transmit is converted to a binary NRZ waveform by a level shifter and the NRZ waveform is filtered by a lowpass filter with linear phase characteristic.

The filtered waveform is applied as control input to a VCO, a voltage controlled oscillator. The lowpass filter reduces the deviation of the modulator for the high-frequency components of the binary modulating signal and thereby reduces the out of band emission of the transmitter.

A sequence of logic 1's should yield a transmitter frequency 2.0 kHz higher than the channel center frequency. A sequence of logic 0's should yield a transmitter frequency 2.0 kHz lower than the channel center frequency. That is the modulation index is 0.5.

The filter (or the equivalent filter in case of an other implementation) shall be a low pass filter with linear phase characteristic and a 3-dB frequency of 2.4 kHz. At a frequency two (2) times the 3-dB frequency the attenuation of the filter shall be 12 dB, and at a frequency four (4) times the 3-dB frequency the attenuation of the filter shall be 48 dB. The high frequency roll-off of the filter must be at least 40 dB/octave. A high frequency attenuation of 70 dB is considered sufficient. Figure 2 shows the amplitude response of the filter. The frequency modulator should be of a wide band linear type with frequency independent response in the frequency range 0 - 4 kHz or otherwise compensated in the baseband filter. An eye diagram of the transmitted signal is shown in Figure 3.

Block

Repro

Cantel Mobitex

Doc. No. 1056 - A 296 5173/04 Ue
 Design Date 1990-02-25 Rev. A F. No. MTS18.2




Figure 2. Amplitude response of lowpass filter.




Figure 3. Eye diagram.

A preferred implementation of the baseband processing is oversampling of the bit-stream 4 - 8 times and digital filtering in a FIR (finite impulse response) filter with symmetric coefficients. This type of implementation can be realized by simple table look-up in a PROM.

The modulation rate is 8 kbits per second. The frequency error of the bitrate clock should not exceed ± 10 ppm. The error of the modulation index should not exceed ± 5 %.

Subcarrier

Spread

A 296 5153.3

Cantel Mobitex

1056 - A 296 5173/04 Ue
 DATE: 1990-02-25 Rev: A P. No: MTS18.2

3.1.3.2 Demodulator

The demodulator should be of non-coherent type. A simple decision feedback or sequence detector should be used to resolve the small receiver eye opening of two subsequent bit transitions. A required bit error rate (BER) curve as a function of receiver input in a static receiver noise limited situation is shown in Figure 4.

The performance requirement of the complete receiving equipment when connected to a reference data transmitter is that the decoded block error rate should be less than 0.1 at the reference RF input signal level. At an RF input signal level 30 dB above the reference level, the decoded block error rate should be less than 0.0001.

It is essential that the demodulator keeps the synchronism with the incoming bit-stream during an entire message, even under disturbed conditions, in order to avoid repetition of other blocks than those which were actually disturbed.




Figure 4. Bit error rate versus receiver input level.

Subnet

Repro

A 292 5153/3

Cantel Mobitex

No.	1056 - A 296 5173/04 Ue
Version	1990-02-25
Rev.	A
File Name	MTS18.2

3.1.3.3 Start of data modulation

Data modulation must not start until the carrier frequency is within its 200 Hz from its steady state value and the carrier power is within 2 dB from its steady state value.

The transmitter carrier should be on for 5 -0/+5 ms before the start of transmission (frame head).

3.1.3.4 Receive/transmit switching times

The switching time from receive to transmit condition to be less than 20 ms including CPU handling time.

The switching time from transmit to receive condition to be less than 20 ms including CPU handling time.

3.1.4 Test terminals

Please note that the transceiver input/output terminals for voice must be accessible.

An interface according to the "machine interface" defined in reference R1-19, must be available during testing.

3.1.5 Test modulation

Short and long frames as defined in the link layer will be used during tests of data transmission.

It should be possible to force the modem to continuously transmit a sequence as specified in the national requirements for out of band emission testing.

It should be also be possible to force the modem to continuously transmit the scrambling sequence that is specified in Physical Layer Specification of the mobile terminal.

Normal audio test modulation is a 1 kHz test tone at such a level that the resulting deviation is +- 1.5 kHz.

Buckert

Rapros

Cantel Mobitex

Doc No
1056 - A 296 5173/04 Ue
Drawing Date
1990-02-25
Rev
A
F. No
MTS18.2

3.2 TRANSMITTER

For definitions and measurement methods, please refer to Appendix A.

3.2.1 Carrier power

The nominal output power is stated in reference R1-06. Requirements of dynamic output power control can be made. In such a case, these are also stated in reference R1-06.

Under normal test conditions and independent of selected channel the carrier output power during carrier on condition to be within (+)(-) 1,5 dB of the nominal output power. Under extreme test conditions the carrier output power to be within +2 dB and -3 dB of the nominal output power.

When the transmitter is in the carrier off condition, the carrier output power should not exceed 0,25uW.

The transmitter to be able to withstand load tests as described below:

- the change in the transmitter output power should not exceed 2 dB during a load test when the transmitter is loaded with a resistive load giving a standing wave ratio of 2. The test to be done at normal test conditions during 5 minutes of continuous transmission.
- without being damaged the transmitter should be able to withstand the same test at extreme test conditions.
- without being damaged the transmitter should be able to transmit for a period of 1 minute with the antenna terminal left open.
- the last mentioned test to be repeated with the antenna terminal short-circuit.

Blanket

Revised

A 296 5153G

Cantel Mobitex

Doc. No.	1056 - A 296 5173/04 Ue
Doc. Date	1990-02-25
Rev.	A
Doc. File	MTS18.2

3.2.2 Carrier rise and fall time

The carrier rise time and carrier fall time are included in the transmit-receive and receive-transmit switching times. Please refer to chapter "Receive/transmit switching times" in this document.

3.2.3 Channel switching time

The channel switching time should not exceed 30 ms.

3.2.4 Frequency deviation

3.2.4.1 Maximum permissible deviation

The maximum permissible frequency deviation to be (+)(-)2.5 kHz.

3.2.4.2 Data modulation

A long sequence of logic 1's (0's) should produce a carrier frequency deviation of +(-, for 0's) 2.0 kHz \pm 0.1 kHz.

3.2.4.3 Audio modulation

The normal audio test tone will produce a deviation of \pm 1.5 kHz.

3.2.4.4 Audio frequency response

The audio frequency response, measured through the audio signal input terminal, should have a 6 dB/octave pre-emphasis between 300 Hz to 2500 Hz. For frequencies higher than 3000 Hz, the frequency response should have a roll-off of at least 30 dB/octave.

Blockout

Reprint

Cantel Mobitex™

Doc No	1056 - A 296 5173/04 Ue		
Doc. Date	1990-02-25	Rev	A
Doc. File	MTS18.2		




Figure 5. Frequency deviation relative to 1 kHz at constant input level.

3.2.5 Adjacent channel power

The adjacent channel power should not exceed the value specified in the national technical requirements, in case such a value is specified in the national technical requirements.

3.2.6 Harmonic distortion

The harmonic distortion factor should not exceed 5%.

3.2.7 Residual modulation

The residual modulation should not exceed - 40 dB, measured with a psophometric filter.

The residual modulation should not exceed - 20 dB, measured without filter.

Blanket

Revised

A 292 51534

Cantel Mobitex -

No. 1056 - A 296 5173/04 Ue		
Date 1990-02-25	Rev. A	EC No. MTS18.2

3.2.8 Modulation due to vibration

The modulation due to vibration should not exceed -30 dB measured by a r.m.s. voltmeter and with a psophometric filter.

Without the psophometric filter and measured by a peak-to-peak voltmeter the modulation should not exceed -14 dB.

3.2.9 Audio muting

An input muting device controlled by the control unit should be provided. The muting to be capable of causing at least 40 dB attenuation in the voice path. Data transmission is not to start until the muting has reached an attenuation of 40 dB.

Block:

Reprod

Cantel Mobitex

Dr. No		1056 - A 296 5173/04 Ue	
Version	Date	Rev	File
1990-02-25		A	MTS18.2

3.3 RECEIVER

For definitions and measurement methods, please refer to Appendix A.

3.3.1 Channel switching time

The channel switching time should not exceed 30 ms including data signal detection time.

3.3.2 Squelch opening and closing levels and delays

There must be no squelch function in the receiver.

3.3.3 Signal strength indication

The signal strength to be indicated by the receiver to the control unit.

The indicated range to be :

RF-level 0 - 50 dBuV emf with a monotonic output and absolute accuracy of $\pm(2 + 10 \% \text{ of actual value})$ dBuV emf.

The time constant to be 1 ms.

3.3.4 RF sensitivity

The receiver sensitivity (speech) not to exceed 0 dBuV emf under normal test conditions and + 4 dBuV emf under extreme test conditions.

The reference signalling sensitivity (data) not to exceed 0 dBuV emf under normal test conditions and 3 dBuV emf under extreme test conditions.

The multipath signalling sensitivity (data) must not exceed 12 dBuV emf. This measurement is only done under normal test conditions.

Budget

Reprod

A 296 5153G

Cantel Mobitex

1056 - A 296 5173/04 Ue	
Date: 1990-02-25	Rev: A
F. No. MTS18.2	

3.3.5 Adjacent channel selectivity

The receiver shall comply with applicable national technical requirements.

3.3.6 Spurious response rejection

The receiver shall comply with applicable national technical requirements.

3.3.7 Co-channel rejection

The measurement is made with the wanted signal at an input level of +10 dBuV emf.

The co-channel rejection level at any frequency displacement of the unwanted signal within the specified range to be greater than -2 dBuV emf.

3.3.8 Intermodulation response

The receiver shall comply with applicable national technical requirements.

3.3.9 Blocking

The receiver shall comply with applicable national technical requirements.

3.3.10 Amplitude characteristic of the receiver

For the specified change of radio frequency input level, the change of the audio output level should not exceed 3 dB between the maximum and minimum output levels.

3.3.11 AM-suppression

The AM-suppression should not be less than 30 dB.

3.3.12 Audio frequency response

The audio frequency response, measured at the audio output terminal, should be within the limits as shown in the figure below.

Block:

Reprod.

A 392 31553

Cantel Mobitex

Rev. No.	1056 - A 296 5173/04 Ue
Issue Date	1990-02-25 A
Rev.	MTS18.2




Figure 6. Audio power relative to 1kHz at constant frequency deviation.

3.3.13 Harmonic distortion

At all audio frequencies used in the measurement and under all test conditions the harmonic distortion factor should not exceed 5%.

3.3.14 Noise and hum

The receiver "noise and hum" ratio should not exceed -40 dB measured by a r.m.s. voltmeter and with a psophometric filter.

Without the psophometric filter and measured by a peak-to-peak voltmeter the "noise and hum" ratio should not exceed -20 dB.

Bidders

Reprint

A 992 51530

Cantel Mobitex

S/N		1056 - A 296 5173/04 Ue	
Date	Rev	F. P. 2	
1990-02-25	A	MTS18.2	

3.3.15 Audio output due to vibration

The noise and hum ratio of the receiver due to vibration should not exceed -30 dB measured by a r.m.s.voltmeter through a psophometric filter.

Without the filter and measured by a peak-to-peak voltmeter the the ratio should not exceed -14 dB.

3.3.16 Audio muting

An output muting device controlled by the control unit to be provided. The muting device to be capable of causing at least 40 dB attenuation in the voice path.

3.3.17

3.3.18

A 292 51550

Cantel Mobitex

Doc No. 1056 - A 296 5173/04 Ue
 Issue Date 1990-02-25 Rev. A Pz. # 1 MTS18.2

4 MOBITEK TERMINAL SPECIFICATION REFERENCE LIST

This document includes a number of references, made to other sections in the terminal specification. The list below shows these references, together with the page(s) they are made on. Please note that a section could be referred to several times on the same page.

R1-06, 6, 7, 8, 13
 R1-19, 12

Below are the reference designations listed.

Reference	Section
R1-01	Arrangement of the documents
R1-02	MOBITEK System description
R1-03	General description of terminals
R1-04	Terminology
R1-05	References
R1-06	Network operator information
R1-08	Application layer
R1-09	Network layer
R1-11	Interface requirements, fixed terminals
R1-12	Other requirements, fixed terminals
R1-16	Link layer, mobile terminals
R1-17	Physical layer, mobile terminals
R1-18	Radio equipment, mobile terminals
R1-19	Other interfaces, mobile terminals
R1-20	Other requirements, mobile terminals

Revised

Revised

A 292 51532

Original Project ET/UC SIS	Facilitating Secret Operations ET/UC SIS	No. No. A/1056 - A 296 5173/01 Ue	
Current Guidant-Operations ET/SYSC STT <i>Sn</i>		Issue Date 1990-02-23	Rev C
		P. No. MTS18A.1	
<p align="center">Cantel Mobitex</p>		<p>MOBITEX MOBILE RADIO EQUIPMENT 12.5 kHz, 900 MHz Appendix A, Measurement methods</p>	
<p><u>1 INTRODUCTION</u></p> <p>This document is an Appendix to MOBITEX TERMINAL SPECIFICATION - RADIO EQUIPMENT. It consists of requirement definitions and measurement method descriptions.</p> <p>The measurement values applies to 12,5 kHz channel spacing in the 900 MHz frequency band.</p> <p>The document describes measurement methods for several data transmission speeds. Therefore, measurements without specified requirement procedures in the main document can be found. These should be ignored.</p> <p>The equipment specified in this document should also meet with basic requirements set up in national regulations for radio transmitters and radio receivers.</p>			
<p>Butlers</p> <p>Repro</p>			

A 296 5153-8

Cantel Mobitex

No. 06 A/1056 - A 296 5173/01 Ue		
Spec. Date 1990-02-23	Rev C	File No. MTS18A.1

TABLE OF CONTENTS

1	INTRODUCTION	1
2	MEASUREMENT METHODS	3
2.1	SYSTEM MEASUREMENTS	3
2.1.1	Receive to transmit switching time	3
2.1.2	Transmit to receive switching time	3
2.1.3	Channel switching time	3
2.1.4	Frequency error	3
2.2	TRANSMITTER MEASUREMENTS	4
2.2.1	Carrier power	4
2.2.2	Maximum permissible frequency deviation	4
2.2.3	Audio frequency response	4
2.2.4	Adjacent channel power	5
2.2.5	Harmonic distortion	6
2.2.6	Residual modulation	6
2.2.7	Modulation due to vibration	7
2.3	RECEIVER MEASUREMENTS	8
2.3.1	RF sensitivity	8
2.3.2	Adjacent channel selectivity	9
2.3.3	Spurious response rejection	10
2.3.4	Co-channel rejection	10
2.3.5	Intermodulation response	11
2.3.6	Blocking	12
2.3.7	Amplitude characteristics	13
2.3.8	AM-suppression	13
2.3.9	Audio frequency response	13
2.3.10	Harmonic distortion	14
2.3.11	Noise and hum	15
2.3.12	Audio output due to vibration	15
2.4	MEASUREMENT ACCURACY	17

Drawn:

Repro:

A 296 5153.3

Cantel Mobitex

A/1056 - A 296 5173/01 Ue

Date: 1990-02-23

Ver:

C

P. No.

MTS18A.1

2 MEASUREMENT METHODS**2.1 SYSTEM MEASUREMENTS****2.1.1 Receive to transmit switching time****Definition:**

The switching time from receive to transmit condition is defined as the elapsed time from the end of an incoming frame with the response flag set, to the beginning of the response, i.e. the data signalling starts (see main document "Start of data modulation").

2.1.2 Transmit to receive switching time**Definition:**

The switching time from transmit to receive condition is defined as the elapsed time from end of the last frame in a message sent by the transmitter, until the receiver is capable of detecting incoming data signals.

2.1.3 Channel switching time**Definition:**

The channel switching time is defined as the elapsed time from the end of a received order to change channel, until the receiver is capable of detecting data signals on the new channel.

2.1.4 Frequency error**Definition:**

The frequency error of the transmitter is the difference between the measured carrier frequency and its nominal value.

Method of measurement:

The carrier frequency should be measured in the absence of modulation with the transmitter connected to an artificial antenna.

The test should be made under normal and extreme test conditions.

Bulldoz

Reprod

Cantel Mobitex

No. A/1056 - A 296 5173/01 Ue
Cantel Code 1990-02-23 Rev C Ps. P.1 MTS18A.1

2.2 TRANSMITTER MEASUREMENTS

2.2.1 Carrier power

Definition:

The transmitter carrier power is the mean power delivered to the artificial antenna during a radio frequency cycle in the absence of modulation.

Method of measurement:

The transmitter should be connected to an artificial antenna and the power delivered to this artificial antenna should be measured.

The measurements should be made under normal and extreme test conditions.

2.2.2 Maximum permissible frequency deviation

Definition:

The frequency deviation is the maximum difference between the instantaneous frequency of the modulated radio frequency signal and the carrier frequency in the absence of modulation.

Method of measurement:

The frequency deviation should be measured at the output of the transmitter connected to an artificial antenna, by means of a deviation meter capable of measuring the maximum deviation, including that due to any harmonics and intermodulation products which may be generated in the transmitter.

2.2.3 Audio frequency response

Definition:

The audio frequency response is the frequency deviation of the transmitter carrier as a function of modulation frequency at a constant level of the modulation signal.

Method of measurement:

A modulation signal at a frequency of 1000 Hz and adjusted to such level that a frequency deviation of (+)(-)0,5 kHz is obtained, is applied to the transmitter. The frequency

Builders:

Regres:

A 201 5153.3

Cantel Mobitex

Doc No: A/1056 - A 296 5173/01 Ue

Serial Date: 1990-02-23 C

Rev: MTS18A.1

of the modulation signal is then varied between 300 Hz and 25 kHz, its level being kept constant. The connection values of frequency deviation and modulation frequency should be determined.

2.2.4 Adjacent channel power

Definition:

The adjacent channel power is that part of the total power output of a transmitter under defined conditions of modulation, which falls within a specified passband centred on the nominal frequency of either of the adjacent channels. This power is the sum of the mean power produced by the modulation, hum and noise of the transmitter.

Method of measurement:

The adjacent channel power should be measured with a power measuring receiver which fulfills the requirements given in the CEPT recommendation T/R 24-1. The transmitter should be operated at the nominal carrier power under normal test conditions. The output of the transmitter should be linked to the input of the receiver by connecting device such that the impedance presented to the transmitter is 50 ohms and the level at the "receiver" input is appropriate.

The transmitter should be modulated with a signal of 1250 Hz.

The signal of 1250 Hz should be adjusted to a level 20 dB higher than that required to produce (+)(-)1,5 kHz deviation. The "receiver" should be tuned to the nominal frequency of the transmitter and the variable attenuator in the "receiver" should be adjusted to a value p dB such that a meter reading of the order of 5 dB above the "receiver" noise level is obtained.

The "receiver" should then be tuned to the nominal frequency of one of the adjacent channels and the variable attenuator should be adjusted to a value q dB such that the same meter reading is obtained.

The measurement should be repeated with normal data test modulation (paragraph Test modulation, in the Main document).

The ratio of adjacent channel power to carrier power is the difference between the attenuator settings p and q. The adjacent channel power is determined by applying this ratio to the carrier power.

Brakert

Repro

A-292 51532

Cantel Mobitex

Doc. No. A/1056 - A 296 5173/01 Ue
Date: 1990-02-23 Rev. C F. No. MTS18A.1

The measurement should be repeated for the other adjacent channel.

2.2.5 Harmonic distortion

Definition:

The harmonic distortion factor of a transmitter modulated by an audio frequency signal is defined as the ratio, expressed as a percentage, of the r.m.s. voltage of all the harmonic components of the fundamental audio frequency to the total r.m.s. voltage of the signal after linear demodulation.

With the method described below, when a distortion meter is used, the hum and noise components are included in the distortion measurement.

Method of measurement:

The radio frequency signal produced by the transmitter is applied, by means of a suitable coupler, to a linear demodulator equipped with a de-emphasis network of 6 dB per octave.

The radio frequency signal to be modulated successively at frequencies of 300, 500 and 1000 Hz frequency to (+)(-)1.5 kHz deviation.

The harmonic distortion factor of the audio frequency signal is measured at all the frequencies given above.

2.2.6 Residual modulation

Definition:

The residual modulation of the transmitter is the ratio, expressed in dB, of the audio frequency noise level produced after radio frequency signal demodulation, in the absence of modulation, by the wanted signal, by the spurious effects of the power supply system, by the modulator or by other causes, to the audio frequency level produced by normal test modulation applied to the transmitter.

Method of measurement:

- a) The normal test modulation is applied to the transmitter. The RF signal produced by the transmitter is applied by means of a suitable coupler to a linear demodulator.

Subpart

Page 1

Cantel Mobitex-

№ 001
A/1056 - A 296 5173/01 Ue

Дата изд.
1990-02-23

Изв.
C

И. П. №
MTS18A.1

The demodulator is equipped with a de-emphasis network of 6 dB per octave.

All precautions should be taken to prevent the measurement results from being affected by emphasis at the low audio frequencies of the internal linear demodulator noise.

Measurements to be carried out on the demodulator output signal by means of an r.m.s. voltmeter equipped with psophometric filter network described in CCITT Recommendation P.53.A.

The modulation is then removed and the level of the residual audio frequency output signal is again measured.

- b) The same method as a) above but without the psophometric filter at the output.

In this case the measurements are carried out by means of a peak-to-peak voltmeter.

2.2.7 - Modulation due to vibration

Definition:

Modulation due to vibration denotes the ability of the transmitter to withstand influence on the radio frequency output signal by mechanical vibrations.

Method of measurement:

The residual modulation is measured in accordance with 5.2.2. The transmitter should during the test be vibrated in each of three directions:

10 - 100 Hz 1 m/s²

sweep rate 1 octave per minute

Билдэрт

Байрм

Cantel Mobitex

Doc. No. A/1056 - A 296 5173/01 Ue

Docum. Date 1990-02-23 C Rev. F. P. MTS18A.1

2.3 RECEIVER MEASUREMENTS

2.3.1 RF sensitivity

Definition:

The maximum usable sensitivity of the receiver is the minimum level of signal (emf) and field-strength respectively at the receiver input, at the nominal frequency of the receiver, with normal test modulation which will produce:

an audio-frequency output power of at least 50% of the rated power output and

a SND/ND ratio (S=signal, N=noise, D=distortion) of 20 dB, measured at the receiver output through a telephone psophometric weighting network as described in CCITT Recommendation P.53-A.

Note: The characteristics of the 1 kHz band-stop filter used in SND/ND measurements should be such that at the output the attenuation at 1 kHz will be at least 40 dB and at 2 kHz will not exceed 0.6 dB. The filter characteristics should be flat within 0.6 dB over the ranges of 20 Hz to 500 Hz and 2 kHz to 4 kHz. In the absence of modulation of the total noise power at the audio-frequency output of the receiver under test.

The reference signalling sensitivity data is the level and field-strength respectively of a radio frequency input signal at the nominal receiver frequency and modulated with the normal coded test signal or pseudo-random bit sequence which will produce a successful calling ratio of 80% for signalling systems with a specific response as output and a bit error ratio of 0.01 for data transmission systems with a bit stream as output respectively.

Measurement methods:

A signal of carrier frequency equal to the nominal frequency of the receiver and with normal test modulation shall be applied to the receiver input terminals. An audio frequency output load and a distortions factor meter incorporating a 1 kHz band-stop filter and a psophometric telephone weighting network shall be connected to the receiver output terminals. Where possible, the receiver volume control shall be adjusted to give at least 50% of the rated output power. The test signal input level shall be reduced until a SND/ND ratio of 20 dB is obtained. The test signal input level under these conditions is the maximum usable sensitivity. The measurement shall be made under normal test conditions and extreme test conditions. Under extreme test conditions, a variation of the receiver

Endnote:

Repro:

A:296 51533

Cantel Mobitex-

No. No.
A/1056 - A 296 5173/01 Ue
Version Date Descr. File
1990-02-23 C MTS18A.1

output power of (+)(-) 3 dB from the value obtained under normal test conditions may be allowed.

A signal of carrier frequency equal to the nominal frequency of the receiver and modulated with the normal coded test signal or a pseudo-random bit sequence shall be applied to the receiver input terminals. The level of this signal shall be such that a successful calling ratio of SCR = 80%, and a bit error ratio of BER = 0.01 respectively is obtained. The reference signalling sensitivity (data) is the maximum level of the levels recorded for SCR = 80% and BER = 0.01.

The multipath signalling sensitivity is the rms value of the level of a Rayleigh fading input signal at the nominal receiver frequency and modulated with the normal coded test signal or pseudo-random bit sequence which will produce a successful calling ratio of 80% and a bit error rate of 0.01. The measurements shall be carried out with a Rayleigh fading simulator set for a simulated vehicle speed of 90 km/h and repeated for a simulated vehicle speed of 50 km/h and 10 km/h. The reference multipath signalling sensitivity (data) is the maximum necessary level of the multipath measurements.

2.3.2 Adjacent channel selectivity

Definition:

The adjacent channel selectivity is a measure of the capability of the receiver to receive a wanted modulated signal without exceeding a given degradation due to the presence of an unwanted modulated signal which differs in frequency from the wanted signal by an amount equal to the adjacent channel separation for which the equipment is intended.

Method of measurement:

Two signals should be applied to the receiver via a combining network. The wanted signal should be at the nominal frequency of the receiver and be modulated with normal test modulation. The unwanted signal should be at the nominal frequency of the upper adjacent channel and be modulated with a 400 Hz tone to a frequency deviation of (+)(-)1,5 KHz.

Initially the unwanted signal should be switched off and the level of the wanted signal should be adjusted to 6 dBuV emf. The unwanted signal should then be switched on and its level adjusted until the SMD/ND ratio, measured at the receiver line output terminal through the psophometric filter, is reduced to 14 dB.

B02401

Revised

A 292 5153.3

Cantel Mobitex

Doc. No. A/1056 - A 296 5173/01 Ue

Issue Date 1990-02-23 Rev C P. No. MTS18A.1

The measurement should be repeated with the unwanted signal at the nominal frequency of the lower adjacent channel.

The adjacent channel selectivity should be expressed as the lower value of the receiver input levels in dBuV emf of the unwanted signal for the upper and lower adjacent channels.

2.3.3 Spurious response rejection

Definition:

The spurious response rejection is a measure of the capability of the receiver to discriminate between the wanted modulated signal of the nominal frequency and an unwanted signal at any other frequency at which a response is obtained.

Method of measurement:

Two input signals should be applied to the receiver via a combining network. The wanted signal should be at the nominal frequency of the receiver and be modulated with normal test modulation. Initially the unwanted signal should be switched off and the wanted input signal adjusted to 6 dBuV emf. The unwanted signal should be switched on and modulated with a 400 Hz tone to a frequency deviation of (+)(-)1,5 kHz. The input level of the unwanted signal should be 86 dBuV emf and its frequency should be varied at least from 100 kHz to 2000 kHz.

At any frequency at which a response is obtained, the input level of the unwanted signal should be adjusted until the SND/ND ratio, measured at the line output terminal of the receiver through the psophometric filter, is 14 dB.

The spurious response rejection should be expressed as the level in dB of the unwanted signal relative to 1 uV emf at the receiver input when the SND/ND ratio of 14 dB, as mentioned above, is obtained.

2.3.4 Co-channel rejection

Definition:

The co-channel rejection is a measure of the capability of the receiver to receive a wanted modulated signal without exceeding a given degradation due to the presence of an unwanted modulated signal, both signals being at the nominal frequency of the receiver.

Backers

Reprod

A 292 5153.3

Cantel Mobitex

Doc. No.
A/1056 - A 296 5173/01 Ue

Issued Date
1990-02-23 C

P. No.
MTS18A.1

Method of measurement:

Two input signals should be applied to the receiver via a combining network. The wanted signal should have normal test modulation. The unwanted signal should be modulated with a frequency of 400 Hz to a frequency deviation of (+)(-)1,5 kHz. Both input signals should be at the nominal frequency of the receiver and the measurement should be repeated for displacements of the unwanted signal up to (+)(-)1,5 kHz offset frequency of the nominal frequency.

Initially the unwanted signal should be switched off and the level of the wanted signal should be adjusted to +6 dBuV emf. The unwanted signal should then be switched on.

The level of the unwanted signal should be adjusted until the SND/ND ratio, measured at the line output terminal of the receiver through the psophometric filter, is reduced to 14 dB.

The co-channel rejection should be expressed as the ratio in dB of the level of the unwanted signal to the level of the wanted signal at the receiver input for which $SND/ND = 14$ dB at the receiver line output terminal occurs.

2.3.5 Intermodulation response

Definition:

The intermodulation response is a measure of the capability of the receiver to receive a wanted modulated signal without exceeding a given degradation due to the presence of two or more unwanted signals with a specific frequency relationship to the wanted signal frequency.

Method of measurement:

Three signal generators, A, B and C, should be connected to the receiver via a combining network.

The wanted signal, represented by signal generator A, should be at the nominal frequency of the receiver and should have normal test modulation.

The unwanted signal from signal generator B should be unmodulated and adjusted to the frequency separated by 25 kHz above the nominal frequency of the receiver.

The second unwanted signal from signal generator C should be modulated with a frequency of 400 Hz with a deviation of 1,5 kHz and adjusted to the frequency 50 kHz above the nominal frequency of the receiver.

Indicators

Regress

A 292 51503

Cantel Mobitex

A/1056 - A 296 5173/01 Ue

Issue Date 1990-02-23 C

File No. MTS18A.1

The amplitude of the wanted input signal should be adjusted to 6 dBuV emf. The amplitude of the two unwanted signals should be maintained equal and should be adjusted until the SND/ND ratio at the receiver output, psophometrically weighted, is reduced to 14 dB.

The frequency of signal generator B should be adjusted slightly, if necessary, to produce the maximum degradation of the SND/ND ratio. The level of the two unwanted test signals should be readjusted to restore the SND/ND ratio of 14 dB.

The measurement should be repeated with the unwanted signal B at 25 kHz below that of the wanted signal and the frequency of the unwanted signal C at 50 kHz below that of the wanted signal.

The intermodulation response level is the receiver input level in dB produced by each of the two unwanted signal generators relative to 1 uV emf.

2.3.6 Blocking

Definition:

Blocking is a change (generally a reduction) in the wanted output power of a receiver or a reduction of the SND/ND ratio due to an unwanted signal on another frequency.

Method of measurement:

Two input signals should be applied to the receiver via a combining network. The wanted signal should be at the nominal frequency of the receiver and should have normal test modulation. Initially the unwanted signal should be switched off and the input level of the wanted signal should be adjusted to 6 dBuV emf.

The output power of the wanted signal at the line output terminal of the receiver should be adjusted to the nominal output level. Then the unwanted signal should be switched on. The unwanted signal should be unmodulated, and its frequency should be varied between +1 MHz and +10 MHz, and also between -1 MHz and -10 MHz, relative to the nominal frequency of the receiver. The input level of the unwanted signal, at all frequencies in the specified ranges, should be so adjusted that the unwanted signal causes:

a) a reduction of 3 dB in the audio frequency output power of the wanted signal,

or

b) a reduction of the SND/ND ratio to 14 dB, measured through a psophometric filter,

Cantel Mobitex

Part No. A/1056 - A 296 5173/01 Us		
Version Code 1990-02-23	Rev C	File No. MTS18A.1

whichever occurs first.

This input level is the blocking level at the frequency concerned.

2.3.7 Amplitude characteristics

Definition:

The amplitude characteristics of the receiver is the relationship between the radio frequency input level of specified modulated signal and the audio-frequency level at the receiver output.

Method of measurement:

A test signal at a level of 6 dBuV emf at the nominal frequency of the receiver and having normal test modulation should be applied to the receiver input. The audio frequency power at the line output should be adjusted to the nominal level. The input signal should be increased to 100 dBuV emf, and the audio frequency output level should again be measured.

2.3.8 AM-suppression

Definition:

AM-suppression is the capability of the receiver to suppress amplitude modulated signals. It is expressed as the ratio in dB of the audio power at the line output terminal with normal test modulation to the audio power with a specified amplitude modulation.

Method of measurement:

A test signal at a level of 20 dBuV emf and 60 dBuV emf at the nominal frequency of the receiver to be applied to the receiver input successively. The signal should initially have normal test modulation and the voice output terminal power should be set to the nominal output level. The normal test modulation should then be replaced by amplitude modulation to 30% with a 1000 Hz tone. The audio power should again be measured. It may be necessary to make this measurement with a selective voltmeter.

2.3.9 Audio frequency response

Definition:

Release

Reproducible

Cantel Mobitex

Sr. No.	A/1056 - A 296 5173/01 Ue	
Date	1990-02-23	PC No. MTS18A.1

The audio frequency response of the receiver expresses the variation in the audio power at the line output terminal as a function of the modulation frequency of the input signal.

Method of measurement:

A test signal at a level of 60 dBuV emf at the nominal frequency of the receiver and having normal test modulation to be applied to the receiver input.

The audio power to be adjusted to 50 % of the rated output power. This setting is not to be altered during the test.

The frequency deviation at 1000 Hz then should be reduced to (+)(-)0,5 kHz and maintained constant while the modulation frequency is varied at least between 300 Hz and 5000 Hz.

The measurement is repeated with the test signal successively at plus and minus 1,25 kHz from the nominal frequency of the receiver.

2.3.10 Harmonic distortion

Definition:

The harmonic distortion factor at the voice output terminal of the receiver is defined as the ratio, expressed as a percentage, of the r.m.s. voltage of all the harmonic components of the fundamental audio frequency to the total r.m.s output voltage.

With the method of measurement described below in case a distortion meter is used, the hum and noise components are included in the distortion measurement.

Method of measurement:

Test signals of 60 dBuV emf and 100 dBuV emf at the nominal frequency of the receiver should be applied successively to the receiver input.

In each measurement the audio power at the voice output terminal should be adjusted to the nominal output level.

The test signal to be modulated successively with 300, 500 and 1000 Hz tones to (+)(-) 1,5 kHz frequency deviation and the harmonic distortion is measured at each frequency.

Under extreme test conditions, tests to be carried out at the nominal frequency of the receiver as well as at plus

Bildkern

Repro

A 292 5152G

Cantel Mobitex

№ 1056
A/1056 - A 296 5173/01 Ue

Issue Date
1990-02-23 C

Rev. 15
MTS18A.1

and minus 1,25 kHz from the nominal frequency. In this case the input signal is modulated only with a 1000 Hz tone to a frequency deviation of (+)(-) 1,5 kHz.

2.3.11 Noise and hum

Definition:

The "noise and hum" of the receiver is the ratio, expressed in decibels, of the audio frequency noise and hum level resulting from the spurious effects of the power supply system or from other causes to the audio frequency level produced by RF-signals as specified below and applied to the receiver input.

Method of measurement:

- a) A test signal at a level of 30 dBuV emf at the nominal frequency of the receiver and having normal test modulation should be applied to the receiver input. A psophometric filter to be connected at the voice output terminal. The audio power to be adjusted to nominal level.

The output voltage is measured with an r.m.s. voltmeter.

The modulation is then removed and the audio power measurement is repeated.

- b) The same method as in case a) above, but without the psophometric filter and using a peak-to-peak voltmeter for the measurement.

2.3.12 Audio output due to vibration

Definition:

Audio output due to vibration denotes the ability of the receiver to withstand influence on a received radio frequency signal by mechanical vibrations.

Method of measurement:

The noise and hum of the receiver is measured in accordance with 5.3.6. The receiver should during the test be vibrated in each of 3 directions.

10 - 100 Hz 1 m/s²

sweep rate 1 octave per minute

Buskort

Regren

A:292.5153.3

Cantel Mobitex -

No. 50	
A/1056 - A 296 5173/01 Ue	
Date Recd	Rev
1990-02-23	C
Fr. File	
MTS18A.1	

During the vibration the radio frequency test signal should be unmodulated and the level of the receiver output signal should be measured.

Subject

Reproce

A 1056 51553

Cantel Mobitex

№ 56
A/1056 - A 296 5173/01 Ue
Дата введ. в экз. 1990-02-23
Изм. C
Ф. Ф. А.
MTS18A.1

2.4 MEASUREMENT ACCURACY

The measurement instrumentation should have at least the accuracy given below:

D.C voltage	(+)(-)1%
A.C mains voltage	(+)(-)3%
A.C mains frequency	(+)(-)0,5%
Audio-frequency voltage, power, etc.	(+)(-)0,5 dB
Audio-frequency	(+)(-)0,1%
Distortion and noise, etc of audio frequency generators	(+)(-)0,5%
Radio frequency	(+)(-)20 Hz
Radio frequency voltage	(+)(-)2 dB
Radio-frequency field strength	(+)(-)3 dB
Radio-frequency carrier power	(+)(-)5%
Impedance of artificial loads, combining units, cable, plugs, attenuators, etc.	(+)(-)5%
Source impedance of generators and input impedance of measuring receivers	(+)(-)10%
Attenuation by attenuators	(+)(-)0,5 dB
Temperature	(+)(-)1°C
Humidity	(+)(-)5%
Time	(+)(-)10%

Биджарт

Стено

A 102 51532

Uppdater: Prepared ET/SYS PES	Förhandsgranskning: Subject responsible ET/SYS PES	St. No. 1056 - A 296 5175/3 Ue	
Disutav Godkänd: Det resonsans godkänd ET/SYSC STT <i>ST</i>		Datum: Date 1990-02-23	Rev. A Följande MTS19.3
Beträffande Cantel Mobitex -		Titel MOBITEX Other interfaces, mobile terminal and fixed terminal	

Cantel Mobitex

No. No	1056 - A 296 5175/3 Ue
Version / Date	Rev
1990-02-23	A
FC. Form	MTS19.3

TABLE OF CONTENTS

1	INTRODUCTION	3
1.1	GENERAL	3
2	GENERAL DESCRIPTION	4
2.1	Terminal interface	4
2.2	Audio interface	5
2.3	Emergency interface	5
3	TERMINAL INTERFACE	6
3.1	PHYSICAL INTERFACE	6
3.2	PROTOCOL FOR PRINTER/DATA COLLECTION UNITS	8
3.3	PROTOCOL FOR TERMINALS WITH SMALL DISPLAY	9
3.4	PROTOCOL FOR ANSI TERMINAL	12
3.5	PROTOCOL FOR "MASC" TYPE TERMINALS	16
4	AUDIO INTERFACE	26
4.1	PHYSICAL INTERFACE	26
5	EMERGENCY INTERFACE	28
5.1	PHYSICAL INTERFACE	28
5.2	Time diagram:	30
6	APPLICATION EXAMPLES	31
7	MOBITEX TERMINAL SPECIFICATION REFERENCE LIST	37

APPENDIX A: Mobitex ASynchronous Communication, Commands.

APPENDIX B: Application example of how to connect fixed terminals via MCU.

APPENDIX C: Mobile terminal monitoring channels, other than MOBITEX, for special purposes(1200 Bps terminals only).

Bridgport

Rapid

A 296 5153/3

Cantel Mobitex

No. No	1056 - A 296 5175/3 Ue	
Date: Date	Rev	PS File
1990-02-23	A	MTS19.3

1 INTRODUCTION

1.1 GENERAL

The purpose of this specification is to give well defined interfaces for the connection of application equipment. This specification will serve as a recommendation for the mobile terminal market.

NOTE: The Radio/MCU must be type-tested with a terminal of "masc" type. A minimum number of commands (defined by document Mobitex ASynchronous Communication, APPENDIX A, Commands) are then required.

Bildzeit

Reprint


A 292 5153-3

Cantel Mobitex™

No. 1056 - A 296 5175/3 Ue						
<table border="1"> <tr> <td>Version Date</td> <td>Rev</td> <td>File</td> </tr> <tr> <td>1990-02-23</td> <td>A</td> <td>MTS19.3</td> </tr> </table>	Version Date	Rev	File	1990-02-23	A	MTS19.3
Version Date	Rev	File				
1990-02-23	A	MTS19.3				

2 GENERAL DESCRIPTION

The picture below shows the mobile terminal system parts.



MOBILE TERMINAL : complete equipment
MCU : mobile control unit
AUDIO-EQUIPMENT : equipment like mic/speaker, handset
OP-TERMINAL : terminal for operators
EMERGENCY EQU. : equipment like emergency receiver, emergency button

2.1 Terminal interface

Asynchronous, serial data transmission. Permitted transmission rates are 600, 1200, 2400, 4800 and 9600 Baud. However, for "masc" type terminals 600 baud is not permitted. Default value is 1200 Baud. In MCU it must be possible to set any of these baud rates by hardware switches or alike. It must be possible to set the baud rate of each output separately. Normally 1 start bit, 8 data bits, 1 stop bit and no parity is used. However, masc type terminals should use 7 data bits and even parity.

2.1.1 Printer/data collection unit

Interface designed to connect a printer or any other character (text) oriented terminal. It can also be used for data collection units. This interface must be combined with one or more of the other terminal interfaces. The 7 most significant bits are coded according to MOBITEK TEXT CODE, see reference RI-06. The eighth bit is set to logical zero.

Bildtext

Reprod

Cantel Mobitex

No. 1056 - A 296 5175/3 Ue

Date 1990-02-23 Rev. A FC No. MTS19.3

2.1.2 Terminal with small display

Designed for connection to a unit with a limited text display area and from which the operator can enter numbers, status messages and text including simple text editing. The editor is placed in MCU. Also the audio equipment and the manual mode of the radio equipment can be handled from this unit. Character oriented format (as above) is used.

2.1.3 ANSI terminal

For connection of asynchronous full screen terminal which complies with terminal interface ANSI X 3.41 1964 and ANSI X 3.64 1979 with respect to cursor control and editing functions.

From the terminal the operator can enter numbers, status messages and text including text editing. The editor is placed in MCU. Character oriented format as above.

2.1.4 "MASC" type terminal

Connection of units with the capacity to handle complete data packets (MPAK), e.g. a personal computer. The format is block oriented which means that information is transmitted in the form of packets (MPAK) according to the format which is given in the network layer specification. Control of the complete mobile terminal, e.g. audio equipment and manual mode, is performed by special commands included in the protocol. The interface also contains functions for reading status parameters in the mobile terminal (meant for the type test). 7 bits per character and even parity to be used. Permitted transmission rates are 1200, 2400, 4800 or 9600 Baud.

For type testing, a masc type interface is required. In this case it may be implemented by external adaptors.

2.2 Audio interface

Connection of microphone and loudspeaker or handset. The interface also contains certain control functions. The handset can be combined with numeric and status keys. The same character codes as for the terminal with small display are used. The audio interface can also be combined with the terminal interface. Refer also to the application examples.

2.3 Emergency interface

Connection facilities for four units. Three connections are for emergency buttons and one is for a receiver for receiving emergency transmissions generated by a portable transmitter. Any of these units can initiate the emergency procedure in MCU.

Ridham

Reprod

Cantel Mobitex

Doc No 1056 - A 296 S175/3 Ue
 Doc Date 1990-02-23 Rev A P. 1.1
 MTS19.3

3 TERMINAL INTERFACE

This chapter describes the interface to equipment which communicates with MCU in serial form.

3.1 PHYSICAL INTERFACE

The physical interface is the same for all terminal types.

The terminal interface uses a 25-pole DSUB socket (female socket with pins) with the following configuration:

PIN	V.24/V.28	V.10 category 1/V.11	SOURCE
1	supply ground	supply ground	
2	transmitted data	transmitted data	A DTE
3	received data	received data	A MCU
4	*	*	
5	*	*	
6	data set ready	data set ready	A MCU
7	signal ground	signal ground	
8	*	data terminal ready B	DTE
9	system start (ground)	system start (ground)	DTE
10	system start (+12V)	system start (+5V)	DTE
11	*	*	
12	*	*	
13	*	*	
14	*	transmitted data	B DTE
15	*	received data	B MCU
16	*	*	
17	*	*	
18	*	data set ready	B MCU
19	*	*	
20	data terminal ready	data terminal ready A	DTE
21	*	*	
22	ring ind.	ring ind.	MCU
23	*	*	
24	-12V (supply)	*	MCU
25	+12V (supply)	+5V (supply)	MCU

* = reserved

Note: Pins 9, 24 and 25 differ from V.28: Pins 9, 10, 24 and 25 differ from V.24.

The following applies to V10: 0 or ON is when A > B and 1 or OFF is when B > A.

The following applies to V28: 0 or ON is when V > 3V and 1 or OFF is when V < -3V.

Signature

Reprod

A 592 5155-3

Cantel Mobitex		SP No	1056 - A 296 5175/3 Ue	
		System Date	Rev	PC File
		1990-02-23	A	MTS19.3

Pin:

2,3 The transmission rate for serial data is 600, 1200, 2400, 4800 or 9600 baud.

6 The signal "DATA SET READY" is activated as soon as MCU is ready to transmit. The signal to be activated when it is not used.

 An active signal means that the physical layer is in the data transmission mode.

9 System Start, activating MCU from equipment not according to V.28.
 MCU starts up within 10 seconds when pin 9 is activated (ON condition). MCU then remains on until all system start signals are inactivated.
 ON condition: voltage 0V - +1V; current less than 5 mA.
 OFF-condition: not connected or voltage +2V - +15V; current less than 5 mA.

10 System Start, activating MCU by signal according to V.28.
 MCU starts up within 10 seconds when pin 10 is activated. MCU then remains on until all system start signals are inactivated.
 ON condition: voltage > 3V (see V28).
 OFF condition: not connected or voltage < -3V. (see V28).

20 The signal "DATA TERMINAL READY" is activated as soon as the terminal is ready to receive. The signal is to be activated when not used.

 An active signal means that the physical layer is in the data transmission mode.

22 The signal "RING INDICATION" is used to activate the peripheral unit.

24 - 12 V/100 mA supply for connected equipment.

25 + 12 V (+ 5 V)/500 mA supply for connected equipment.

A 090511339

Cantel Mobitex

Sr. No.	1056 - A 296 5175/3 Ue
Issue Date	1990-02-23
Rev	A
P. P.	MTS19.3

3.2 PROTOCOL FOR PRINTER/DATA COLLECTION UNITS

General

Interface designed to connect a printer or any other character (text) oriented terminal. It can also be used for data collection units. This interface must be combined with one or more of the other terminal interfaces.

Receiving text

To stop the data stream from MCU temporarily, the printer sends XOFF (DC3) to MCU and to restart the data stream it sends XON (DC1).

Sending text

Text can be sent to MCU. In MCU a complete MPAK will be created with sender and addressee before it is transmitted on the radio path.

The connected unit stops sending when it has received XOFF (DC3) from MCU and does not start again until XON (DC1) is received.

Midwest

Repro

A 002 51533

Cantel Mobitex

No. 1056 - A 296 5175/3 Ue
 Version 1990-02-23 Rev A E. P. MTS19.3

3.3 PROTOCOL FOR TERMINALS WITH SMALL DISPLAY

3.3.1 Receiving data

To stop the data stream from MCU temporarily, the terminal sends XOFF (DC3) and to restart the data stream it sends XON (DC1). Received characters in the code range 32 - 126 (decimal) are printed out directly. Other codes are interpreted by the terminal according to the following table:

CHARACTER CODE	TERMINAL'S INTERPRETATION OF CHARACTER
000	NUL -
001	SOH -
002	STX -
003	ETX -
004	EOT -
005	ENQ -
006	ACK -
007	BEL give audible signal
008	BS move cursor one step to left
009	HT -
010	LF line feed
011	VT -
012	FF -
013	CR move cursor to beginning of line
014	SO -
015	SI -
016	DLE -
017	DC1 resume sending data
018	DC2 -
019	DC3 stop sending data
020	DC4 -
021	NAK -
022	SYN -
023	ETB -
024	CAN -
025	EM -
026	SUB -
027	ESC carry out function as defined below
028	FS -
029	GS -
030	RS -
031	US -
127	DEL -

Buildings

Revised

A 292 61533

Cantel Mobitex -

Nr. No. 1056 - A 296 5175/3 Ue
 Datum Date 1990-02-23 Rev. A Fz. For MTS19.3

SEQUENCE	FUNCTION WHEN RECEIVED
<ESC>[Ax	place the cursor at position x
<ESC>[Bx	insert character x at cursor position
<ESC>[Cx	delete character at cursor and insert character x at end of line
<ESC>[Dx	delete character at cursor and insert character x at beginning of line
<ESC>[E	send user information
<ESC>[H	send display size
<ESC>[M	restart of terminal from MCU
<ESC>[N	display visible <CR>
<ESC>[O	display visible <LF>
<ESC>[P	LED1: on (contact with system)
<ESC>[Q	(green) blinking (no contact with system)
<ESC>[R	off (power off)
<ESC>[S	LED2: on (external call ind. on)
<ESC>[T	(orange) blinking (no function)
<ESC>[U	off (external call ind. off)
<ESC>[V	LED3: on (Manual radio mode)
<ESC>[Z	(yellow) blinking (Call indication man. mode)
<ESC>[[off (MOBITEX)

Bildkart

Diagram

A 292 5153/3

Cantel Mobitex

Mr No 1056 - A 296 5175/3 Ue

System Date 1990-02-23

Rev A

File No MTS19.3

3.3.2 Sending data

The terminal stops when it has received XOFF (DC3) from MCU and does not restart until XON (DC1) is received. All characters are interpreted as when receiving except for the <ESC> sequences defined in the following table:

SEQUENCE	FUNCTION WHEN SENDING
<ESC>OA	place cursor at beginning of text
<ESC>OB	place cursor at end of text
<ESC>OC	move cursor one step to the right
<ESC>OD	move cursor one step to the left
<ESC>OE	user information follows (2048 octets)
<ESC>OHxy	display size: x=character/line, y=no. of line
<ESC>OK	user information missing
<ESC>OM	send message
<ESC>OP	LINE CONNECTION start
<ESC>OQ	STATUS
<ESC>OR	EMERGENCY
<ESC>OW	TELEX
<ESC>OX	DATEX
<ESC>Ol	copy
<ESC>Om	lock
<ESC>On	LINE CONNECTION end
<ESC>Oo	external call indication on/off (toggle)
<ESC>Op	TEXT
<ESC>Oq	increase audio volume
<ESC>Or	decrease audio volume
<ESC>Os	loudspeaker on/off (toggle)
<ESC>Ot	cancel
<ESC>Ou	TELEPHONE
<ESC>Ov	MANUAL RADIO MODE

When the terminal is sending, the character DEL (decimal 127) is interpreted as the terminal wishing to remove the character to the left of the cursor.

Following ASCII codes are used to control MANUAL RADIO mode:

Q	channel number where x=channel number 01 - 99
W X	squelch on/off (toggle)
E	selective call to xxxxxxx, x = 0 - 9
R xxxxxxx	transmit call tone
T	loudspeaker on/off (toggle)
U	scanning
I	external call indication on/off (toggle)

Block

Repro

Cantel Mobitex

No. 24	1056 - A 296 5175/3 Ue	
Start Date	Rev	File
1990-02-23	A	MTS19.3

3.4 PROTOCOL FOR ANSI TERMINAL**3.4.1 Receiving data**

To stop the data stream from MCU temporarily, the ANSI terminal sends XOFF (DC3) and to restart the data stream it sends XON (DC1). Received characters in the code range 32 - 126 (decimal) are displayed directly. Other codes are interpreted by the ANSI terminal according to the following tables:

CHARACTER CODE		ANSI terminal's interpretation of character
000	NUL	-
001	SOH	-
002	STX	-
003	ETX	-
004	EOT	-
005	ENQ	-
006	ACK	-
007	BEL	give audible signal
008	BS	move cursor one step to the left
009	HT	-
010	LF	line feed
011	VT	-
012	FF	-
013	CR	carriage return
014	SO	-
015	SI	-
016	DLE	-
017	DC1	resume sending data
018	DC2	-
019	DC3	stop sending data
020	DC4	-
021	NAK	-
022	SYN	-
023	ETB	-
024	CAN	-
025	EM	-
026	SUB	-
027	ESC	carry out function as defined below
028	FS	-
029	GS	-
030	RS	-
031	US	-

Bildtext

Reprod

A 296 5175/3

Cantel Mobitex-

No. 1056 - A 296 5175/3 Ue
 Date: 1990-02-23 Rev. A File No. MTS19.3

SEQUENCE	FUNCTION WHEN RECEIVING
<ESC>[A	cursor up one step
<ESC>[B	cursor down one step
<ESC>[C	cursor right one step
<ESC>[D	cursor left one step
<ESC>[c	restart of terminal from MCU
<ESC>[0q	switch off LED1--LED4 (not ANSI)
<ESC>[1q	switch on LED1 (not ANSI)
<ESC>[2q	switch on LED2 (not ANSI)
<ESC>[3q	switch on LED3 (not ANSI)
<ESC>[4q	switch on LED4 (not ANSI)

For the meaning of LED1 - LED3 see terminal with small display.

If additional functions are required, we recommend the use of functions and control sequences in accordance with ANSI X 3.41 1974 and ANSI X 3.64 1979.

Bitcount

Supervise

A 292 51533

Cantel Mobitex

No. No
1056 - A 296 5175/3 Ue
Document Date Rev File
1990-02-23 A MTS19.3

3.4.2 Sending data

The ANSI terminal stops sending when it has received XOFF (DC3) from MCU and does not restart until XON (DC1) is received. All characters are interpreted as when receiving, except for the <ESC> sequences defined in the following table:

SEQUENCE	FUNCTION WHEN SENDING
<ESC>OA	move cursor up one step
<ESC>OB	move cursor down one step
<ESC>OC	move cursor one step to the right
<ESC>OD	move cursor one step to the left
<ESC>OE	-
<ESC>OF	-
<ESC>OG	-
<ESC>OHxy	display size: x=character/line,y=no. of lines
<ESC>OI	-
<ESC>OJ	-
<ESC>OK	user information missing
<ESC>OL	-
<ESC>OM	send message
<ESC>ON	-
<ESC>OO	-
<ESC>OP	LINE CONNECTION start
<ESC>OQ	STATUS
<ESC>OR	EMERGENCY
<ESC>OS	-
<ESC>OT	-
<ESC>OU	-
<ESC>OV	-
<ESC>OW	TELEX (not in ANSI standard)
<ESC>OX	DATEX (not in ANSI standard)
<ESC>OY	-
<ESC>OZ	-
<ESC>O[-
<ESC>O\	-
<ESC>O]	-

(Continued on next page)

Bidkast

Repost

Cantel Mobitex

Doc No. 1056 - A 296 5175/3 Ue
Revision Date 1990-02-23 Rev A File Path MTS19.3

SEQUENCE	FUNCTION WHEN SENDING
<ESC>0a	-
<ESC>0b	-
<ESC>0c	-
<ESC>0d	-
<ESC>0e	-
<ESC>0f	-
<ESC>0g	-
<ESC>0h	-
<ESC>0i	-
<ESC>0j	-
<ESC>0k	-
<ESC>0l	copy
<ESC>0m	lock
<ESC>0n	LINE CONNECTION and
<ESC>0o	external call indication on/off (toggle)
<ESC>0p	MOBITEX, start sending message
<ESC>0q	increase volume
<ESC>0r	decrease volume
<ESC>0s	loudspeaker on/off
<ESC>0t	cancel
<ESC>0u	TELEPHONE
<ESC>0v	scroll up presentation field
<ESC>0w	scroll down presentation field
<ESC>0x	get next message
<ESC>0y	-
<ESC>0z	-
<ESC>0{	-
<ESC>0	-
<ESC>0}	-

When the terminal is sending the character DEL (decimal 127) is interpreted as the terminal wishing to remove the character to the left of the cursor.

332222

Reprod

A 391 51533

Cantel Mobitex

No. 1056 - A 296 5175/3 Ue		
Doc. No. 1990-02-23	Rev. A	FS F. 1 MTS19.3

3.5 PROTOCOL FOR "MASC" TYPE TERMINALS

The masc type interface is designed for connection of units with the capacity to handle complete data packets (MPAK see reference RI-09), e.g. a personal computer. Information is transferred between the terminal and MCU in the form of frames, described in subsequent clauses. Control of the complete mobile terminal, e.g. audio equipment and manual mode, is performed by special commands included in the protocol. The interface also contains functions for reading status parameters in the mobile terminal (meant for the type test).

For type testing, a masc type interface is required. In this case it may be implemented by external adaptors. For the type testing, only the basic commands and the type testing commands are required.

A frame is formed as a message packet with unique characters marking the beginning and the end of the frame. Sending may be initiated from both sides. The information frame must be acknowledged with ACK before the next information frame is sent.

The characteristics of the protocol are:

- All characters are coded into the 7 least significant bits and bit 8 is used for even parity.
- The error control is done by longitudinal and character parity check and frame length control,
- Transparent data can be sent in hex coded data fields.
- The protocol permits full duplex.

3.5.1 Frame structure

Communication takes place in the form of frames. There are two types of frames, information frames and control frames. The information frames are used to transfer commands and other information. The control frames are used to control the information frame flow.

Subject

Reprod

A 292 5150G

Cantel Mobitex™

Doc. No. 1056 - A 296 5175/3 Ue
 Date Issued 1990-02-23 Rev. A Pgs. 1
 MTS19.3

The Information frames are divided into the following fields (number of octets stated below):

start	length	text	std.	data	check	end
1	4	1-256	1	0-1120	2	1

The Control frames are divided into the following fields (number of octets stated below):

start	type	sequ	end
1	1	0-1	1

The maximum frame size permitted is set up by the B-command. The maximum possible size is 1150 octets. This means that an Information frame can not have the maximum length in all fields.

- Start

The start of a frame is denoted by the character ^ with code 136/94/5E in octal/decimal/hexadecimal notation.

All characters received before the start character should be ignored. Every start character is the beginning of a new frame.

- Length

The size of the frame, in number of octets, should be written in this field with the ASCII codes of four hexadecimal digits. The least significant digit should always be written in octet 4.

The size of the frame includes all octets including start and end characters.
 Permitted characters of length field: 0-9, A-F.

- Text

Text is a field which determines the meaning and the interpretation of the frame. The interpretation of the text field is carried out by a higher layer. The text field consists of at least 1 character and a maximum of 256 characters. Numeric information, e.g. command parameters, are always to be given as the ASCII codes of the corresponding hexadecimal digits 0-F.
 Permitted characters of text field are:
 SPACE (40/32/20) to } (175/125/7D) except Std(:) and startcharacter(^).

Block:

Repeat

A 291 5153

Cantel Mobitex

Doc No	1056 - A 296 5175/3 Ue	
Serial Date	1990-02-23	Ver A
File No	MTS19.3	

- Std (start data)

Text and data are separated by the character : (colon 72/58/3A). Std should be stated even if the data field is empty.

- Data

The data field consists of data.
The coding of the data field is carried out in hexadecimal code so that transparent data can be sent. Each octet of data which is to be coded into the data field is divided into two half octets with four bits in each. Each of these four bit groups is then represented in the data field by the ASCII code of the corresponding hexadecimal digit 0-F. Thus each input octet is represented by two characters (octets) in the data field.

The data field consists of maximum 1120 characters.
Permitted characters of data field is: 0-9, A-F.

- Check

Longitudinal checksum created by exclusive OR on all characters starting with the start character and ending with the character before the checkfield. The check field consists of two ASCII coded hexadecimal digits with the least significant digit in octet 2.

Permitted characters for the check field is: 0-9, A-F

- Type

The type of control frame is stated with one character. The characters which may be used are * (52/42/2A), ? (77/63/3F), ! (41/33/21), # (43/35/23) or \$ (46/38/26).

- Sequ (sequence number)

The sequence number for ACK-frames. The sequence number can be one of the characters 0 (60/48/30), 1 (61/49/31) or - (minus, 55/45/2D).

- End

The frame is terminated with the carriage return character (CR, 15/13/0D). A frame which is not ended with the end character should be ignored.

Boldart

Reprod

Cantel Mobitex

Doc No.	1056 - A 296 5175/3 Use
Series Date	1990-02-23
Rev	A
E. No.	MTS19.3

3.5.2 Information frame

Messages are sent as Information frames with an expected acknowledgement (ACK).

The text field of an Information frame has the following general structure:

com	SP	par
>=1	0-1	>=0

com is the command or function code.

SP is the space character (ASCII code 40/32/20 in octal/decimal/hexadecimal notation) which separates the command from the parameters.

par is the ASCII coded parameters or data.

A command which sets parameter A to 587 can be coded in the following ways (all commands are terminated with CR):

```

^0010S A=587:50
^0012SET A/587:D1
^0010S A:028BAF      028B is hex code for 587
^000FSA:028B78       SA is a command

```

Note: The textfield can only consist of one (1) command.

Sidekan

Report

Cantel Mobitex™

No. No.	1056 - A 296 5175/3 Ue	
Version Data	Rev	Fr. F.m
1990-02-23	A	MTS19.3

3.5.3 Control frames

The protocol consist of the following control frames:

- ACK
- NACK
- RACK
- SENS
- SACK

- ACK (Acknowledgement of a correct received frame)

Structure:

^	*	sequ	CR
1	1	1	1

ACK means that the received Information frame is correct. A correct frame should comply with the following:

- starts with the start character (^)
- contains only one colon (:)
- the fields "check" and "length" have the correct values
- only permitted characters in text and data fields
- no characters with parity error
- the permitted number of characters has not been exceeded in any individual field or in the complete frame.
- ends with the end character (CR)

The field "sequ" (sequence number) should alter between ASCII character 0 and ASCII character 1 for each frame sent, except when repeating the latest ACK on a RACK request. Then the same value as before is sent again. The first time an ACK is sent "sequ" should be the character 0. If a RACK is received before any ACK has been sent, the field "sequ" will be filled with the character - (minus). "Sequ" with the value of - (minus) is only used when RACK is received before ACK has been sent the first time.

- NACK (No acknowledgement of an incorrect received frame)

Structure:

^	?	CR
1	1	1

NACK is to be sent if the conditions for sending ACK are not fulfilled and the Information frame:

- starts with the start character (^)
- contains only one colon (:)
- has a total length of 10 characters or more
- ends with the end character (CR)

Block:

Repro:

Cantel Mobitex

No. 1056 - A 296 5175/3 Ue
 Date: 1990-02-23 Rev. A Doc. No. MTS19.3

Should the criteria not be fulfilled for sending ACK or NACK, no reply will be given. The frame will then be repeated by the timeout function in the sending unit.

If the receiving unit cannot handle the incoming data flow, NACK may be used to limit the flow.

- RACK (Request for repetition of the latest sent ACK).

Structure:

^	I	CR
1	1	1

RACK, request for repetition of the latest sent ACK, is sent when no reply on the Information frame has been received within 10 seconds. The receiver of RACK is to reply by repeating ACK with the latest sequence number (sequ) used.

- SENS (link layer control)

Structure:

^	#	CR
1	1	1

SENS is used to control the communication link when there is no traffic. The sender decides when SENS will be sent. Time between 2 SENS should be at least 10 seconds.

When sending a SENS a reply (SACK) will be received within 10 seconds. If no reply is received within 10 seconds, a new SENS will be sent. When two SENS have been sent and no reply is received or no info-frame has been correctly transmitted, the communication link is supposed to be broken. A restart will be done by sending a B-frame.

If SACK is received and no SENS has been sent, the SACK will be ignored.

- SACK (Sens acknowledgement)

Structure:

^	&	CR
1	1	1

SACK will be sent when a controlframe (SENS) has been received. It should be sent at the first possible opportunity when nothing else is being sent.

Cantel Mobitex

No. 1056 - A 296 5175/3 Ue
 Datum 1990-02-23 Rev A F. MTS19.3

3.5.4 Flow control and error handling

If the reply of an Information frame is ACK, the Information frame will be correctly received. The field "sequ" is saved as the latest received sequ number.

If the reply is a NACK, the Information frame will be repeated.

If there is no reply within 10 seconds after the Information frame was sent, a RACK will be sent. If there is no reply on the RACK, a new RACK will be sent every 10 seconds. If no ACK has been received within 30 seconds after the Information frame was sent (time-out), higher layers will be notified. However, the repetition of RACK will continue until interrupted by higher layers or by the fact that an ACK has been received.

When an ACK is received as a reply to a RACK, the sequ number of this ACK will be compared with the stored sequ number of latest received ACK. If the numbers are equal, the Information frame was not received and must be repeated. If the numbers are different, the Information frame was received correctly (but ACK was lost) and the Information frame should not be repeated. However, if the sequ number of the received ACK is - (minus) the Information frame must be repeated.

When the physical layer gets into datatransmission mode the link layer is supposed to start up.

When one of the two interconnected units is started up, it has no stored value of the sequ of the latest received ACK. Neither does it have a value of the sequ of the latest sent ACK. To handle this situation and to prevent a possible doubling of the first frame, the following start up procedure is required:

- The first Information frame sent should be a B-frame. This B-frame consists of communication parameters for mascc protocol(see appendix A).
- If the sending of that B-frame leads to error handling with RACK, the B-frame must be repeated regardless of the value of the sequ field of the ACK response to RACK.

The actions to be taken when receiving ACK as a response to RACK are summarized in the following table:

		sequ of received ACK			
		-	0	1	
sequ of the latest received ACK	none	repeat	repeat	repeat	
	0	repeat	repeat	no rep.	
	1	repeat	no rep.	repeat	

Blockers

Reproce

Cantel Mobitex

No. 1056 - A 296 5175/3 Ue

Issue Date 1990-02-23 Rev A File MTS19.3

3.5.5 Time diagram

0. MCU/terminal starts up by setting protocol parameters.
1. MCU sends Information frame 0 to terminal which sends acknowledge.
2. MCU sends Information frame 1 which is disturbed and then repeated after NACK from terminal.
- 3.0 MCU sends Information frame 2 but it does not reach the terminal the first time. Information frame repeated after RACK and repeated ACK being the same as previous ACK (sequ=0).
- 3.1 The same as 3.0 but this time ACK(1) does not reach the sender. RACK is sent and now the repeated ACK, having a new sequ, indicates that the frame was received correctly.
4. MCU and terminal sending Information frames at the same time.
5. MCU and terminal doesn't start at the same time.
- 5.5 MCU restarts and B-frame is repeated.

(Number in brackets after ACK denotes sequence number)


MCU	masc protocol	operator terminal
0. B(len,int)	----->	
	<-----	ACK(0)
ACK(0)	<-----	B(len,int)
	----->	
1. Info frame 0	----->	
	<-----	ACK(1)
2. Info frame 1	-----X----->	
	<-----	NACK
Info frame 1	----->	
	<-----	ACK(0)
3.0 Info frame 2	----->/	
timeout 10 s	----->	
RACK	<-----	ACK(0)
Info frame 2	----->	
	<-----	ACK(1)
3.1 Info frame 2	----->	
	/<-----	ACK(1)
timeout 10 s	----->	
RACK	<-----	ACK(1)

Bickert

Repro

Cantel Mobitex

No. 1056 - A 296 5175/3 Use
Dayton Date 1990-02-23 Ver A P. File MTS19.3



Bildschirm

Diagramm

A 292 5153.3

Cantel Mobitex

1056 - A 296 5175/3 Ue
 1990-02-23 A MTS19.3

4 AUDIO INTERFACE

This interface is intended for the connection of audio equipment such as microphone and loudspeaker or a handset. The interface also contains certain control functions.

A simple audio equipment can consist of a loudspeaker and a microphone or a handset with holder and switches to activate the functions needed (hook on/off, push-to-talk). The handset can also be a more complex unit using serial data to communicate over the interface and including a small display and numeric and status keys. Some examples are given in application examples.

4.1 PHYSICAL INTERFACE

The terminal interface uses a 15-pole DSUB socket (female socket with pins) with the following configuration:

PIN	SIGNAL	ACTIVE	SOURCE
1	ground for earphone/loudsp		MCU
2	data send		audio equipment
3	data receive		MCU
4	extern. call indic. on/off	on = 0V	audio equipment
5	volume up	up = 0V	audio equipment
6	volume down	down=0V	audio equipment
7	ground for control signals		MCU
8	system start	start=0V	audio equipment
9	+12V		MCU
10	-12V		MCU
11	microphone LF		audio equipment
12	microphone ground		
13	microphone hook on/off	lifted=0V	audio equipment
14	transmit/receive switch	transm.=0V	audio equipment
15	earphone/loudspeaker LF		MCU

pins:

2,3 Data send/receive
 V24/V28 applies.
 Data is formatted in accordance with "terminal with small display".

4 External call indication on/off
 When pin 4 is activated, MCU toggles the external call indication on/off. When on, the external call indicator (e.g. horn) is activated when a message is received.

Blockart

Reprod

Cantel Mobitex -

Doc No. 1056 - A 296 5175/3 Ue
 Date 1990-02-23 Rev A P. No. MTS19.3

pins:
5,6

Volume up/down

Grounding pin 5 or 6 will adjust the audio level (volume) of the loudspeaker or the earphone, whichever is active when the pin is activated. (The audio level of the inactive unit will remain as before.) The adjustment is made in steps, one step for each new activation of the pin. If the pin is activated continuously, the level to be adjusted by one step per second. The lowest level possible to set must still be noticeable.

8

System start

MCU will start up within 10 seconds when pin 8 is activated. It then remains on until switched off by other means even if the pin is inactivated.

9,10

Power supply of connected equipment

+12V (pin 9) is able to supply a current of at least 500 mA and -12V (pin 10) a current of at least 100 mA.

11,12

Microphone input

Input impedance: 10 kohm.

Sensitivity: An input signal with the frequency 1 kHz and a level of 100 mV produces an RF deviation of 3.0 kHz. This level is produced by the microphone at a sound pressure of 94 dB above $2 \cdot 10^{-5}$ pascal.

13

Microphone hook on/off

When the microphone or handset is lifted from its holder, pin 13 is activated (HOOK OFF signal generated). If a handset with earphone is used, the loudspeaker will be inactivated and the earphone activated. When the microphone or handset is placed in its holder again, pin 13 will be inactivated (HOOK ON signal generated). If an earphone has been used, it will be inactivated and the loudspeaker activated (for audio level settings, see pin 5,6).

14

Transmit/receive switch

When activated, the radio unit will transmit and when deactivated, the radio unit will receive (push-to-talk switch).

1,15

Earphone/loudspeaker

This output is able to support impedances down to 4 ohms.

Earphone sensitivity: The earphone produces a sound pressure of 85-95 dB above $2 \cdot 10^{-5}$ pascal when driven by a signal with the frequency 1 kHz and a level corresponding to an RF deviation of 3.0 kHz.

Bulkent

Repro

Cantel Mobitex

No. 1056 - A 296 5175/3 Ue
 Date: 1990-02-23 Rev. A P. 19.3
 MTS19.3

5 EMERGENCY INTERFACE

5.1 PHYSICAL INTERFACE

The terminal interface uses a 15-pole DSUB socket (female socket with pins) with the following configuration:

PIN	SIGNAL	ACTIVE	SOURCE
1	emergency 1	emerg=0V	emergency equip.
2	emergency ACK	ACK =0V	MCU
3	emergency_ack. from fixed	emack=0V	MCU
4	emergency_ack. ACK	ACK =0V	emergency equip.
5	*		
6	emergency 2	emerg=0V	emergency equip.
7	ground for control signal		
8	system start	start=0V	emergency equip.
9	+12V (supply)		MCU
10	*		
11	emergency 3	emerg=0V	emergency equip.
12	emergency 4	emerg=0V	emergency equip.
13	emergency LF input		emergency equip.
14	emergency LF ground.		emergency equip.
15	external indicator	on = 0V	MCU

* = reserved

pins:

1 Emergency 1
 Emergency alarm from an external emergency unit, e.g. a receiver for emergencies sent on radio from a pocket transmitter. Emergency 1 (pin 1) is used together with pin 8 (system start) and pin 2 (emergency ACK from MCU) to be able to initiate an emergency alarm even if MCU is powered off. When the external emergency unit initiates the alarm, it activates both pin 1 (emergency 1) and pin 8 (system start). After detecting the alarm, MCU sends an acknowledge to the emergency unit by activating pin 2 (emergency ACK from MCU). The emergency unit must keep pins 1 and 8 activated until this ACK has been received. MCU will then create and send a SOS packet to the network.

2 Emergency ACK from MCU
 Emergency ACK is an acknowledgement from MCU that emergency 1 has been received by MCU (response to activation of pin 1).

Bitdata

Reprode

A 292 51530

Cantel Mobitex

1056 - A 296 5175/3 Ue
 1990-02-23 A MTS19.3

3. Emergency acknowledgement from fixed terminal
 When the fixed terminal has received the emergency message (SOSINFO), it can send a special emergency acknowledgement packet (SOSACK) or a request for an emergency connection (SOSCONREQ) addressed to the alarming subscription. When a SOSACK is received by MCU, it indicates this to the emergency unit by grounding pin 3. The emergency unit in turn grounds pin 4 as an acknowledgement.
 Additional reactions from MCU when receiving SOSACK or SOSCONREQ are very much depending on application. A parameter emergency-acknowledge-status should be implemented and stating at least the following:
 status = 0 no additional reaction
 1 activate external indication (e.g. horn)
 2 emergency line connection in direction mobile to base (one-way, mobile transmitting)
 3 send acknowledge to op. terminal
4. Emergency acknowledgement ACK from emergency unit
 Used by the emergency unit to acknowledge the activation from MCU of pin 3.
- 6,11,12 Emergency 2, 3 and 4
 These pins are intended for initiating an emergency alarm from simple emergency equipment such as a single push button. When one of these pins is activated, MCU creates a SOS packet and sends it to the network. Should the pin remain active, the time between repeated SOS packets must be at least 1 minute. The signals are not acknowledged by MCU.
8. System start
 MCU will start up within 10 seconds when pin 8 is activated. It then remains on until switched off by other means even if the pin is inactivated.
9. Power supply for external equipment
 +12V is able to supply a current of at least 500 mA. (The emergency unit should always be powered up)
- 13,14 Emergency LF input (for emergency connection)
 Input impedance: 10 kohm.
 Sensitivity: An input signal with the frequency 1 kHz and a level of 100 mV produces an RF deviation of 3.0 kHz. This level is produced by the microphone at a sound pressure of 94 dB above $2 \cdot 10^{-5}$ pascal.
15. Activation of external indicator
 This pin is used to activate an external indicator (e.g. horn). It is able to sink at least 100 mA to operate e.g. a relay which activates the horn (open collector output).

Bildart:

Repro:

A 5925153

Cantel Mobitex

Ver. No. 1056 - A 296 5175/3 Ue
 Docum. Date 1990-02-23 Rev. A F.F. File MTS19.3

5.2 Time diagram:

EMERGENCY UNIT (emergency 1):

packet	radio path	RADIO/MCU	interface	em. unit
SOS	<-----	start	<--- 8	start up
		emergency 1	<--- 1	emerg.1
		emergency ACK	2 --->	ack
		send emergency signal (external indicator might be activated	15 --->	horn)

IN CASE OF MANUAL ACKNOWLEDGE FROM FIXED TERMINAL AFTER RECEIVING SOSINFO

SOSACK	----->	emerg._ack from fixed	3 --->	fixd ack
		acc. to em.ack.status (e.g. ext. indicator	<--- 4	ack
			15 --->	horn)

EMERGENCY BUTTON (emergency 2, 3 or 4):

packet	radio path	RADIO/MCU	interface	em.butt.
SOS	<-----	emergency 2 (3 or 4)	<--- 6	emerg.2
		send emergency signal (external indicator might be activated	15 --->	horn)

IN CASE OF MANUAL ACKNOWLEDGE FROM FIXED TERMINAL AFTER RECEIVING SOSINFO

SOSACK	----->	emerg._ack from fixed	3 ---/	
		acc. to em.ack.status (e.g. ext. indicator	15 --->	horn)

Bidder

Reprod

A 292 5155-3

Cantel Mobitex

Sr No. 1056 - A 296 5175/3 Ue
 Date 1990-02-23 Rev A Pa Pa MTS19.3

6 APPLICATION EXAMPLES

The interfaces can be used in a variety of ways depending on the application. Below are some examples given.

The terminal equipment can be connected to these interfaces.

terminal interface



OP. TERMINAL

The op. terminal comprises a display for message presentation and editing and a keyboard for entering commands and information.

printer interface



PRINTER

Printer for printing out text or data collection unit sending text strings.

audio interface



AUDIO EQUIPMENT

Loudspeaker and microphone or handset with or without keys. Switches/buttons to control interface signals and/or serial data according to V24/V28.

emergency interface



EMERGENCY EQUIPMENT

Emergency unit, e.g. receiver for emergencies from pocket transmitter, or simple emergency buttons to initiate emergency signal (SOS) from MCU.

BilKort

Rapport

A 296 5153/3

Cantel Mobitex


Doc No. 1056 - A 296 5175/3 Ue
 Date 1990-02-23 Rev A P. F. 3
 MTS19.3

The following examples are described:

1. Microphone/loudspeaker
2. Handset with numeric and function keys
3. Handset with numeric and function keys, printer
4. Microphone/loudspeaker, control unit, printer
5. Op. terminal with small display, loudspeaker, printer
6. Op. terminal of ANSI type, microphone/loudspeaker, data collection unit
7. PC, microphone/loudspeaker
8. PC, handset with keys, printer, emergency equipment
9. PC, microphone/loudspeaker, control unit, printer, emergency equipment


(PTT = push-to-talk button)

1. Microphone/loudspeaker



Is able to send/receive speech. (Sends only to default receiver)

2. Handset with numeric and function keys



Is able to send/receive status and speech.

Buildings


Repro

A 292 51534

Cantel Mobitex


Doc No	1056 - A 296 5175/3 Use
DATE IN USE	1990-02-23
Rev	A
File No	MTS19.3

3. Handset with numeric and function keys, printer



Is able to send/receive status and speech and to receive text.

4. Microphone/loudspeaker, control unit, printer



Is able to send/receive status and speech and to receive text.

Bildzeit


Reprint

A 296 5175/3

Cantel Mobitex


Rev. 3/88
1056 - A 296 5175/3 Ue
Date: 1990-02-23 Rev. A File: MTS19.3

5. Op. terminal with small display, microphone/loudspeaker, printer



Is able to send/receive text, status and speech.

6. Op. terminal of ANSI type, microphone/loudspeaker, data collection unit.



Is able to send/receive text, data, status and speech. Data can be controlled and collected over radio in the form of text strings to and from the data collection unit.


Bildtext

Reprod

Cantel Mobitex -


Doc. No. 1056 - A 296 5175/3 Ue
 Doc. Date 1990-02-23 Rev. A PC No. MTS19.3

7. Personal computer as terminal, microphone/loudspeaker



Is able to send/receive text, data, status and speech.

8. Personal computer as terminal, handset with numeric and function keys, printer, emergency equipment



Is able to send/receive text, data, status, speech and emergency.

Booklet


Regred

A 292 11532

Cantel Mobitex-

Doc. No. 1056 - A 296 5175/3 Ue
 Date of Issue 1990-02-23 Rev. A
 EC 2.2 MTS19.3

9. Personal computer as terminal, microphone/loudspeaker, control unit, printer, emergency equipment



Is able to send/receive text, data, status, speech and emergency.

Bildschirm

Reprint

A 296 5155/3

Cantel Mobitex

No. 1056 - A 296 5175/3 Ue	
Date 1990-02-23	Rev A
P. No. MTS19.3	

7 MOBITEK TERMINAL SPECIFICATION REFERENCE LIST

This document includes a number of references, made to other sections in the terminal specification. The list below shows these references, together with the page(s) they are made on. Please note that a section could be referred to several times on the same page.

R1-06, 4
R1-09, 16

Below are the reference designations listed.

<u>Reference</u>	<u>Section</u>
R1-01	Arrangement of the documents
R1-02	MOBITEK System description
R1-03	General description of terminals
R1-04	Terminology
R1-05	References
R1-06	Network operator information
R1-08	Application layer
R1-09	Network layer
R1-11	Interface requirements, fixed terminals
R1-12	Other requirements, fixed terminals
R1-16	Link layer, mobile terminals
R1-17	Physical layer, mobile terminals
R1-18	Radio equipment, mobile terminals
R1-19	Other interfaces, mobile terminals
R1-20	Other requirements, mobile terminals

Block

Report

A/92 51530

REQUIREMENT SPECIFICATION 1(47)

Contract Reference ET/SYS PES	Functional Requirements ET/SYS PES	Req No 2/1056 - A 296 5175/2 Ue	
Contract/Contract - Description/Description ET/SYSC STT <i>ST</i>		Issue Date 1990-02-26 A	Rev. No MTS19A.2
Description Cantel Mobitex		Title MOBITEX Terminal Specification Mobitex ASynchronous Communication APPENDIX A, Commands	
<p>ABSTRACT</p> <p>This document specifies commands in the interface MOBITEX ASynchronous Communication(MASC) used between an application and a mobile terminal.</p>			
<p>Bidkort</p> <p>Regress</p>			

A 296 5153/3

Cantel Mobitex

No. 2/1056 - A 296 5175/2 Ue
Serial Date 1990-02-26 A
Rev. 1.1
MTS19A.2

TABLE OF CONTENTS

1	INFORMATION FRAME COMMANDS AND FUNCTIONS IN MOBILE TERMINAL	5
1.1	BASIC FUNCTIONS	5
1.2	TYPE TEST FUNCTIONS	6
1.3	TERMINAL SYSTEM FUNCTIONS	7
1.4	AUDIO FUNCTIONS	7
1.5	MANUAL RADIO FUNCTIONS	7
1.6	USER COMMANDS	7
2	BASIC FUNCTIONS (always to be implemented in MCU) ...	8
2.1	B-command (parameters for the MASC protocol)	8
2.2	M-command (send/receive MPAK via radio)	9
2.3	E-command (Error command or function)	10
2.4	N-command (return of MPAK not sent)	11
2.5	R-command (return of incorrect MPAK)	12
2.6	D-command (route received MPAKs to an output)	13
2.7	S-command (sends MPAK to the specified output)	15
2.8	T-command (request/transfer of emergency text)	16
2.9	U-command (send emergency signal SOS)	17
2.10	F P-command (MAN request)	18
2.11	F Q-command (device handling the MASC protocol)	18
2.12	F F-command (MCU in contact with mobitex)	18
2.13	F G-command (MCU not in contact with mobitex)	18
2.14	F H-command (MPAK sent over radio path)	18
2.15	F K-command (error message from MCU)	18
2.16	F O-command (prepare to close down)	18
2.17	F #-command (short number list)	18
3	TYPE TEST FUNCTIONS (always to be implemented in MCU) 19	
3.1	P-command (request/list of parameters)	19
3.2	PA-command (request/list of radio-parameters)	20
3.3	PA-command (request/list of identity-parameters)	22
3.4	PA-command (request/list of channel-parameters)	23
3.5	PA-command (request/list of roaming-parameters)	24
3.6	PA-command (request/list of test-parameters)	25
3.7	K-command (receive/transmit frequency number)	27
3.8	KA-command (receive/transmit frequency number)	28
4	TERMINAL SYSTEM FUNCTIONS (implemented according to application)	29
4.1	F B Change to MOBITEK operation mode	29
4.2	F C Set up a MOBITEK line connection	29
4.3	F D Set up a TELEPHONE line connection	29
4.4	F E Disconnect line connection	29
4.5	F F Contact with the MOBITEK network	29
4.6	F G No contact with MOBITEK network	29

Bidder:

Reprint

Cantel Mobitex

Doc No	2/1056 - A 296 5175/2 Ue
Doc Date	1990-02-26
Rev	A
Doc No	MTS19A.2

4.7	F H	MPAK sent by the radio to the network	30
4.8	F I	Cancell previously transmission of MPAK	30
4.9	F J	Print out current MANs in terminal	30
4.10	F K	Error message about a fault situation	30
4.11	F L	Activate external call indication	30
4.12	F M	Transmitter on/off	30
4.13	F N	Change to MANUAL RADIO mode	30
4.14	F O	Prepare for closing down MCU	30
4.15	F P	Terminal MAN request/answer	31
4.16	F Q	MASC device identity	31
4.17	F R	Change network identification	31
4.18	F S	Change AREA-LIST	31
4.19	F T	Change TEMP DEFAULT LIST	31
4.20	F V	Speech queue information	32
4.21	F #	Short number list	32

5 AUDIO FUNCTIONS (implemented according to application) 33

5.1	A B	Increase audio volume level	33
5.2	A C	Decrease audio volume level	33
5.3	A D	Loudspeaker on/off	33
5.4	A E	External call indication on/off	33
5.5	A H	Microphone (hook) on/off	33
5.6	A I	Transmit/receive switch	33
5.7	A J	Hands free	33
5.8	A V	Audio level order	33

6 MANUAL RADIO MODE FUNCTIONS (implemented according to application) 34

6.1	H A	Change to MOBITEK mode	34
6.2	H B	Increase audio volume level	34
6.3	H C	Decrease audio volume level	34
6.4	H D	Loudspeaker on/off	34
6.5	H E	External call indication on/off	34
6.6	H F	Call indication	34
6.7	H G	Squelch open/closed (toggle)	34
6.8	H H	Microphone (hook) on/off	34
6.9	H I	Transmit/receive switch	34
6.10	H J	Hands free	35
6.11	H K	Change to channel number	35
6.12	H L	Channel number indication	35
6.13	H M	Send selective call number	35
6.14	H N	Scan the specified channels	35
6.15	H O	Carrier indication	35
6.16	H P	Copy of own selective number	35
6.17	H Q	Transmit/receive indicator	35

7 Signalling between MCU and terminal equipment connected to the MASC interface. 37

7.1	MPAK received from the network	37
7.2	MPAK received from a terminal	38
7.3	Connection between the MCU and the terminal	39
7.4	Signalling between MCU and more than one terminal	40

Booklet

Report

Cantel Mobitex-

Doc. No. 2/1056 - A 296 5175/2 Ue		
Issue Date 1990-02-26	Rev. A	P. No. MTS19A.2

- 7.5 Description of a system with MASC interface.41
- 7.6 Fault situation in mobitex mobile stations.45
- 8 MOBITEK TERMINAL SPECIFICATION REFERENCE LIST47

Buildkeys

Regros

A 292 51530

Cantel Mobitex

No. 2/1056 - A 296 5175/2 Ue		
Date 1990-02-26	Rev A	File MTS19A.2

1 INFORMATION FRAME COMMANDS AND FUNCTIONS IN MOBILE TERMINAL

The commands, questions and replies available as information frames in MASC are summarized below and a description is given on the following pages.

1.1 BASIC FUNCTIONS

The following commands are always to be implemented in MCU.

- B parameters for the MASC protocol
- M send/receive MPAK via radio
- E error command or function
- N return of MPAK that has not been sent
- R return of incorrect MPAK
- D route received MPAKs to an output
- S send MPAK to the specified output
- T request or transfer of emergency text
- U send emergency signal (SOS-packet)
- F P terminal subscription MAN request and answer
- F Q device handling the MASC protocol
- F F MCU in contact with Mobitex network
- F G MCU has no contact with Mobitex network
- F H MCU inform that MPAK has been sent over the radio
- F K Error message from MCU
- F O Prepare to close down MCU
- F # Short number list request and answer

Signature

Reprod

Cantel Mobitex

No. 26
2/1056 - A 296 5175/2 Ue

Station Date
1990-02-26 A

File No.
MTS19A.2

1.2 TYPE TEST FUNCTIONS

The following commands are always to be implemented in MCU.

These functions should only be used during type testing and must be made inoperative for normal use.

All requested parameters which are available in the mobile should be included in all answers to type test functions.

Type test functions consist of commands belonging to specific radio protocol.

To separate mobile terminals with different radio protocol, the following commands are available:

P-command Used in mobile terminal at 1200bps.

K-command Used in mobile terminal at 1200bps.

PA-command Used in mobile terminal at 8/16kbps.

KA-command Used in mobile terminal at 8/16kbps.

Bildzeit

Regend

A 292 5155G

Cantel Mobitex

Mr. To: 2/1056 - A 296 5175/2 Ue
 Date: 1990-02-26 Rev: A P.O. No: MTS19A.2

1.3 TERMINAL SYSTEM FUNCTIONS

The following commands to be implemented in MCU, according to application.

F system control

1.4 AUDIO FUNCTIONS

The following commands to be implemented in MCU, according to application.

A controlling audio functions

1.5 MANUAL RADIO FUNCTIONS

The following commands to be implemented in MCU, according to application.

H controlling manual radio mode

1.6 USER COMMANDS

The following commands are free to use in applications. If used in application, contact mobile manufacturer about implementation in MCU.

X
 Y
 Z

Bridport

Reprod

A 297 51580

Cantel Mobitex -

Doc No. 2/1056 - A 296 5175/2 Ue
Serial Data 1990-02-26 Rev A
F. File MTS19A.2

2 BASIC FUNCTIONS (always to be implemented in MCU)

2.1 B-command (parameters for the MASC protocol)

Structure of text field:

B	SP	len	,	int
1	1	3	1	1-4

The data field is empty.

The B-command is used to set parameters for the protocol.

len is a 3-digit ASCII coded hex number which sets the maximum length of an information frame. This field should always be set to the maximum possible frame size, i.e. 47E (1150 decimal).

int is a maximum 4-digit ASCII coded hex number which sets the shortest time between two subsequent frames. The value is given in 10 ms increments. Default value is int = 0.

len and int are separated by a , (comma).

These parameters should be used as soon as they have been received.

The default values are used until a B-command has been received. A B-command should be the first frame sent after start up.

After receiving a B-command, the protocol should send a start of line signal to a higher protocol, to make clear that the connection is established and that the start sequence can follow.

Start of line signal is an internal signal between the link layer and higher layer.

Robbert

Repton

A 292 51530

Cantel Mobitex-

2/1056 - A 296 5175/2 Ue		
Doc. 9	Doc. 9	Doc. 9
1990-02-26	A	MTS19A.2

2.2 M-command (send/receive MPAK via radio)

Structure of text field:

M	SP	sequ-id
---	----	---------

1 1 1
SP indicate that a sequence number identity is added. If no SP then there is no sequ-id.

sequ-id is a 1-digit ASCII coded decimal number between 0 - 9. This sequence number is an identity of the MPAK.

Structure of data field:

MPAK
16-1120

MCU receiving the M-command sends MPAK via the radio path to the network. If M-command consists of a sequence number, the command FH indicating 'sent to mobitex network' is sent to terminal including the sequence number. Returned MPAK should also indicate sequence number.

MPAK received via the radio path, is sent over the interface to the terminal with the M-command (MAN is included in MPAK). The sequence number is not used in this M-command.

The received MPAK(to be sent via the radio path) should be a permitted MPAK concerning valid information in the MPAK head and MPAK length(sender, trafstate, class, packet type, size of MPAK).

Description of the different MPAKs can be found in " Network layer for terminals", see reference R1-09.

Blockers

Regard

Cantel Mobitex-

No. 2/1056 - A 296 5175/2 Ue		
Start Date	Rev	F. P.
1990-02-26	A	MTS19A.2

2.3 E-command (Error command or function)

Structure of text field:

E

1

The datafield may be used to send information about the error.

The E-command informs that the previously received command or function cannot be executed. (Command or function is not implemented in the receiving unit or included parameters are not accepted).

Bildkurz

Reprod

A 292 51533

Cantel Mobitex

No. 2/1056 - A 296 5175/2 Ue
 Datum: 1990-02-26 Rev: A Pl. P.: MTS19A.2

2.4 N-command (return of MPAK not sent)

Structure of text field:

N	SP	err-code	,	sequ-id
---	----	----------	---	---------

1 1 2 1 1
 SP indicate that an error code and sequence number are added. If no SP then there is no error code or sequence number.

err-code is a 2-digit ASCII coded hex number between 00 - FF. This error code is described in chapter "Fault situation in mobitex mobile stations".

sequ-id is a 1-digit ASCII coded decimal number between 0 - 9. This sequence number is an identity of the MPAK.

Structure of data field:

MPAK
16-1120

The N-command indicates to the terminal that the MPAK has not been sent over radio (communication failure or transmission interrupted by FO or FI-command).

In manual mode MPAK's should be returned by the N-command.

The MCU can indicate the reason, of not sending the MPAK over the radio, by adding the error code.

If a sequence number is indicated in the M-command, then this sequence number should also be in the N-frame.

If no error code or sequence number is valid, this parameter is not added.

Description of the different MPAKs can be found in " Network layer for terminals", see reference R1-09.

Bitkare

Regard

Cantel Mobitex -

Doc No. 2/1056 - A 296 5175/2 Ue
 Date: 1990-02-26 Rev. A P. 12
 MTS19A.2

2.5 R-command (return of incorrect MPAK)

When receiving the R-frame and not finding the fault, the receiving unit is supposed to make a restart by sending a B-frame.

Structure of text field:

R	SP	err-code	,	sequ-id
---	----	----------	---	---------

1 1 2 1 1
 SP indicate that an error code and sequence number are added. If no SP then there is no error code or sequence number.

err-code is a 2-digit ASCII coded hex number between 00 - FF. This error code is described in chapter "Fault situation in mobitex mobile stations".

sequ-id is a 1-digit ASCII coded decimal number between 0 - 9. This sequence number is an identity of the MPAK.

Structure of data field:

MPAK
16-1120

MCU uses the R-frame to return an MPAK which was received with the M-command and which does not comply with the format and the rules set by the network and link layers of MOBITEX terminals.

The MCU can indicate the reason, of not accepting the MPAK, by adding the error code.

If a sequence number is indicated in the M-command, then this sequence number should also be in the N-frame.

If no error code or sequence number is valid, this parameter is not added.

Description of the different MPAKs can be found in " Network layer for terminals", see reference R1-09.

Bidder:

Repro:

Cantel Mobitex-

No. 2/1056 - A 296 5175/2 Ue

Date 1990-02-26 A

F. M. MTSL9A.2

2.6 D-command (route received MPAKs to an output)

Structure of text field:

D	SP	MAN	,	UTG	,	TYP	,	SET
1	1	6	1	1	1	1	1	1

The data field is empty.

MAN is a 6-digit ASCII coded hex number stating the MAN for which MPAKs are to be routed to output UTG. MAN must be one of the possible MANS of the terminal (terminal MAN, group MAN or personal MAN).

UTG is a 1-digit ASCII-coded hex-number stating the output to which received MPAKs are to be routed.

TYP is a 1-digit ASCII-coded hex-number stating the type of MPAK which is to be routed to UTG.

SET is activating the function of set/reset these parameters.

UTG and TYP to be used as follows:

UTG = 0 default output
 1 printer
 2 audio
 3 emergency
 4 op. terminal:1 (MASC protocol)
 5 op. terminal:2
 6 op. terminal:3
 7 op. terminal:4
 8 op. terminal:5
 9 op. terminal:6

TYP = 0 no types(reset all)
 1 text
 2 data
 3 status
 4 line connection (speech)
 5 emergency
 6 all types except emergency
 7 extpak
 8 hpdata
 9 dteserv

SET = 0 set these parameters
 1 reset these parameters

Bildtext:

Reprod

Cantel Mobitex

Doc. No.
2/1056 - A 296 5175/2 Ue

Derivat. Data

1990-02-26 A

Th. Title

MTS19A.2

After receiving the D-command, MCU will route incoming MPAKs of the specified type and intended for the specified MAN to the function block which handles the communication (formatting etc) for the specified output. Thus it is possible to route MPAKs to several outputs e.g. to both printer and op.terminal.

When receiving a D-command with UTG="default output", the MCU resets all earlier D-commands for the specified MAN and specified TYP. If for example the TYP is "all types", all earlier D-commands concerning this specified MAN are reset and all types are sent to default output connection. If TYP is "no types", then all types is reset for this MAN and UTG.

It is possible to set or reset an earlier D-command, using the parameter set or reset.

After logout, a personal subscription should be removed from this list of routing MPAKs.

When power on, MCU sets up default outputs, e.g. text, data and status to op.terminal and line connection to audio interface.

All MPAK:DTESESV is routed to output, where terminal MAN is located(can be more than one).

Description of the different MPAKs can be found in " Network layer for terminals", see reference R1-09.

Bilkers:

Expro:

A 296 51533

Cantel Mobitex -

No. 2/1056 - A 296 5175/2 Ue	
Date: 1990-02-26	Ver. A
File: MTS19A.2	

2.7 S-command (sends MPAK to the specified output)

Structure of text field:

S	SP	UTG
1	1	1

Structure of data field:

-----	MPAK	-----
16-1120		

UTG is a 1-digit ASCII-coded hex-number which states to which output MPAK is to be sent.

When receiving the S-command, MCU sends MPAK to the output stated by UTG.

The parameter UTG is to be used as follows:

UTG = 0	direct to default output
1	printer
2	audio
3	emergency
4	op. terminal:1 (MASC protocol)
5	op. terminal:2
6	op. terminal:3
7	op. terminal:4
8	op. terminal:5
9	op. terminal:6
A	
B	
C	
D	
E	
F	printer, without printing the MPAK-head

Note 1: When the parameter UTG = F, the datafield consists of printable information except the MPAK-head. The printer should ignore the MPAK-head, this means that the information starts in octet 12.

Description of the different MPAKs can be found in "Network layer for terminals", see reference R1-09.

Bidder

Reprod

A 296 51593

Cantel Mobitex	No. 2/1056 - A 296 5175/2 Use	
	Serial Date 1990-02-26	Rev. A Fw. 1.2 MTS19A.2

2.8 T-command (request/transfer of emergency text).

Structure of text field, request:

T

1

Structure of data field for transfer of emergency text:

Emergency text

0 - 256

The T-command is used by the terminal to set up in MCU the dynamic text part of the emergency signal and as a request to MCU to return the stored emergency text. MCU uses the command as a reply to the request.

The emergency text field is the emergency text which is to be transferred. The emergency text can have up to 256 characters according to MOBITEK textcode. The first two octets of the text part are reserved to indicate the source of the emergency.

Source of emergency:

Emergency 1	= 01
Emergency 2	= 02
Emergency 3	= 03
Emergency 4	= 04
Handset	= 05
OP-terminal 1	= 06

When receiving a T-command with text part, MCU stores emergency text as the dynamic text part of a possible, future SOS packet. When receiving the T-command request, the stored emergency text is sent to the terminal by the T-command with text part.

Description of the emergency packets and procedures (SOS, SOSINFO etc) can be found in "Network layer for terminals", see reference R1-09.

Buildart:

Repro:

A10751530

Cantel Mobitex

Dr. No.
2/1056 - A 296 5175/2 Ue

Creation Date
1990-02-26 A

Rev. No.
MTS19A.2

2.9 U-command (send emergency signal SOS)

U

1

The U-command is used by the terminal to initiate the transmission of an emergency signal (SOS packet).

When receiving the U-command, MCU creates a SOS packet and sends it to the network. The text part of SOS is made up by the stored emergency text (received earlier by the T-command) where the identity of the emergency source is inserted as the first two octets.

Description of the emergency packets and procedures (SOS, SOSINFO etc) can be found in "Network layer for terminals", see reference R1-09.

When MCU is in manual mode, it is recommended that the MCU return to MOBITEK operating mode and sends the packet MPAK:SOS.

Brickware

Reprod.

A 292 51533

Cantel Mobitex

2/1056 - A 296 5175/2 Ue

Date Recd 1990-02-26 A

F. No. MTS19A.2

2.10 F P-command (MAN request)

The FP-command is described in chapter TERMINAL SYSTEM FUNCTIONS F-command.

2.11 F Q-command (device handling the MASC protocol)

The FQ-command is described in chapter TERMINAL SYSTEM FUNCTIONS F-command.

2.12 F F-command (MCU in contact with mobitex)

The FF-command is described in chapter TERMINAL SYSTEM FUNCTIONS F-command.

2.13 F G-command (MCU not in contact with mobitex)

The FG-command is described in chapter TERMINAL SYSTEM FUNCTIONS F-command.

2.14 F H-command (MPAK sent over radio path)

The FH-command is described in chapter TERMINAL SYSTEM FUNCTIONS F-command.

2.15 F K-command (error message from MCU)

The FK-command is described in chapter TERMINAL SYSTEM FUNCTIONS F-command.

2.16 F O-command (prepare to close down)

The FO-command is described in chapter TERMINAL SYSTEM FUNCTIONS F-command.

2.17 F #-command (short number list)

The F#-command is described in chapter TERMINAL SYSTEM FUNCTIONS F-command.

Buckart

Reprod

A 292 51553

Cantel Mobitex

No. 2/1056 - A 296 5175/2 Ue
 Datum 1990-02-26 Rev. A Pl. No. MTS19A.2

3 TYPE TEST FUNCTIONS (always to be implemented in MCU)

These functions should only be used during type testing and must be made inoperative for normal use.

3.1 P-command (request/list of parameters)

Structure of text field in request for internal parameters from terminal to MCU:

P
1

Structure of text field in reply from MCU to terminal (list of parameters):

P SP list of parameters
1 1 >=1

The data field is empty.

The P-command is used by the terminal to request radio protocol parameters and by MCU to send these parameters as a reply to the request.

The list of parameters consists of a number of ASCII coded hex numbers separated by , (comma). The parameters to be sent in the following order:

Parameter	No of bytes
Slot length	1
Timeout short	1
Timeout long	1
Free slots	1
Rand slots	1
Current base (internal parameters in MCU)	2
Chosen slot (internal parameters in MCU)	1
Max access	1
Max rep	1
Priority (internal parameter in MCU)	1
Sequential number up (term.MAN)	1
Sequential numbers down (term.MAN+15 groups)	16
Upfreq (current)	2
Dofreq (current)	2
Flexlist (MAN 1 - 7)	21
Grouplist (MAN 1-15)	45

The meaning and structure of the different parameters can be found in "Data link layer for terminals", see reference R1-16.

Cantel Mobitex

No. 2/1056 - A 296 5175/2 Ue
 Date 1990-02-26 Rev. A File MTS19A.2

3.2 PA-command (request/list of radio-parameters)

Structure of text field in request for internal parameters from terminal to MCU:

PA01

4

Structure of text field in reply from MCU to terminal (list of parameters):

PA01 SP list of parameters

4

1

>=23

The data field is empty.

The PA-command is used by the terminal to request radio protocol parameters and by MCU to send these parameters as a reply to the request.

The list of parameters consists of a number of ASCII coded hex numbers separated by , (comma). If a parameter is not available or not given, this parameter is not included. The parameters to be sent in the following order:

Parameter	No of bytes
Timeout	1
Slot_length	1
Free_slots	1
Rand_slots	1
Max_rep	1
Max_access	1
Max_speech	1
Txpow	1
Slev1	1
Slev2	1
Scan_time	1
Bad_base	1
Good_base	1
Choose_base	1
Better_base	1
Qpos	1
Current_base (internal parameter in MCU)	2
Chosen_slot (internal parameter in MCU)	1
Priority (internal parameter in MCU,current value)	1
Upfreq (current value)	2
Dofreq (current value)	2
Access_channel_upfreq (current value)	2
Access_channel_dofreq (current value)	2
Network_id (mobile tx)	2
Network_id (mobile rx)	2
Area_id	1

Cantel Mobitex -

Nr. No.		
2/1056 - A 296 5175/2 Ue		
Creation Date	Rev	Pl. F.
1990-02-26	A	MTS19A.2

Example of PA01-command:

MCU

TERMINAL

PA01

PA01 01,02,03,04,05,06,07,08,09,10,11,12,13,14,15,16,0017,
18,19,0020,0021,0022,0023,0024,0025,26

or

PA01 01,02,03,04,,,,,,,,,,,,,,,,,,,,,26

The meaning and structure of the different parameters can be found in "Data link layer for terminals", see reference R1-16.

Diskette

Reprod

Cantel Mobitex -

No. 2/1056 - A 296 5175/2 Ue			
<table border="1"> <tr> <td>Start Date 1990-02-26</td> <td>Rev A</td> <td>Ed. No. MTS19A.2</td> </tr> </table>	Start Date 1990-02-26	Rev A	Ed. No. MTS19A.2
Start Date 1990-02-26	Rev A	Ed. No. MTS19A.2	

3.3 PA-command (request/list of identity-parameters)

Structure of text field in request for identity parameters from terminal to MCU:

PA02

4

Structure of text field in reply from MCU to terminal (list of parameters):

PA02 SP list of parameters

4

1

>=40

The data field is empty.

The P-command is used by the terminal to request radio protocol parameters and by MCU to send these parameters as a reply to the request.

The list of parameters consists of a number of ASCII coded hex numbers separated by , (comma). If a parameter is not available or not given, this parameter is not included. The parameters to be sent in the following order:

<u>Parameter</u>	<u>No of bytes</u>
Terminal MAN	3
ESN	4
Flexlist (MAN 0 - 7)	21
Grouplist (MAN 1-15)	45
Sequential number up (term.MAN)	1
Sequential numbers down (term.MAN+15 groups)	16

Example of PA02-command:

```

MCU                                TERMINAL
    <----- PA02
PA01 000001,00000002,000003,000004,000005,,,,,000010,,,,
      ////////////////26,27/////////////////42
      ----->
  
```

The meaning and structure of the different parameters can be found in "Data link layer for terminals", see reference R1-16.

Bildschirm

Reprint

Cantel Mobitex

2/1056 - A 296 5175/2 Ue
 1990-02-26 A MTS19A.2

3.4 PA-command (request/list of channel-parameters)

Structure of text field in request for parameters from terminal to MCU:

PA03

4

Structure of text field in reply from MCU to terminal (list of parameters):

PA03 SP list of parameters

4 1 >=4

The data field is empty.

The P-command is used by the terminal to request radio protocol parameters and by MCU to send these parameters as a reply to the request.

The list of parameters consists of a number of ASCII coded hex numbers separated by , (comma). If a parameter is not available or not given, this parameter is not included. The parameters to be sent in the following order:

Parameter	No of bytes
Channel list (current)	1
Number Of channels in channel_list (total)	2
Number of channels in this command	1
Channel #1 - upfreq	2
Channel #1 - dofreq	2
Channel #2 - upfreq	2
Channel #2 - dofreq	2

Channel-list = 01(hex) DEFAULT LIST
 02(hex) CURRENT LIST
 03(hex) TEMP_DEFAULT LIST

All parameters in this command is a number of ASCII coded hex number.

Example: Answer with a default list of 100 channels.

PA03 01,0064,3C,0123,0123,.....
 PA03 01,0064,28,0123,0123,.....

The meaning and structure of the different parameters can be found in "Data link layer for terminals", see reference R1-16.

Cantel Mobitex

Doc No	2/1056 - A 296 5175/2 Ue
Doc Date	1990-02-25
Rev	A
Rev Date	MTS19A.2

3.5 PA-command (request/list of roaming-parameters)

Structure of text field in request for parameters from terminal to MCU:

PA05

4

Structure of text field in reply from MCU to terminal (list of parameters):

PA05 SP list of parameters

4

1

>=4

The data field is empty.

The P-command is used by the terminal to request radio protocol parameters and by MCU to send these parameters as a reply to the request.

The list of parameters consists of a number of ASCII coded hex numbers separated by , (comma). If a parameter is not available or not given, this parameter is not included. The parameters to be sent in the following order:

Parameter	No of bytes
Number of bases in table	1
Current base id	2
roaming_value	1
Base_id	2
roaming_value	1
.	.
.	.

Example: Mobile terminal with current_base(23) choosen.

PA05 03,0023,09,0025,02,0019,04

Mobile terminal with no choosen current_base.

PA05 03,,,0023,02,0019,01

The meaning and structure of the different parameters can be found in "Data link layer for terminals", see reference RI-16.

Signature

Revised

Cantel Mobitex

No. 2, 2/1056 - A 296 5175/2 Ue
 Docum. Date 1990-02-26 A Rev. Pn. Pn. MTS19A.2

3.6 PA-command (request/list of test-parameters)

Structure of text field in request for parameters from terminal to MCU:

PA06	SP	function	,	parameter
4	1	2		>= 0

Structure of text field in reply from MCU to terminal (list of parameters):

PA06	SP	function	,	list of parameters
4	1	2	1	>=1

The data field is empty.

The P-command is used by the terminal to request for radio protocol parameters and by MCU to send these parameters as a reply to the request.

The function is a ASCII coded decimal number between 00 - 99, describing separate request or answer. Those functions are described below.

The list of parameters consists of a number of ASCII coded hex numbers separated by , (comma). If a parameter is not available or not given, this parameter is not included. The parameters to be sent in the following order:

Function:

No:	description:	parameter:
01	current_base(Req/ans)	in the answer, the current_base is in ASCII coded hex number.
02	set current_base	Current base in ASCII coded hex number.
03	disable base search mode	-
04	enable base search mode	-
05	clear dynamic memory	-
06	enable copy REPMAP when receiving or sending the frame <REB>	An ASCII coded hex number for each bit set to "1" indicating repetition in the frame <REB>. A comma is placed between each number.
07	disable copy REPMAP	-
08	enable loudspeaker	-
09	disable loudspeaker	-

Blocker

Report

A-292 51592

Cantel Mobitex

2/1056 - A 296 5175/2 Ue

1990-02-26 A MTS19A.2

No: **description:**
10 copy NUMRET

parameter:

The parameter NUMRET in ASCII coded hex number, stating the number of retransmissions.

- 11 enable transmitting the scrambling signal over the radio(see ref R1-17) -
- 12 disable transmitting the scrambling signal over the radio(see ref R1-17) -
- 13 copy speech parameters.

Subscriber, con-id, upfreq, dofreg. Parameters in ASCII coded hex number separated by a comma.

Example: MCU

Terminal

PA6 01,1234

<----- PA6 01

<----- PA6 02,1234

PA6 06,6,23,35

<----- PA6 06

<----- PA6 07

<----- PA6 08

<----- PA6 09

PA6 10,12

<----- PA6 10

<----- PA6 12

<----- PA6 11

<----- PA6 13

PA6 13,123456,12,1111,2222

The meaning and structure of the different parameters can be found in "Data link layer for terminals", see reference R1-16.

Boisort

Reprod

A 292 51553

Cantel Mobitex -

Rev. 2/1056 - A 296 5175/2 Ue

Drawn Date 1990-02-26 Rev A PC File MTS19A.2

3.7 K-command (receive/transmit frequency number)

Structure of text field to frequency number reception:

KM	SP	parameter
2	1	3

Structure of text field to frequency number transmission:

KS	SP	parameter
2	1	3

The data field is empty in both commands.

The parameter field states the frequency number. The number is given as the ASCII codes of the hexadecimal digits of the frequency number in hexadecimal notation.

The K-command is used to set up the frequency pair to be used for reception and transmission. The frequency number range is hexadecimal 001 - 617 (decimal 0001 - 1559).

If the frequency number included in the frame is not implemented in the equipment, MCU will respond with an E-frame (error function).

For correspondence between frequency number and frequency, see reference RI-06 .

Buildings

Reprod

A 292 51530

Cantel Mobitex

Sr. No. 2/1056 - A 296 5175/2 Ue

Comm Date 1990-02-26 Rev A

P. No. MTS19A.2

3.8 KA-command (receive/transmit frequency number)

Structure of text field to frequency band:

KAB	SP	FBI
-----	----	-----

3 1 1

Structure of text field to frequency number reception:

KAM	SP	parameter
-----	----	-----------

3 1 4

Structure of text field to frequency number transmission:

KAS	SP	parameter
-----	----	-----------

3 1 4

The data field is empty in all commands.

The parameter FBI states the Frequency band and bitrate. The parameter is given as the ASCII coded hex number of the parameter FBI in upfreq and dofreg.

The parameter field states the frequency number. The number is given as the ASCII codes of the hexadecimal digits of the frequency number in hexadecimal notation.

The KA-command is used to set up the frequency pair to be used for reception and transmission. The frequency number range is hexadecimal 0001 - 1FFF (decimal 0001 - 8191).

If the frequency number included in the frame is not implemented in the equipment, MCU will respond with an E-frame (error function).

For correspondence between frequency number and frequency, and frequency band(FBI) and bitrate, see reference R1-06.

Bildtext

Reprod

A 292 51540

Cantel Mobitex

2/1056 - A 296 5175/2 Ue
1990-02-26 A MTS19A.2

4 TERMINAL SYSTEM FUNCTIONS (implemented according to application)

4.0 F-command (system control)

The F-command is used from op. terminal to execute the specified function in MCU.
The F-command is used by MCU to send information to the terminal.

Structure of the text field:

F	SP	list of parameters
1	1	>=1

The data field is used only in the FT- and F#-frame with list of channel numbers and short numbers.

The list of parameters is a list of one-character function codes and parameters in ASCII code according to the following table:

- 4.1 F B Change to MOBITEX operation mode
MCU sends an ACTIVE packet to the network
- 4.2 F C Set up a MOBITEX line connection
parameters MAN1,MAN2
MAN is a 6-digit ASCII-coded hex-number.
MAN1=sender, MAN2=addressee.
MCU creates and sends a CONREQ packet to the network.
- 4.3 F D Set up a TELEPHONE line connection
Parameters MAN,TEL
MAN is a 6-digit ASCII-coded hex-number (sender).
TEL is the desired number in the telephone network.
The number is given in MOBITEX textcode, right justified in a 20 character field with leading spaces according to the corresponding field of EXTCONREQ.
MCU creates and sends an EXTCONREQ packet to the network.
- 4.4 F E Disconnect line connection
MCU creates and sends a DISCON packet to the network.
- 4.5 F F Contact with the MOBITEX network
MCU is in contact with the MOBITEX network.
- 4.6 F G No contact with MOBITEX network
MCU has no contact with the MOBITEX network and is trying to establish contact again (roaming procedure started).

Bildzeit

Repro

A 292 51535

Cantel Mobitex

No. 26
2/1056 - A 296 5175/2 Use

Issue Date 1990-02-26 Rev. A F. No. MTS19A.2

- 4.7 F H MPAK sent by the radio to the network
Parameter SEQU-ID
MCU inform that MPAK has been sent to the network.
The parameter SEQU-ID is added if SEQU-ID was included in the M-command. SEQU-ID is a 1-digit ASCII coded decimal number between 0 - 9.
- 4.8 F I Cancel previously transmission of MPAK
Previously activated transmission of MPAK is cancelled. The MPAK to be returned to the terminal by an N-frame.
- 4.9 F J Print out current MANs in terminal
Print current MANs in terminal on printer (terminal subscription MAN, group MANs (group list) and personal subscription MANs (flex_list) in that order.
- 4.10 F K Error message about a fault situation
Parameter XX
Error message where XX is the error number in ASCII coded hex digits 00-FF (0-255).
Information from MCU about a fault situation. Description of the meaning fault situation see chapter "Fault situation in mobitex mobile stations".
- 4.11 F L Activate external call indication
Activate external indication (e.g. horn) for 2 seconds.
- 4.12 F M Transmitter on/off
Parameter X
X = character 0 ----> transmitter off
X = character 1 ----> transmitter on
- 4.13 F N Change to MANUAL RADIO mode
MCU sends an INACTIVE packet to the network.
- 4.14 F O Prepare for closing down MCU
From terminal: Command to prepare closing down (switching off) the MCU.
MCU clears buffers for stored MPAKs. MPAKs to be transmitted to the network are transmitted. All other MPAKs are sent to the terminal. If no contact with the network, MPAK's to the network are returned by the N-command.
Then MCU sends an INACTIVE packet to the network. Finally MCU confirms that it is empty by sending a FO-frame to the terminal.
From MCU: MCU is empty and ready to be switched off.

Note: If more than one device connected, the FO-command from the MCU should be sent to all devices.

Indikator

Reproce

Cantel Mobitex

No. 2/1056 - A 296 5175/2 Use
 Date 1990-02-26 Rev A File MTS19A.2

4.15 F P Terminal MAN request/answer
 Request from terminal for terminal subscription MAN.

F PXXXXXX Terminal subscription MAN from MCU to terminal as response to the request.
 XXXXXX is the MAN as a 6 digit ASCII coded hex number.

4.16 F Q MASC device identity
 Parameter XXX
 Type of device handling the MASC protocol.
 F_Q(MASC_DEVICE) is information to other units connected to this MASC interface.
 XXX = MCU
 XXX = MOX

4.17 F R Change network identification
 Parameters XXXX,YYYY
 Send this new network identification to data link layer(see reference R1-16).
 XXXX = is new network ID for mobile tx in ASCII coded hex number.
 YYYY = is new network ID for mobile rx in ASCII coded hex number.

4.18 F S Change AREA-LIST
 Parameters BITMAP,COM
 Send this new area list to data link layer(see reference R1-09 and R1-16).
 BITMAP = see AREALIST reference R1-09.
 COM = see Command reference R1-09.
 Parameters BITMAP and COM is in ASCII coded hex digits.

4.19 F T Change TEMP_DEFAULT_LIST
 Parameters TNUM,NUM,M
 Send this new channel list to data link layer(see reference R1-09 and R1-16).
 TNUM = Total number of channels. If TNUM is zero, delete TEMP_DEFAULT_LIST and return to DEFAULT_LIST.
 NUM = Number of channels in this command
 M = 0 No more channels
 M = 1 More channels in next command.
 Parameters TNUM, NUM and M is in ASCII coded hex digits.
 The list itself is sent in the data field of the frame. The list is described in reference R1-16.

Bitmask

Repeat

Cantel Mobitex

No. 21	2/1056 - A 296 5175/2 Ue	
Issue Date	1990-02-26	Rev. A
File No.	MTS19A.2	

- 4.20 F V Speech queue information
Parameter XX
Information about queue-position when waiting for speech to be connected.
XX is the speech-queue number in ASCII coded hex digits in the range 00-FF.

- 4.21 F # Short number list
Request from terminal for short number list.

F #XX
List of short numbers from MCU or terminal. The list contains short numbers which are common to MCU and all connected terminals (general short numbers). It is sent by the terminal to set up this list and by MCU as a reply to the F# request frame from the terminal.
XX is the number of short numbers in the list in ASCII coded hex digits in the range 00-32 (0-50 decimal).
The list itself is sent in the data field of the frame. In the list, the actual numbers corresponding to each short number from 1 and up are given as ASCII coded digits with a maximum of 20 digits each. The numbers are separated by the character , (comma).

NOTE: Only the 'one-character function' can be included in an F-command, e.g. F P123456.

Description of the different packets and procedures mentioned here can be found in reference R1-09 and R1-16.

Bildspur

Reprint

2/1056 - A 296 5175/2 Ue		
Drawn Date	Rev	Ed File
1990-02-26	A	MTS19A.2

5.0 A-command (controlling audio functions).

A	SP	list of parameters
---	----	--------------------

The data field is empty.

The A-command is used to control the audio equipment.

The list of parameters is a list of one-character function codes and parameters in ASCII code according to the following table:

- ```

5.1 A B Increase audio volume level
5.2 A C Decrease audio volume level
5.3 A D Loudspeaker on/off
 Parameter X
 X = character 0 --> off
 X = character 1 --> on
5.4 A E External call indication on/off
 Parameter X
 X = character 0 --> off
 X = character 1 --> on
5.5 A H Microphone (hook) on/off
 Parameter X
 X = character 0 --> off
 X = character 1 --> on
5.6 A I Transmit/receive switch
 Parameter X
 X = character 0 --> transmit
 X = character 1 --> receive
5.7 A J Hands free.
 Parameter X
 X = character 0 --> off
 X = character 1 --> on
5.8 A V Audio level order.
 Parameter X
 X=data, ASCII coded hex digit 0-F.

```

NOTE: Only the 'one-character function' can be included in an A-command, e.g. A E0.

# Cantel Mobitex

2/1056 - A 296 5175/2 Ue

1990-02-26 A

MTS19A.2

## 6 MANUAL RADIO MODE FUNCTIONS (implemented according to application)

### 6.0 H-command (controlling manual radio mode)

Structure of text field:

|   |    |                    |
|---|----|--------------------|
| H | SP | list of parameters |
| 1 | 1  | >=1                |

The data field is empty.

The H-command is used to control the radio equipment when in manual radio mode.

The list of parameters field is a list of one-character function codes and parameters in ASCII code according to the following table:

- 6.1 H A Change to MOBITEX mode.  
MCU sends an ACTIVE packet to the network.
- 6.2 H B Increase audio volume level.
- 6.3 H C Decrease audio volume level.
- 6.4 H D Loudspeaker on/off.  
Parameter X  
X = character 0 --> off.  
X = character 1 --> on.
- 6.5 H E External call indication on/off.  
Parameter X  
X = character 0 --> off.  
X = character 1 --> on.
- 6.6 H F Call indication  
Parameter X  
X = character 0 --> no call received  
X = character 1 --> call received
- 6.7 H G Squelch open/closed (toggle).
- 6.8 H H Microphone (hook) on/off.  
Parameter X  
X = character 0 --> off.  
X = character 1 --> on.
- 6.9 H I Transmit/receive switch  
Parameter X  
X = character 0 --> transmit  
X = character 1 --> receive

Disksort

Reprod

A 292 51530

# Cantel Mobitex

|       |                          |
|-------|--------------------------|
| ST No | 2/1056 - A 296 5175/2 Ue |
| Rev   | 1990-02-26 A             |
| Rev   | MTS19A.2                 |

- 6.10 H J Hands free.  
Parameter X  
X = character 0 --> transmit  
X = character 1 --> receive
- 6.11 H K Change to channel number.  
Parameter XX  
Change to channel number XX where XX is the desired channel number in ASCII coded hex digits in the range 01-63 (1-99 decimal).
- 6.12 H L Channel number indication.  
Parameter XX  
XX is the channel number in ASCII coded hex digits in the range 01-63 (1-99 decimal). Will be sent when start up or a changed channel occur.
- 6.13 H M Send selective call number.  
Parameter XXXXXXXX  
Send selective call number XXXXXXXX on current channel.  
X is an ASCII coded digit 0-9.  
If the number of digits is less than 7, the number will be left justified and the XXXXXXXX-field will be filled with trailing spaces (hex code 20).
- 6.14 H N Scan the specified channels.  
Parameter XX..XX  
XX..XX is a list of maximum 8 channel numbers in a field of 16 octets. Each XX represents a channel number in ASCII coded hex digits in the range 01-63 (1-99 decimal). If the number of channels is less than 8, the field will be filled with trailing spaces (hex code 20).  
The specified channels are scanned for carrier or selective call.
- 6.15 H O Carrier indication.  
Parameter X  
The frame must be transmitted only when there is a change between sensing carrier and sensing no carrier. The carrier sense itself should be updated at least once per second.  
X = character 0 --> no carrier  
X = character 1 --> carrier
- 6.16 H P Copy of own selective number.  
Parameter XXXXXXXX  
Copy of the own selective call number.  
X is an ASCII coded digit 0-9.  
If the number of digits is less than 7, the number will be left justified and the XXXXXXXX-field will be filled with trailing spaces (hex code 20).
- 6.17 H Q Transmit/receive indicator  
Parameter X

Buildcode

Reprod

A 292 51333

# Cantel Mobitex-

|                              |     |          |
|------------------------------|-----|----------|
| No. 2/1056 - A 296 5175/2 Ue |     |          |
| Version Date                 | Rev | Ed. Date |
| 1990-02-26                   | A   | MTS19A.2 |

X = S ---> transmitting (sending)  
X = M ---> receiving (monitoring)

Note: Only the 'one-character function' can be included in an H-command, e.g. H P1234567.

Buildings

Report

A 292 5155/3

# Cantel Mobitex

|             |                          |          |  |
|-------------|--------------------------|----------|--|
| No. N°      | 2/1056 - A 296 5175/2 Ue |          |  |
| Series Date | Rev                      | F. F. J. |  |
| 1990-02-26  | A                        | MTS19A.2 |  |

## 7 Signalling between MCU and terminal equipment connected to the MASC interface.

### 7.0 General

These chapters have been included because the network layer may be differently implemented in different terminal equipment. For any terminal equipment, connected to MCU via the MASC interface, the MCU can be considered as a DCE for connection to the MOBITEK network. A terminal can have a complete MOBITEK network layer or a simplified network layer, using different commands of the MASC protocol.

A terminal connected to the MCU must have the same terminal MAN number as the MCU.

The terminal MAN must be associated to at least one output connection, either a MASC interface or another connection (e.g. a handset or a printer).

All messages to groups, belonging to terminal MAN, should be directed to the same output connection(s) as terminal MAN.

The MCU has the responsibility towards the MOBITEK network according to the network layer.

In order to get the MOBITEK network layer in MCU and the terminal to interact correctly, the following chapters have to be considered.

### 7.1 MPAK received from the network

ROAMORD, FLEXREQ, INFOREQ and ESNREQ will be completely handled within the MCU without notifying any connected terminal.

DIE and LIVE will be completely handled within the MCU but notified by FK-command(if handled) to connected terminals.

All other correctly received MPAKs will, after normal handling in the MCU, be sent to the output connection where the addressed MAN is located.

A fixed terminal can't receive a CONORD, therefore CONORD is to be converted to a CONREQ by the MCU.

Bildern

Begeet

# Cantel Mobitex

2/1056 - A 296 5175/2 Ue  
 1990-02-26 A MTS19A.2

## 7.2 MPAK received from a terminal

Normally, if the MPAK passes the checks in the MCU, the MPAK will be sent to the network. The MCU should react and enter states as if the MPAK was generated in the MCU (e.g. on CONREQ the MCU should enter a state for call in progress, and should also act according to the radio protocol for sending such MPAK).

If the checks fail, the MPAK should be returned to the terminal by an R-frame.

For the following MPAK's, however, the MCU should have a special treatment.

|                                    |                                                                                                   |
|------------------------------------|---------------------------------------------------------------------------------------------------|
| CONREA                             | to be treated as a hook off-signal                                                                |
| DISCON                             | to be treated as a hook on-signal                                                                 |
| FLEXREQ                            | if the personal subscription already exist in flexlist the terminal will be informed by FK-frame. |
| FLEXLIST                           | to be returned to the terminal by an R-frame.                                                     |
| BORN,<br>ROAM,<br>INFO,<br>ESNINFO | to be returned to the terminal by an R-frame.                                                     |
| LINEON,<br>LINEOFF                 | to be returned to the terminal by an R-frame.                                                     |

8ddkrt

8aprod

A 296 5175/2



## Cantel Mobitex-

|              |                          |
|--------------|--------------------------|
| Doc No       | 2/1056 - A 296 5175/2 Ue |
| Version Date | 1990-02-26 A             |
| E. F.        | MTS19A.2                 |

### 7.3 Connection between the MCU and the terminal

The terminal is supposed to have a list of groupMAN's and a list of personal subscriptions (flexlist). In order to get the lists in the MCU equivalent to the list in the terminal, the following should be considered.

Each time the link layer connection is established (by exchange of B-frames), the terminal will send:

- MANREQ (command F P) to request MCU for the terminal MAN

To answer this, the MCU sends the terminal MAN in the command MAN (command F P). This answer should be sent immediately or, if another frame is currently being transmitted by the MCU, immediately after the transmission is completed. After that, the MCU will send the MASC\_DEVICE command (F Q).

The MCU should send:

- GROUPLIST to set the list of groupMAN in the terminal
- FLEXLIST to set the flexlist in the terminal.

The terminal will then handle the flexlist according to the specification, see R1-09.

Bundart


Repro:

A 222 51533


# Cantel Mobitex

Doc. No. 2/1056 - A 296 5175/2 Ge  
Doc. Date 1990-02-26 Rev A P.C. File MTS19A.2

Example of start sequence when MCU starts.



Example of start sequence when TERMINAL starts:



Note: Packets above the dotted line in each sequence belong to the link layer, and packets below the dotted line belong to the network layer.

## 7.4 Signalling between MCU and more than one terminal

The MCU may have more than one MASC interface.

All MASC interfaces should have the same start sequence as described in chapter "Connection between the MCU and the terminal".

The MCU handles all MPAKs and messages to different output connections where the MAN is located.

Builderc


Reprint

# Cantel Mobitex

|            |                          |     |   |
|------------|--------------------------|-----|---|
| Doc No     | 2/1056 - A 296 5175/2 Ue |     |   |
| Issue Date | 1990-02-26               | Rev | A |
| File No    | MTS19A.2                 |     |   |

## 7.5 Description of a system with MASC interface.


### 7.5.1 MCU connected to one terminal.



MCU handles the terminal MAN, group MAN and personal MAN with GROUPLIST and FLEXLIST in the start sequence.

After the start sequence, all MPAKs are routed to the terminal.

### 7.5.2 MCU connected to two terminals.



MCU handles the terminal MAN, group MAN and personal MAN with GROUPLIST and FLEXLIST in the start sequence.

All terminals that have other terminal equipment connected, will have the same start sequence as described in chapter "Connection between the MCU and the terminal". These terminals should be considered as an MCU by the connected units.

After the start up sequence all MPAKs are routed to the current terminal.

Blanket

Reprints

# Cantel Mobitex™

Doc No 2/1056 - A 296 5175/2 Ue

Doc Date 1990-02-26


Rev A

Pl. No MTS19A.2

Examples of start sequences.

## EXAMPLE 1.

Lists when MAN are correct and MCU starts.



**Note:** Packets above the dotted line in the sequence belong to the link layer, and packets below the dotted line belong to the network layer.

Blockart

Report


A 296 51533

# Cantel Mobitex

No. 2  
2/1056 - A 296 5175/2 Ue  
Date: 1990-02-26 1 Rev: A 2 Rev: MTS19A.2

## EXAMPLE 2


MAN1 is only in UNIT1 and TERMINAL1. MAN2 is only in MCU.  
MAN1 and MAN2 are personal subscriptions not included in MCU's  
Flexlist.



**Note 1:** The terminal/unit1/unit2 will replace former lists with these new lists. When replacing the flexlist the terminal/unit1/unit2 will decide if MAN1 and MAN2 are connected or disconnected. If connected, a loginreq is sent from MAN1 in unit1 and a loginreq sent from MAN2 in unit2. If not connected an presentation of the logout is sent to the user.

**Note 2:** The application in UNIT1 has to send LOGINREQ for MAN1 if it wishes to keep MAN1.

**Note 3:** Packets above the dotted line in the sequence belong to the link layer, and packets below the dotted line belong to the network layer.



BitRate

Speed

A 296 5175/2


# Cantel Mobitex

No. 2/1056 - A 296 5175/2 Ue

Start Date 1990-02-26 Rev A Pl. No. MTS19A.2

## EXAMPLE 3.

TERMINAL1 is starting the connection.



**Note:** Packets above the dotted line in the sequence belong to the link layer, and packets below the dotted line belong to the network layer.

Boldnet

Supers

**Cantel Mobitex**

|              |                          |
|--------------|--------------------------|
| No.          | 2/1056 - A 296 5175/2 Ue |
| Version Date | 1990-02-26 A             |
| Rev.         | MTS19A.2                 |

**7.6 Fault situation in mobitex mobile stations.**

This is a recommendation of error message from the MCU to the connected unit using a MASC interface. This error message is a response for a fault situation and sent as an error number in the FK-command (see chapter "Information frame commands and functions").

Error numbers 0 - 4F is reserved for specific meaning. Error numbers 50 - FF is free to use.

New meaning of error numbers is described in R1-06.

Error no: meaning:

|   |                                                |                                                                             |
|---|------------------------------------------------|-----------------------------------------------------------------------------|
| 0 | reserved                                       |                                                                             |
| 1 | DIE mode.                                      | An MPAK:DIE is received. No user traffic can be sent from the MCU.          |
| 2 | LIVE mode.                                     | An MPAK:LIVE is received..User traffic can be sent from the MCU.            |
| 3 | SPEECH mode.                                   | The MCU is in speech mode and can not send any traffic except MPAK:CSUBCOM. |
| 4 | MANUAL mode.                                   | The MCU is in the manual mode and not in contact with mobitex network.      |
| 5 | reserved                                       |                                                                             |
| 6 | reserved                                       |                                                                             |
| 7 | reserved                                       |                                                                             |
| 8 | reserved                                       |                                                                             |
| 9 | reserved                                       |                                                                             |
| A | Receiver buffer full, waiting for free buffer. |                                                                             |
| B | Buffer/memory free.                            |                                                                             |
| C | No memory, waiting for more memory.            |                                                                             |
| D | reserved                                       |                                                                             |
| E | reserved                                       |                                                                             |
| F | reserved                                       |                                                                             |

Bokkore

Bapoon

A 292 51534

## Cantel Mobitex -

№. №  
2/1056 - А 296 5175/2 Уе

|                  |        |
|------------------|--------|
| Date: 1990-02-26 | Rev: A |
|------------------|--------|

MTS19A.2

Error no:      meaning:

- ```

10      Returned MPAK during die mode.
11      Returned MPAK during speech mode.
12      Returned MPAK during manual mode.
13      Returned MPAK during buffer full.
14      reserved
15      reserved
16      Loginrequest MAN already exist in the flexlist.
17      Loginrequest MAN is not possible, flexlist is full.
18      MPAK sender MAN is not in TMAN or flexlist.
19      reserved
1A      reserved
1B      reserved
1C      reserved
1D      reserved
1E      reserved
1F      reserved

20 - 4F reserved

```

Büdkort

Report on

Cantel Mobitex

Doc No
2/1056 - A 296 5175/2 Ue
Doc Date
1990-02-26 A
Rev
1
File
MTS19A.2

8 MOBITEK TERMINAL SPECIFICATION REFERENCE LIST

This document includes a number of references, made to other sections in the terminal specification. The list below shows these references, together with the page(s) they are made on. Please note that a section could be referred to several times on the same page.

RI-06, 27, 28, 45
RI-09, 9, 11, 12, 14, 15, 16, 17, 31, 32, 39
RI-16, 19, 21, 22, 23, 24, 26, 31, 32
RI-17, 26

Below are the reference designations listed.

Reference	Section
RI-01	Arrangement of the documents
RI-02	MOBITEK System description
RI-03	General description of terminals
RI-04	Terminology
RI-05	References
RI-06	Network operator information
RI-08	Application layer
RI-09	Network layer
RI-11	Interface requirements, fixed terminals
RI-12	Other requirements, fixed terminals
RI-16	Link layer, mobile terminals
RI-17	Physical layer, mobile terminals
RI-18	Radio equipment, mobile terminals
RI-19	Other interfaces, mobile terminals
RI-20	Other requirements, mobile terminals

Revised

Reprod

A 296 51530

REQUIREMENT SPECIFICATION 1(38)

Support - Primary ET/SYS PES	Interconnecting device requirement ET/SYS PES	Doc No 1/1056 - A 296 5175 Ue	
Discrete Outputs - Discrete Inputs ET/SYSC STT <i>ST</i>		Date 1990-02-23	Rev B
		File No MTS19B.1	
Description CanTel Mobitex		Title MOBITEX Terminal Specification Other interfaces, mobile terminal APPENDIX B, Application example	
<p>APPLICATION EXAMPLE</p> <p>OF HOW TO MAKE AN ALTERNATE CONNECTION VIA MCU</p> <p>FOR FIXED TERMINALS WITH MASC INTERFACE.</p>			

Discrete

Repro

A 296 5155-3

Cantel Mobitex

No. 1/1056 - A 296 5175 Ue
 Date: 1990-02-23 Rev. B File: MTS19B.1

TABLE OF CONTENTS

1	INTRODUCTION	3
2	MCU WITH APPLICATION	4
3	DESCRIPTION OF SIGNALS	6
4	EXAMPLES OF SIGNALLING IN THIS APPLICATION	9
4.1	EXAMPLE 1: sending TEXT successfully	9
4.2	EXAMPLE 2: sending TEXT unsuccessfully	10
4.3	EXAMPLE 3: sending TEXT unsuccessfully	11
4.4	EXAMPLE 4: sending TEXT unsuccessfully	12
4.5	EXAMPLE 5: receiving TEXT successfully	13
4.6	EXAMPLE 6: receiving TEXT unsuccessfully	14
4.7	EXAMPLE 7: receiving CONREQ	15
4.8	EXAMPLE 8: receiving CONREQ	16
5	LISTS OF SIGNALS	17
5.1	Interface A	17
5.1.1	Signals sent from APP_DIR to line handlers	17
5.1.2	Signals sent from line handlers to APP_DIR	18
5.1.3	Signals from APP_DIR to AUDIO	19
5.1.4	Signals from AUDIO to APP_DIR	19
5.1.5	Signals from APP_DIR to RADIO_NET	19
5.1.6	Signals from RADIO_NET to APP_DIR	20
6	REGISTERS IN APP_DIR	21
6.1	Register number one: MCU_REG	21
6.2	Register number two: FLEXLIST	23
6.3	Register number three: GROUPLIST	23
6.4	Register number four: CONNECTION_REG	23
7	REQUIREMENTS ON THE NETWORK LAYER IN MCU	24
8	REQUIREMENTS ON A FIXED TERMINAL	25
9	PSEUDO CODE FOR APP_DIR	27
10	MOBITEX TERMINAL SPECIFICATION REFERENCE LIST	38

Blocket

Reprova

Cantel Mobitex

1/1056 - A 296 5175 Ue

1990-02-23 B

MTS19B.1

1 INTRODUCTION

This document describes an example (i.e. not a specification) of an MCU application. Its purpose is to make it easier for the manufacturers. For the understanding of this document, the reader has to be well informed about the Network layer for terminals (reference R1-09) and Link layer for mobile terminals (reference R1-16).

A fixed terminal may be directly connected to the MOBITEK network via a masc interface (MASC) see document "Other interfaces" and appendix A "Commands". The application in this document describes how such a terminal may be connected via an MCU, that handles the masc interface. As to the requirements of such a terminal, please refer to chapter 7 in this document.

Bidirect

Repro

A-2-000

Cantel Mobitex

1/1056 - A 296 5175 Ue
1990-02-23 B MTS19B.1

2 MCU WITH APPLICATION

Figure 1 shows an MCU with its processes. Each process communicates with the other processes as is indicated by the arrows in the figure.




FIGURE 1

In the centre of figure 1 is a process called APP DIR, application director. This document will describe that process.

Each MASC handler (MASC1 to MASCn) handles a masc interface.

The audio handler (AUDIO) handles an audio interface.

The printer handler (PRINTER) handles a printer, connected to the MCU.

Furthermore one may have "emergency handler", "terminal with small display handler" etc.

The network layer (RADIO NET) is a normal MOBITEK network layer for mobile terminal, plus the additions made in chapter 7 (Requirements on network layer in MCU in this application).

Bildzeit

Repro:

Cantel Mobitex -

1/1056 - A 296 5175 Ue		
Date	Ver	F. No
1990-02-23	B	MTS19B.1

The letters A, B and C represent different signalling sequences. Observe that the MASC handler and the printer handler acts similarly towards the application director. All handlers act in the same way as an MASC handler towards the application director.

Following terms are used in this document:

- line handler common name for all handlers. E.g. MASC1, MASC7, AUDIO ...
- MCU_MAN the mobile terminal's MOBITEK subscription number.

Boeken:

Regen:

A 292 81533

Cantel Mobitex™

1/1056 - A 296 5175 Ue

1990-02-23 B

MTS19B.1

3 DESCRIPTION OF SIGNALS

All signals that are handled by APP_DIR have the following structure:

origin Original sender. Can be: line handler,
RADIO NET or
APP_DIR.

from Sender. Can be : line handler,
RADIO NET or
APP_DIR.

signal_status Signal status can be signal_status_ok or
signal_status_not_sent.
Signal status is always set to
signal_status_ok when the signal is
created.
If the RADIO NET or any of the line
handlers fails to transmit a signal,
signal status will be set to
signal_status_not_sent. Then the signal
is returned to APP_DIR.

signal_type Can be: S_hook_on,
S_hook_off,
S_MPAK,
S_MPAK_sent_on_radio,
S_returned_incorrect_MPAK,
S_not_sent_MPAK
S_line_up,
S_line_down.

(MPAK) If signal_type is S_MPAK, S_not_sent_MPAK
or S_returned_incorrect_MPAK, it contains
an MPAK in this field.

Bulker

Repro

A 296 51533

Cantel Mobitex

1/1056 - A 296 5175 Ue

Date Issued 1990-02-23 B

File No. MTS19B.1

Description of the signal types:

S line up

S_line_up is sent by all line handlers to APP_DIR after a correct start or restart.

If the line handler is an MASC handler, the starting up sequence will send a PRIM_MASC_frame and an acknowledgement of this will be received from the connected unit before S_line_up may be sent.

If the line handler is a PRINTER, it is recommended that S_line_up is not sent until the modem signals say there is a printer connected.

S line down

S_line_down is sent by all line handlers to APP_DIR when the unit is disconnected.

If the line handler fails to transmit a signal to the connected unit, S_line_down will be sent to APP_DIR together with the signal being returned.

S MPAK

S_MPAK is the normal signal being sent between line handler and APP_DIR and between RADIO_NET and APP_DIR. In the normal case, signal status is signal status OK. But in the case when line handler or RADIO_NET fails to transmit the signal, signal status will be set to signal status not sent and the signal will be returned to APP_DIR. For further information see examples below (chapter 4).

When an S_MPAK is received by the MASC-handler, the MASC-handler must send an M-frame to the connected unit according to the masc protocol.

When an M-frame is transmitted from the connected unit to the MASC-handler, the MASC-handler must send an S_MPAK to APP_DIR.

S returned incorrect MPAK.

S_returned_incorrect_MPAK is sent by APP_DIR to line handler if an incorrect MPAK was received.

If an MASC handler receives a S_returned_incorrect_MPAK, this MPAK will be sent to the connected unit in an R-frame according to the masc protocol.

Buskort

Reproce

A 202 5150-2

Cantel Mobitex-

1/1056 - A 296 5175 Ue
1990-02-23 B MTS19B.1

S not sent MPAK.

S not sent MPAK is sent by APP_DIR to line handler if, for some reason, it is impossible to transmitt a mpak on radio.

If an MASC handler receives a S not sent MPAK, this MPAK will be sent to the connected unit in an N-frame according to the masc protocol.

S MPAK sent on radio

S MPAK sent on radio is sent by RADIO_NET to APP_DIR when an MPAK has been sent via radio. Origin helps APP_DIR to direct this signal to correct line-handler. When the MASC handler receives an S MPAK sent on radio, it uses the masc F H-frame to send the signal to connected unit.

S hook off

S hook off is sent by AUDIO to APP_DIR at hook off. APP_DIR updates its registers and passes the signal on to RADIO_NET.

An MPAK CONREA, received by APP_DIR from connected unit, will not be sent to RADIO_NET. Instead S_hook_off will be sent from APP_DIR to RADIO_NET.

S hook on

S hook on is sent by AUDIO to APP_DIR at hook on. APP_DIR updates its registers and passes the signal on to RADIO_NET.

An MPAK DISCON, received by APP_DIR from connected unit, will not be sent to RADIO_NET. Instead S_hook_on will be sent from APP_DIR to RADIO_NET.

Stukun

Reproce

Cantel Mobitex


1/1056 - A 296 5175 Ue

1990-02-23 B MTS19B.1

4 EXAMPLES OF SIGNALLING IN THIS APPLICATION

4.1 EXAMPLE 1: sending TEXT successfully

Unit A sends an MPAK TEXT to a subscriber B in the MOBITEK network. Transmission via radio is successful.



signal	signal_type	origin	from	signal_status
1	masc frame M			
2	S_MPAK	MASCn	MASCn	signal_status_ok
3	S_MPAK	MASCn	APP_DIR	signal_status_ok
4 - 5 are not handled in this document.				
6	S_MPAK sent on radio	MASCn		
7	S_MPAK sent on radio	MASCn	RADIO_NET	signal_status_ok
8	S_MPAK sent on radio	MASCn	APP_DIR	signal_status_ok
9	masc frame F_H			

Observe that origin = MASCn through the whole sequence. This gives APP DIR an opportunity to route signals easier back to the sender.

9.0000


Report

Cantel Mobitex™

1/1056 - A 296 5175 Ue
1990-02-23 B MTS19B.1

4.2 EXAMPLE 2: sending TEXT unsuccessfully

Unit A sends an MPAK TEXT to a subscriber B in the MOBITEX network. APP_DIR discovers some kind of error.



signal	signal_type	origin	from	signal_status
1	masc frame M			
2	S_MPAK	MASCn	MASCn	signal_status_ok
3	S_returned-I_incorrect_MPAK	MASCn	APP_DIR	signal_status_ok
4	masc frame R			

Observe that signal 3 has signal status set to signal_status_ok. Only line handlers and RADIO_NET may set signal status to signal_status_not_sent.

BusCard

Superion

A 202 51553


Cantel Mobitex

Doc No. 1/1056 - A 296 5175 Ue

Issue Date 1990-02-23 Ver. B File No. MTS19B.1

4.3 EXAMPLE 3: sending TEXT unsuccessfully

Unit A sends an MPAK TEXT to a subscriber B in the MOBITEK network. Transmission via radio fails.



signal	signal_type	origin	from	signal_status
1	masc frame M			
2	S_MPAK	MASCn	MASCn	signal_status_ok
3	S_MPAK	MASCn	APP_DIR	signal_status_ok
4 - 6 are not handled in this document.				
7	S_MPAK	MASCn	RADIO_NET	signal_status-not sent
8	S not sent MPAK	MASCn	APP_DIR	signal_status_ok
9	masc frame N			

Blockset

Diagram


Cantel Mobitex

1/1056 - A 296 5175 Ue

System Date 1990-02-23 Rev B F.T. MTS19B.1

4.4 EXAMPLE 4: sending TEXT unsuccessfully.

Unit A sends an MPAK TEXT to a subscriber B in the MOBITEK network. Transmission via radio fails. The MCU fails to return the packet to unit A.



signal	signal_type	origin	from	signal_status
1	masc frame M			
2	S_MPAK	MASCn	MASCn	signal_status_ok
3	S_MPAK	MASCn	APP_DIR	signal_status_ok
4 - 6	are not handled in this document.			
7	S_MPAK	MASCn	RADIO_NET	signal_status-not sent
8	S_not_sent_MPAK	MASCn	APP_DIR	signal_status_ok
9	masc frame N			
10	S_not_sent_MPAK	MASCn	MASCn	signal_status-not sent

This sequence is the same as the one in example 3, except for signal 10. When receiving signal 10, APP_DIR discovers that origin = from, i.e. the signal is returned even from the MASC handler. The only thing APP_DIR can do is to forget the signal.

Bridport

Beyron

Cantel Mobitex


1/1056 - A 296 5175 Ue

1990-02-23 B

MTS19B.1

4.5 EXAMPLE 5: receiving TEXT successfully

MCU receives an MPAK TEXT, addressed to MCU-MAN.



signal	signal_type	origin	from	signal_status
1 - 2	are not handled in this document.			
3	S_MPAK	RADIO_NET	RADIO_NET	signal_status_ok
4	S_MPAK	RADIO_NET	APP_DIR	signal_status_ok
5	masc frame M			

The sequence above is valid if there is only one line handler.

If an MPAK is addressed to the MCU MAN, and there is more than one line handler, APP DIR will send a copy of signal 4 to each one of them. But if the MPAK is addressed to a transferred MAN, APP DIR will know on which of the line handlers this MAN can be reached.

Bruckner

Repro


A 002 51503

Cantel Mobitex

1/1056 - A 296 5175 Ue
 1990-02-23 B MTS19B.1

4.6 EXAMPLE 6: receiving TEXT unsuccessfully

MCU receives an MPAK TEXT to unit B. Transmission to unit B fails. There is only one receiver in this example and MPAK is addressed to MCU_MAN.



signal	signal_type	origin	from	signal_status
1 - 2	are not handled in this document.			
3	S_MPAK	RADIO_NET	RADIO_NET	signal_status_ok
4	S_MPAK	RADIO_NET	APP_DIR	signal_status_ok
5	masc frame M			
6	S_MPAK	RADIO_NET	MASCn	signal_status-not_sent

Observe that an MPAK, addressed to MCU_MAN or any MAN included in the grouplist, must not under any circumstances, be returned to the MOBITEK network. In this application, APP_DIR forgets the MPAK.

Header


Page

Cantel Mobitex

1/1056 - A 296 5175 Ue
1990-02-23 B MTS19B.1

4.7 EXAMPLE 7: receiving CONREQ

MCU receives an MPAK CONREQ addressed to unit B. Unit B responds with an MPAK CONREA after which the call can begin. Unit B terminates the call by sending an MPAK DISCON.



signal	signal_type	origin	from	signal_status
1 - 2	are not handled in this document.			
3	S_MPAK	RADIO_NET	RADIO_NET	signal_status_ok
4	S_MPAK	RADIO_NET	APP_DIR	signal_status_ok
5	mask frame M			
6	mask frame M			
7	S_MPAK	MASCn	MASCn	signal_status_ok
8	S_hook off	MASCn	APP_DIR	signal_status_ok
9 - 10	are not handled in this document.			
11	mask frame M			
12	S_MPAK	MASCn	MASCn	signal_status_ok
13	S_hook on	MASCn	APP_DIR	signal_status_ok
14 - 15	are not handled in this document.			

Note: signal 1 - 5 contains MPAK CONREQ.
signal 6 - 7, 9-10 contains MPAK CONREA
signal 11 - 12, 14-15 contains MPAK DISCON

In this application S hook on and S hook off are always sent, instead of MPAK DISCON and MPAK CONREA, to the RADIO_NET.

Build:


Repro:

Cantel Mobitex

1/1056 - A 296 5175 Ue
 1990-02-23 B MTS19B.1

4.8 EXAMPLE 8: receiving CONREQ

MCU receives an MPAK CONREQ addressed to unit B. The audio interface generates a hook off after which the call can begin. The call is terminated by the audio interface generating an hook on.



signal	signal_type	origin	from	signal_status
1 - 2	are not handled in this document.			
3	S_MPAK	RADIO NET	RADIO NET	signal_status_ok
4	S_MPAK	RADIO_NET	APP_DIR	signal_status_ok
5	masc frame M			
6	S hook off	AUDIO	AUDIO	signal_status_ok
7	S hook off	AUDIO	APP_DIR	signal_status_ok
8 - 9	are not handled in this document.			
10	S hook on	AUDIO	AUDIO	signal_status_ok
11	S hook on	AUDIO	APP_DIR	signal_status_ok
12 - 13	are not handled in this document			
14	S_MPAK	RADIO_NET	APP_DIR	signal_status_ok
15	masc frame M			

Note: signal 1 - 5 contains MPAK CONREQ
 signal 8 - 9 contains MPAK CONREA
 signal 12 - 15 contains MPAK DISCON

Observe that APP_DIR generates MPAK DISCON to unit B.
 This is to avoid blocking situations in unit B.

Cantel Mobitex

1/1056 - A 296 5175 Ue

1990-02-23 B MTS19B.1

5 LISTS OF SIGNALS

Signals that are sent within the MCU, interfaces A, B and C in figure 1, are listed below. The signals are divided into categories of normal and returned signals.

5.1 Interface A**5.1.1 Signals sent from APP_DIR to line handlers****Normal signals****S_MPAK**

origin = creator of this signal
 from = APP_DIR
 signal_status = signal_status_ok
 signal_type = S_MPAK
 MPAK = MPAK in question

S_not_sent_MPAK

origin = creator of original MPAK
 from = APP_DIR
 signal_status = signal_status_ok
 signal_type = S_not_sent_MPAK
 MPAK = MPAK in question

S_returned_incorrect_MPAK

origin = creator of original MPAK
 from = APP_DIR
 signal_status = signal_status_ok
 signal_type = S_returned_incorrect_MPAK
 MPAK = MPAK in question

S_MPAK_sent_on_radio

origin = creator of original MPAK
 from = APP_DIR
 signal_status = signal_status_ok
 signal_type = S_MPAK_sent_on_radio

Bureau

Region

A 292 5133-3

Cantel Mobitex

1/1056 - A 296 5175 Ue
 1990-02-23 B MTS19B.1

5.1.2 Signals sent from line handlers to APP_DIR

Normal signals

S_line_up
 Origin = line handler in question
 from = origin
 signal_status = signal_status_ok
 signal_type = S_line_up

S_line_down
 Origin = line handler in question
 from = origin
 signal_status = signal_status_ok
 signal_type = S_line_down

S_MPAK
 origin = line handler in question
 from = origin
 signal_status = signal_status_ok
 signal_type = S_MPAK
 MPAK = MPAK in question

Returned signals

S_MPAK
 origin = no change in this field
 from = line handler in question
 signal_status = signal_status_not_sent
 signal_type = S_MPAK
 MPAK = MPAK in question

S_MPAK_sent_on_radio
 Origin = no change in this field
 from = line handler in question
 signal_status = signal_status_not_sent
 signal_type = S_MPAK_sent_on_radio

S_returned_incorrect_MPAK
 origin = no change in this field
 from = line handler in question
 signal_status = signal_status_not_sent
 signal_type = S_returned_incorrect_MPAK
 MPAK = MPAK in question

S_not_sent_MPAK
 origin = no change in this field
 from = line handler in question
 signal_status = signal_status_not_sent
 signal_type = S_not_sent_MPAK
 MPAK = MPAK in question

B:000000

B:000000

A:0015132

Cantel Mobitex -

1/1056 - A 296 5175 Ue

1990-02-23 B MTS19B.1

5.1.3 Signals from APP_DIR to AUDIO

All signals listed in 5.1.1.

5.1.4 Signals from AUDIO to APP_DIR

All signals listed in 5.1.2, plus the following:

S_hook off

Origin	=	AUDIO
from	=	AUDIO
signal_status	=	signal_status_ok
signal_type	=	S_hook_off

S_hook on

Origin	=	AUDIO
from	=	AUDIO
signal_status	=	signal_status_ok
signal_type	=	S_hook_on

5.1.5 Signals from APP_DIR to RADIO_NET

Normal signals

S_MPAK

origin	=	creator of this signal
from	=	APP DIR
signal_status	=	signal_status_ok
signal_type	=	S_MPAK
MPAK	=	MPAK in question

S_hook on

Origin	=	AUDIO
from	=	APP DIR
signal_status	=	signal_status_ok
signal_type	=	S_hook_on

S_hook off

Origin	=	AUDIO
from	=	APP DIR
signal_status	=	signal_status_ok
signal_type	=	S_hook_off

Author:

Repro:

A:192 5153-3

Cantel Mobitex

1/1056 - A 296 5175 Ue
1990-02-23 B MTS19B.1

5.1.6 Signals from RADIO_NET to APP_DIR

Normal signals

S_MPAK

origin	=	RADIO_NET
from	=	origin
signal_status	=	signal_status_ok
signal_type	=	S_MPAK
MPAK	=	MPAK in question

Returned signals

S_MPAK

origin	=	no change in this field
from	=	RADIO_NET
signal_status	=	signal_status_not_sent
signal_type	=	S_MPAK
MPAK	=	MPAK in question

S_hook_on

origin	=	AUDIO
from	=	RADIO_NET
signal_status	=	signal_status_not_sent
signal_type	=	S_hook_on

S_hook_off

origin	=	AUDIO
from	=	RADIO_NET
signal_status	=	signal_status_not_sent
signal_type	=	S_hook_off

B. alert

Repro

A 10751533

Cantel Mobitex

1/1056 - A 296 5175 Ue

1990-02-23 B

MTS19B.1

6 REGISTERS IN APP_DIR

Four registers are kept in APP_DIR:

6.1 Register number one: MCU_REG

The register called MCU_REG has the structure shown in the figure below.

LINE	MASC1	MASC2	MASC3	AUDIO	PRINTER
MAY / MAY NOT INACTIVATE MCU					
LINE_UP / LINE_DOWN					
MSG TYPE	TEXT				
	STATUS				
	DATA				
	HPDATA				
	SPEECH				
	EMERGENCY				
	EXTPAK				

line

Contains the line handlers that exist in this application. This is static information.

msg type

Tells which MPAKs, addressed to MCU MAN or any MAN in the group list, will be received by the line handler. As an example, there is nothing to prevent that MPAK TEXT is received by a number of line handlers. In the speech connection case, in this particular application, only one line handler can be enabled. Msg type contains static information.

may/may not inactivate MCU

Tells whether the line handler in question is allowed to inactivate MCU with an MPAK DTESERV.INACTIVE. Normally, only one (or very few) of the line handlers should be allowed to do this. This is static information.

Subnet:

Report

A 292-6153 3

Cantel Mobitex

Doc No: 1/1056 - A 296 5175 Ue

Status Date: 1990-02-23 B Rev: MTS19B.1

line up/down

Contains information about each of the connected line handlers. This information is dynamic.

The figure below shows how the MCU_REG may be used.

LINE		MASC1	MASC2	MASC3	AUDIO	PRINTER
MAY / MAY NOT INACTIVATE MCU		MAY	NOT	NOT	NOT	NOT
LINE UP / LINE DOWN		UP	UP	DOWN	UP	UP
MSG TYPE	TEXT	X	X	X		X
	STATUS				X	
	DATA	X				
	HPDATA	X				
	SPEECH	X				
	EMERGENCY	X				
	EXTPAK	X				

In this case, only MASC1 is allowed to inactivate the MCU. All line handlers, except for MASC3, are connected and intact. When APP DIR receives an MPAK TEXT from MOBITEK network, it will be sent to MASC1, MASC2 and PRINTER. Since MASC3 does not have status line_up, it does not receive any MPAKs. Received MPAK STATUS is to be sent to AUDIO. Other MPAKs are to be sent to MASC1.

Observe that APP DIR does not keep information of if MCU is active or inactive. Nor does APP DIR know if RADIO NET has received an MPAK DIE from the MOBITEK network. It is the responsibility of RADIO NET to keep information about this. If RADIO NET notes which APP DIR is not allowed to send to the MOBITEK network, the packets are returned to APP DIR with signal status set to signal_status_not_sent.

Booklet

Regres

A 296 5133-3

Cantel Mobitex

Doc ID: 1/1056 - A 296 5175 Ue
 Doc. Date: 1990-02-23 Ver: B File: MTS19B.1

6.2 Register number two: FLEXLIST

The FLEXLIST register has the structure shown in the figure below.

MAN	LINE	STATUS

MAN - The MOBITEK subscription number of the transferred subscriber. Up to seven MAN-numbers are allowed.

LINE - The line handler to which the transferable has transferred..

STATUS - Tells login status.
 It can be: **UNDER_LOGIN** - the login sequence is not yet finished
OK_LOGIN - the login sequence is finished and accepted

6.3 Register number three: GROUPLIST

The GROUPLIST contains a list of group MAN numbers. Up to 15 MAN numbers is allowed.

6.4 Register number four: CONNECTION_REG

CONNECTION_REG keeps information about the status of the speech line. It contains the following information:

CONNECTION_STATUS - can be free, busy or waiting_for_hook_off

CONNECTION_PARTY_HERE - MAN number for connection part in the MCU

CONNECTION_OTHER_PARTY - MAN number for the other connection part

CONNECTION_CONN_ID - connection identity for current speech line connection

Buskett

Regene

Cantel Mobitex

1/1056 - A 296 5175 Ue

1990-02-23 B MTS19B.1

7 REQUIREMENTS ON THE NETWORK LAYER IN MCU

Requirements on the network layer in MCU (RADIO_NET) are listed below:

1. Everything applicable to mobile terminal in document MOBITEK network layer for terminals, 5/1056 - A 296 5171.
- 2 All MPAKs that the application wants to send via radio and network layer to
 - be acknowledged to the application if the transmission was successful,
 - be returned to the application if the transmission failed.
- 3 The signals hook on and hook off will be returned to the application if the transmission via radio fails.
- 4 The following MPAKs, received by the MCU via radio, to be sent to the application:
 - all MPAKs of class PSUBCOM.
 - all MPAKs of class PSOSCOM.

Note that a transferred subscriber, connected to the MCU via an MASC handler, can be emergency receiver.

- following MPAKs, belonging to the class CSUBSOM:
 - + CONREQ
 - + ADDCONREQ
 - + SOSCONREQ
 - + EXTCONREQ
 - + CONORD
 - + DISCON
- following MPAKs, belonging to the class DTESERV:
 - + LOGINREQ * **
 - + LOGINREF * **
 - + LOGOUTORD * **
 - + LOGINGRA * **
 - + FLEXLIST * **
 - + TIME * **
 - + GROUPLIST * **
 - + SOSRX * ***
 - + VICESOSRX * ***

- * These MPAKs can only have MPAK states that are not OK.
- ** These MPAKs concern flexlist and grouplist. They are handled by the network layer and sent to the application. The reason for this is that the application has copies of flexlist and grouplist.
- *** Only if a terminal, connected to the MCU, has an emergency receiver transferred to it.

Bakari

Zaprou

Cantel Mobitex

1/1056 - A 296 5175 Ue		
Serial Date	Rev	File Name
1990-02-23	B	MFS19B.1

8 REQUIREMENTS ON A FIXED TERMINAL

The requirements for a fixed terminal which is able to connect to the MOBITEK network as well as the MCU are as follows.

Link layer

Frames in the masc protocol for implemented:

All control frames : ACK, RACK, NACK, SENS, SACK

Following information frames:

B, M, E, R, F_P, F_Q, N

Network layer

The MOBITEK network considers a fixed terminal, connected via an MCU, as a mobile terminal. This has the following consequences as to which MPAKs may be sent and received by the terminal.

class PSUBCOM:

The terminal is allowed to send and receive all MPAKs in this class.

class PSOSCOM:

An emergency sender can be a mobile subscriber or a transferable subscriber which is transferred to a mobile subscriber. A receiver can be a fixed terminal subscriber or a transferable subscriber. All emergency senders can send SOS and receive SOSACK. Furthermore, all mobile terminals are able to receive SOS and SOSACK addressed to All terminals group MAN.

class CSUBCOM:

If the fixed terminal has one line for speech line connection, the following MPAKs can be received and sent:

CONREQ
SOSCONREQ
ADDCONREQ
EXTCONREQ
CONREA
DISCON

Connection to group will be made by the MCU by converting CONORD to CONREQ.

Dissect

Supreme

Cantel Mobitex

1/1056 - A 296 5175 Ue

1990-02-23 B

MTS19B.1

class DTESERV:

Following MPAKs may be sent:

LOGINREQ
LOGOUT
ACTIVE
INACTIVE
VICESOSRX
SOSRX
FLEXLIST

*
*

* Only if the sender is a transferable subscriber.

Following MPAKs shall be received:

LOGINREQ
LOGINRA
LOGINREF
LOGOUTORD
VICESOSRX
SOSRX
GROUPLIST
FLEXREQ
TIME

When the network layer receives masc frame N from the masc interface, it acts in the same manner as if the MPAK never leaved the fixed terminal.

Hidden

Supers

Cantel Mobitex™

1/1056 - A 296 5175 Ue
 Serial Date 1990-02-23 E F. L. MTS19B.1

9 PSEUDO CODE FOR APP_DIR

In this pseudo code all procedures start with "P_", and all functions with "F_".

REPEAT

```
Wait for input
CASE input signal type OF
  S_MPAK_sent_on_radio
    IF from = RADIO_NET THEN
      send this signal to origin
    ELSE
      forget this signal
    END IF
  S_hook_on
  P_hook_on
  S_hook_off
  P_hook_off
  S_line_up
  P_line_up
  S_line_down
  P_line_down
  S_MPAK
  P_MPAK
  conOrd timer
  CONNECTION_STATUS = free
otherwise
  forget this signal
END CASE input signal OF
UNTIL forever
```

P_hook_on

```
IF ( from = AUDIO ) AND ( CONNECTION_STATUS <> free )
  THEN
    send this signal to RADIO_NET
    send signal S_MPAK with MPAK = DISCON to
    CONNECTION LINE
    (MPAK.sender = CONNECTION_OTHER_PARTY
    MPAK.addressee = CONNECTION_PARTY_HERE
    MPAK.type_dependent.line number = 0
    MPAK.type_dependent.CONN_ID=CONNECTION_CONN_ID)
    CONNECTION_STATUS = free
  ELSE
    forget this signal
  END IF (from = AUDIO) AND (CONNECTION_STATUS <>free)...
END P_hook_on
```

Brackets

Report

Cantel Mobitex

1/1056 - A 296 5175 Ue

1990-02-23 B

MTS19B.1

```

P_hook_off
  IF from = AUDIO THEN
    IF CONNECTION STATUS = waiting_for_hook_off THEN
      CONNECTION STATUS = busy
      send this signal to RADIO_NET
      reset conord_timer
    ELSE
      forget this signal
    END IF CONNECTION STATUS = waiting_for_hook_off...
  ELSE
    IF (from=RADIO_NET) AND (signal_status =
      signal_status_not_sent) THEN
      forget this signal
      send signal S MPAK with MPAK = DISCON to
      CONNECTION LINE
      ( MPAK.sender = CONNECTION OTHER PARTY
        MPAK.addressee = CONNECTION PARTY HERE
        MPAK.type_dependent.line number = 0
        MPAK.type_dependent.CONN_ID = CONNECTION_CONN_ID )
      CONNECTION STATUS = free
    ELSE
      forget this signal
      END IF (from = RADIO_NET) AND (signal_status =...)
    END IF from = AUDIO...
  END P_hook_off

```

```

P_line_down
  mark origin in MCU REG as line down
  FOR all MAN in our flexlist pointing at origin DO
    send signal S MPAK with MPAK = logout to RADIO NET
    ( MPAK.sender = MAN in question from flexlist
      MPAK.addressee = the MOBITEK network
      MPAK.type dependent part = MCU MAN )
    remove MAN in question from our flexlist
  END FOR all MAN in our flexlist pointing...
END P_line_down

```

```

P_line_up
  send signal S MPAK with MPAK = grouplist to origin
  ( MPAK.sender = the MOBITEK network
    MPAK.addressee = MCU MAN
    MPAK.type dependent part = our grouplist )
  send signal S MPAK with MPAK = flexreq to origin
  ( MPAK.sender = the MOBITEK network
    MPAK.addressee = MCU MAN )
  mark origin in MCU REG as line_up
END P_line_up

```

Bulgar

Regime

Cantel Mobitex

1/1056 - A 296 5175 Ue

1990-02-23 B

MTS19B.1

```

P_MPAK
IF signal_status = signal_status_ok THEN
  IF from = RADIO_NET THEN
    P_MPAK_from_radio
  ELSE
    P_MPAK_from_other
  END IF from = RADIO_NET...
ELSE
  IF origin = from THEN
    forget this signal (can't send this signal in any
    direction )
  ELSE
    IF origin = RADIO_NET THEN
      forget this signal (Never send back MPAK to
      network)
    ELSE
      IF MPAK.unknown_f = 0 THEN
        CASE MPAK.packet_class OF
          PSUBCOM,PSOSCOM
            signal_status = signal_status_ok
            signal_type = S_not_sent_MPAK
            send this signal to origin
          CSUBCOM
            CASE MPAK.packet_type OF
              CONREQ,ADDCONREQ,SOSCONREQ,EXTCONREQ
                signal_status = signal_status_ok
                signal_type = S_not_sent_MPAK
                send this signal to origin
              CONNECTION_STATUS = free
            otherwise
              forget this signal
            END CASE MPAK.packet_type...
          DTESERV
            CASE MPAK.packet_type OF
              VICESOSRX,SOSRX
                signal_status = signal_status_ok
                signal_type = S_not_sent_MPAK
                send this signal to origin
              LOGINREQ
                remove MPAK.type_dependent_part from our
                flexlist
                signal_status = signal_status_ok
                signal_type = S_not_sent_MPAK
                send this signal to origin
              otherwise
                forget this signal
            END CASE MPAK.packet_type...
          END CASE MPAK.class...
        ELSE
          forget this signal
        END IF MPAK.unknown_f.
      END IF origin...
    END IF origin...
  END IF signal_status...
END P_MPAK

```

Budget

Region

A 292 51533

Cantel Mobitex

1/1056 - A 296 5175 Ue
1990-02-23 B MTS19B.1

```

P_MPAK_from_other
mark origin in MCU REG as line_up
CASE MPAK.packet_class OF
PSUBCOM,PSOSCOM
IF MPAK.unknown_f = 1 THEN
IF (F_get_receiver_MAN in our grouplist ) OR
(F_get_receiver_MAN = MCU_MAN ) THEN
forget this signal
ELSE
IF F_get_receiver_MAN in our flexlist THEN
remove F_get_receiver_MAN from our flexlist
send signal S_MPAK with MPAK = LOGOUT to RADIO_NET
(MPAK.sender = F_get_receiver_MAN
MPAK.addressee = the MOBITEK network
MPAK.type_dependent_part = MCU_MAN )
END IF F_get_receiver_MAN in our flexlist
send this signal to RADIO_NET
END IF (F_get_receiver_MAN in our grouplist...)
ELSE ( IF MPAK.unknown_f = 1 ...)
IF (MPAK.state <> OK ) OR ( MPAK.digital_f = 1 ) THEN
signal_type = S_returned_incorrect_MPAK
send this signal to origin
ELSE
IF (F_get_transmitting_MAN = MCU_MAN ) or
(F_get_transmitting_man in our flexlist with status
ok_login ) THEN
send this signal to RADIO_NET
ELSE
send signal S_MPAK with MPAK = LOGOUT to origin
(MPAK.sender = the MOBITEK network
MPAK.addressee = MCU_MAN
MPAK.type_dependent_part= F_get_transmitting_MAN)
signal_type = S_not_sent_MPAK
signal_status = signal_status_ok
send this signal to origin
END IF (F_get_transmitting_MAN = MCU_MAN...)
END IF MPAK.state...
END IF MPAK.unknown_f...
CSUBCOM
CASE MPAK.packet_type OF
CONREQ,ADDCONREQ,SOSCONREQ,EXTCONREQ
IF ( MPAK.unknown_f = 0 ) and
( MPAK.mailbox_f = 0 ) and
( MPAK.sendlist_f = 0 ) and
( mpak.state = OK ) THEN
IF (F_get_transmitting_MAN = MCU_MAN ) or
(F_get_transmitting_MAN is in our flexlist with
status ok_login )
THEN
IF CONNECTION STATUS = free THEN
CONNECTION_line = origin
CONNECTION_status = busy
send this signal to RADIO_NET

```

Endnote

Page 30

Cantel Mobitex

1/1056 - A 296 5175 Ua

1990-02-23 B

MTS19B.1.

```

ELSE
  signal_type = S_not_sent_MPAK
  signal_status = signal_status_ok
  send this signal to origin
END IF 'CONNECTION_STATUS = free...'
ELSE
  send signal S_MPAK with MPAK = LOGOUTORD to
  origin
  ( MPAK.sender = the MOBITEK network
    MPAK.addressee = MCU MAN
    MPAK.type dependent Part =
      F_get transmitting_MAN )
  signal_type = S_not_sent_MPAK
  signal_status = signal_status_ok
  send this signal to origin
END IF (F_get_transmitting_MAN = MCU_MAN...)
ELSE
  signal_type = S_returned_incorrect_MPAK
  send this signal to origin
END IF ( MPAK.unknown_f = 0...
CONREA
IF ( CONNECTION_STATUS = waiting_for_hook_off) and
( origin = CONNECTION_line ) THEN
  forget this signal
  send signal S hook off to RADIO_NET
  CONNECTION_STATUS = busy
  reset conord_timer
ELSE
  forget this signal
DISCON
IF ( CONNECTION_STATUS <> free) and
( origin = CONNECTION_line ) THEN
  forget this signal
  send signal hook on to RADIO_NET
  CONNECTION_STATUS = free
ELSE
  forget this signal
otherwise
  forget this signal
END CASE MPAK.packet_type...
DTESERV
CASE MPAK.packet_type OF
LOGINREQ,LOGOUT,ACTIVE,INACTIVE,VICESOSRX,SOSRX,FLEXLIST
IF (MPAK.state = ok ) AND
( MPAK.digital_f = 0 ) AND
( MPAK.mailbox_f = 0 ) AND
( MPAK.sendlist_f = 0 ) AND
( MPAK.unknown_f = 0 ) AND
( MPAK.extern_f = 0 ) AND
( MPAK.addressee = MOBITEK_network ) THEN
CASE MPAK.packet_type OF
LOGINREQ,ACTIVE,INACTIVE,FLEXLIST
IF MPAK.sender = MCU MAN THEN
CASE MPAK.packet_type OF

```

Bidkern

Raynov

A 292 51523

Cantel Mobitex

1/1056 - A 296 5175 Ue

1990-02-23 B MTS19B.1

```

LOGINREQ
IF MPAK.type_dependent_part in our flexlist
with status = ok login THEN
send signal S_MPAK with MPAK LOGINGRA to
origin
( MPAK.sender = the MOBITEK network
MPAK.addressee = MCU MAN
MPAK.type_dependent_part =
=<old>MPAK.type_dependent_part )
forget this signal
ELSE
IF more space exists in our flexlist THEN
mark MPAK.type_dependent_part in our
flexlist
with status=under_login and line =
origin
send this signal to RADIO_NET
ELSE
signal_type = S_not_sent_MPAK
signal_status = signal_status_ok
send this signal to origin
END IF more space in our flexlist...
END IF MPAK.type_dependent_part in our...
ACTIVE, INACTIVE
IF origin may inactivate THEN
P_line down
send this signal to RADIO_NET
ELSE
P_line down
forget this signal
END IF origin may activate/inactivate...
FLEXLIST
FOR all MAN in MPAK.FLEXLIST not in our
flexlist
with status ok login DO
send signal S_MPAK with MPAK = logoutord
to origin
( MPAK.sender = the MOBITEK network
MPAK.addressee = MCU MAN
MPAK.type_dependent_part = MAN in
question )
END FOR all MAN in MPAK.FLEXLIST not in our...
forget this signal
END CASE MPAK.packet_type
ELSE ( IF MPAK.sender = MCU MAN)
signal_type = S_returned_incorrect_MPAK
send this signal to origin
END IF MPAK.sender = MCU_MAN...

```

Bulky:

Repeat

A 297 51333

Cantel Mobitex

1/1056 - A 296 5175 Ue
1990-02-23 B MTS19B.1

```
VICESOSRX,SOSRX
IF MPAK.sender in our flexlist with status
ok_login THEN
  send this signal to RADIO_NET
ELSE
  signal_type = S_not_sent_MPAK
  signal_status = signal_status_ok
  send this signal to origin from
END IF MPAK.sender in our flexlist with status...
LOGOUT
IF MPAK.sender in our flexlist with any status
THEN
  delete MPAK.sender from our flexlist
  MPAK.type_dependent_part = MCU MAN
  send this signal to RADIO_NET
ELSE
  forget this signal
END IF MPAK.sender in our flexlist ...
END CASE MPAK.packet_type...
ELSE
  signal_type = S_returned_incorrect_MPAK
  send this signal to origin
END IF (MPAK.state = ok...
otherwise
  signal_type = S_returned_incorrect_MPAK
  send this signal to origin
END CASE MPAK.packet_type...
END CASE MPAK.class...
END P_MPAK_from_other
```

```
P_MPAK from radio
CASE MPAK.class OF
  PSUBCOM,PSOSCOM
    IF F_get_receiver MAN in our flexlist THEN
      send this signal to line in question
    ELSE
      IF ( F_get_receiver MAN = MCU MAN ) OR
      ( F_get_receiver MAN in our groupelist ) THEN
        CASE MPAK.class OF
          PSUBCOM
            CASE MPAK.packet_type OF
              TEXT
                P_copy_and_send_signal( text )
              STATUS
                P_copy_and_send_signal( status )
              HPDATA
                P_copy_and_send_signal( hpdata )
              DATA
                P_copy_and_send_signal( data )
              EXTPAK
                P_copy_and_send_signal( EXTPAK )
            otherwise
              forget this signal
          END CASE MPAK.packet_type...
```

3.00000

Reprova

A-292 5153-0

Cantel Mobitex

1/1056 - A 296 5175 Ue
1990-02-23 B MTS19B.1

```

PSOSCOM
IF ( MPAK.packet_type = SOS or SOSINFO )
AND ( MPAK.addressee = all terminal group MAN )
THEN
  IF MPAK.sender in out flexlist THEN
    send this signal to line in question
  ELSE
    P_copy_and_send_signal( emergency )
  END IF MPAK.sender in our flexlist...
ELSE
  P_copy_and_send_signal( emergency )
END IF ( MPAK.packet_type = SOS or SOSINFO...
END CASE MPAK.class...
ELSE
  ( This case can not appear; the network layer shall
  take care of unknown MPAKs from the network)
  MPAK.unknown_f = 1
  send this signal to RADIO_NET
  END IF ( F_get_receiver MAN = MCU MAN...
  END IF F_get_receiver MAN in our flexlist...
CSUBCOM
CASE MPAK.packet_type OF
  CONREQ,ADDCONREQ,SOSCONREQ,EXTCONREQ
  IF MPAK.state <> ok THEN
    P_discon
  ELSE
    IF F_get_receiver MAN in our flexlist THEN
      CONNECTION STATUS = waiting for hook off
      CONNECTION LINE = line in question from flexlist
      CONNECTION PARTY HERE = MPAK.addressee
      CONNECTION OTHER PARTY = MPAK.sender
      CONNECTION CONN ID =MPAK.type dependent.conn_id
      send this signal to line in question
    ELSE
      IF F_get_receiver MAN = MCU MAN THEN
        CONNECTION STATUS = waiting for hook off
        CONNECTION PARTY HERE = MPAK.addressee
        CONNECTION OTHER PARTY = MPAK.sender
        CONNECTION CONN ID =MPAK.type dependent.conn_id
        send this signal to first line in MCU_REG with
        (line status = up) AND (msg_type = speech)
        IF no such line THEN
          forget this signal
          CONNECTION STATUS = waiting for hook off
          send signal S_hook_on to RADIO_NET
        ELSE
          CONNECTION LINE = line in question from
          MCU_REG
        END
      ELSE
        forget this signal
        send signal S hook on to RADIO NET
      END IF ( F_get_receiver MAN = MCU MAN...
    END IF F_GET_receiver MAN in our flexlist...
  END IF MPAK.state <> ok

```

Blanket

Regime

A 292 51553

Cantel Mobitex

Doc No.	1/1056 - A 296 5175 Ue
Doc Date	1990-02-23 B
Doc No.	MTS19B.1

```

CONORD
IF CONNECTION STATUS = free THEN
  IF F_get_receiver MAN in our grouplist THEN
    MPAK.packet_type = CONREQ
    CONNECTION STATUS = waiting for hook off
    CONNECTION_PARTY HERE = MPAK.addressee
    CONNECTION_OTHER_PARTY = MPAK.sender
    CONNECTION_CONN ID= MPAK.type_dependent.conn_id
    send this signal to first line in MCU_REG with
    ( line_status = up ) AND ( msg_type = speech )
    IF no such line THEN
      forget this signal
      CONNECTION STATUS = free
      send signal S_hook_on to RADIO_NET
    ELSE
      CONNECTION_LINE = line in question from MCU_REG
      set timer: conord_timer
    END
  ELSE
    forget this signal
    send signal S_hook_on to RADIO_NET
  END IF F_get_receiver MAN in our grouplist...
ELSE
  forget this signal
  END IF CONNECTION STATUS = free...
DISCON
P_discon
otherwise
  forget this signal
  END CASE MPAK.packet_type...
DTESERV
CASE MPAK.packet_type OF
  LOGINREQ, LOGINREF, LOGOUTORD
    IF MPAK.type_dependent in our flexlist THEN
      send this signal to line IN QUESTION
      remove MAN in question from our flexlist
    ELSE
      forget this signal
    END IF MPAK.type_dependent in our flexlist THEN
  LOGINGRA
    IF MPAK.type_dependent in our flexlist THEN
      mark in our flexlist status = ok_login
      send this signal to line in question
    ELSE
      send signal S_MPAK with MPAK = logout to RADIO_NET
      ( MPAK.sender = MCU MAN
        MPAK.addressee = MOBITEK network
        MPAK.type_dependent_part = MAN in question
      )
    END IF MPAK.type_dependent in our flexlist ....

```

Block:

Repre:

A 296 51533

Cantel Mobitex

1/1056 - A 296 5175 Ue

1990-02-23 B MTS19B.1

```

FLEXLIST
FOR all MAN in this signal who are not in our flexlist
  send signal S_MPAK with MPAK = logout to RADIO_NET
  ( MPAK.sender = MCU_MAN
    MPAK.addressee = MOBITEK network
    MPAK.type_dependent_part = MAN in question)
END
FOR all MAN in our flexlist who are not in this signal
  send signal S_MPAK with MPAK = logoutord to line in
  question
  ( MPAK.sender = MOBITEK network
    MPAK.addressee = MCU_MAN
    MPAK.type_dependent_part = MAN in question )
  remove MAN in question from our flexlist
END
TIME
  send a copy of this signal to all lines
GROUPLIST
  store grouplist from this signal in our register
  send a copy of this signal to all lines
SOSRX,VICESOSRX
  IF F_get_receiver MAN in our flexlist THEN
    send this signal to line in question
  ELSE forget this signal
  END CASE MPAK.packet_type OF...
  END CASE MPAK.class...
END P_MPAK_from_radio

P_copy_and_send_signal( type )
  send a copy to all lines in MCU_REG with
  ( line_status = up ) and ( msg_type = type )
END P_copy_and_send_signal

P_discon
  IF CONNECTION_STATUS <> free
    send this signal to CONNECTION_LINE
    CONNECTION_STATUS = free
  ELSE
    forget this signal
  END
END P_discon

```

Budart

Repro

A 296 515343

Cantel Mobitex-

1/1056 - A 296 5175 Ue		
Docum. Date	Rev	Ed. F.
1990-02-23	B	MTS19B.1

```

F_get receiver_MAN
CASE MPAK.state OF
  ok,from mail
    F_get_receiver_MAN = MPAK.sender
  otherwise
    F_get_receiver_MAN = MPAK.addressee
END CASE
END F_get_receiver_MAN

F_get transmitting_MAN
IF MPAK.unknown_F = 0 THEN
  F_get_transmitting_MAN = MPAK.sender
ELSE
  F_get_transmitting_MAN = F_get_receiver_MAN
END
END F_get_transmitting_MAN

```

Bidder:

Reverend

Cantel Mobitex

No. T.		
1/1056 - A 296 5175 Ue		
Item Date	Rev	File
1990-02-23	B	MTS19B.1

10 MOBITEK TERMINAL SPECIFICATION REFERENCE LIST

This document includes a number of references, made to other sections in the terminal specification. The list below shows these references, together with the page(s) they are made on. Please note that a section could be referred to several times on the same page.

R1-09, 3
R1-16, 3

Below are the reference designations listed.

<u>Reference</u>	<u>Section</u>
R1-01	Arrangement of the documents
R1-02	MOBITEK System description
R1-03	General description of terminals
R1-04	Terminology
R1-05	References
R1-06	Network operator information
R1-08	Application layer
R1-09	Network layer
R1-11	Interface requirements, fixed terminals
R1-12	Other requirements, fixed terminals
R1-16	Link layer, mobile terminals
R1-17	Physical layer, mobile terminals
R1-18	Radio equipment, mobile terminals
R1-19	Other interfaces, mobile terminals
R1-20	Other requirements, mobile terminals

Bildkurz

Bezeichnet

A 292 51333

REQUIREMENT SPECIFICATION 1(9)

USCIB/IN P-100000 ET/SYS PES	FIGURE/FIGURE SUBJECT/FIGURE ET/SYS PES	No. No 1056 - A 296 5177/02 Ue	
USCIB/IN P-100000 ET/SYSC STT <i>57</i>		DATE 1990-02-26	REV A
Description Cantel Mobitex		P. No MTS20.2	
<p>SUMMARY</p> <p>The general requirements for MOBITEK mobile terminals are described in this document. These include environmental requirements, power supply requirements, the minimum requirements for controls and indicators and special requirements in connection with the type approval testing.</p>		Title MOBITEK	
		General requirements, mobile term.	
Bid/contract Report			

A 296 51530

Cantel Mobitex™

Doc No	1056 - A 296 5177/02 Ue	
Current Date	1990-02-26	Rev A
File No	MTS20.2	

TABLE OF CONTENTS

1.1	Temperature	3
1.2	Relative humidity	3
1.3	Vibrations	3
2	POWER SUPPLY	4
2.1	Nominal voltage	4
2.2	Voltage limits	4
3	MARKING	4
3.1	Electronic serial number check	4
4	CONTROLS	5
5	INDICATORS	5
6	TYPE APPROVAL TESTING	6
6.1	Equipment to be type approved	6
6.2	Normal test conditions	6
6.3	Extreme test conditions	6
6.4	Test connections, interfaces and controls	8
7	MOBITEX TERMINAL SPECIFICATION REFERENCE LIST	9

Bidsort

Repros

A 102 5153.3

Cantel Mobitex-

No. 1056 - A 296 5177/02 Ue		
Date 1990-02-26	Rev. A	Doc. MTS20.2

1 ENVIRONMENTAL REQUIREMENTS

The equipment must be operational also under the extreme temperature conditions. No error functions which can interfere with the operation of the MOBITEX network must occur under any environmental condition.

1.1 Temperature

The normal operational temperature range:

+15 to +35 degrees C.

The extreme operational temperature range:

-25 to +55 degrees C.

The equipment should be such that it is not damaged by storage in the temperature range of:

-40 to +70 degrees C.

1.2 Relative humidity

Mobil terminal should be able to withstand 20-75% RH.

1.3 Vibrations

The equipment should be able to withstand a vibration test in accordance with IEC publication 68-2-6:

10 - 55 Hz +/- 0,15 mm movement.

55 - 150 Hz 20 m/s square acceleration.

Sweep rate: 1 octave per minute

Duration: 2 hours in each of the three directions.

The equipment should not be in operation during the test but should comply with the requirements in the MOBITEX terminal specification after the test.

Budget:

Repairs:

Cantel Mobitex

Doc No	1056 - A 296 5177/02 Ue
Doc Date	1990-02-26 A
Doc No	MTS20.2

2 POWER SUPPLY

2.1 Nominal voltage

The nominal voltage is optional and should be stated by the manufacturer.

2.2 Voltage limits

Equipment designed for working from lead acid accumulators in a vehicle should comply with the specifications when the voltage varies from 0.9 to 1.3 times the nominal voltage.

Equipment designed for operating on an alternating voltage should comply with the specifications when the voltage varies by +10%.

If these limiting values are exceeded, error functions which can interfere with the operation of the network should not occur.

3 MARKING

The equipment should be clearly marked with the manufacturer, type designation, serial number, approving text ("Approved by ...") and registration number of the type approval. The marking should be engraved on metal and permanently fixed to the equipment.

The mobile terminal's subscription number should be clearly visible or accessible.

3.1 Electronic serial number check

The serial number should be stored together with the terminal subscription MAN and permanently in such a way that they are impossible to change by software or by unauthorised persons, preferably in encrypted form.

The serial number of the equipment should be checked in the terminal against the serial number stored together with the MAN at power on. If the numbers are not equal, it should be impossible to use the equipment.

In addition, the serial number (ESN) is sent to the network at "activation", to be checked with the serial number stored in the network (see reference R1-09).

Blanket

Reprod

Cantel Mobitex

No. 24
1056 - A 296 5177/02 Ue
Date of issue
1990-02-26 A
Rev. 2
MTS20.2

4 CONTROLS

There are no requirements for type approval of controls. There are certain recommendations however.

If number keys for number keying are used, they should comply with one of the following minimum configurations.

1 2 3 4 5 * A B
6 7 8 9 0 # C D

1 2	1 2 3 A
3 4	4 5 6 B
5 6	7 8 9 C
7 8	* 0 # D
9 0	
* #	
A B	
C D	

The following recommendations apply for the A, B, C and D keys. The D key should have the data send function. If there is a speech facility, key C is used for "speech request". The key should be marked with T. Keys A and B can be used for status or another function and marked according to use.

International standards should be followed if a completely alphanumeric keyboard is used. The number keys on the keyboard can then be used for number keying as well.

5 INDICATORS

An indicator with yellow or amber colour should indicate when the power is switched on.

An indicator with green colour should indicate with a steady light when the mobile terminal is in contact with the MOBITEK network and with a twinkling light when it is not (base search mode).

Bidder:

Repro:

Cantel Mobitex

Doc No	1056 - A 296 5177/02 Ue	
Issue Date	1990-02-26	Rev A
		File MTS20.2

6 TYPE APPROVAL TESTING

Except the equipment described in the chapters below, requirements may be specified by the network operator (please refer to reference RI-06) for equipment such as:

- Portable antennas
- Cabling and terminations
- Terminal display

6.1 Equipment to be type approved

The type approval test applies to the radio equipment and to the physical, link and network layers of the mobile equipment according to these specifications. Application layer functions are only tested if under special requirements when installed.

The type approval only applies to the software tested. If a change is made in any software stored in the same storage unit as the software handling the tested functions, a new type test must be made. The testing authority should determine at its discretion and based on documentation of the modifications, whether new measurements are necessary for a new approval.

Optional terminal equipment to be connected to the radio control unit is not type tested.

6.2 Normal test conditions

The mobile terminal should be tested in the normal environment stated above. The specified data should be complied with for all combinations.

Terminals designed for operating on lead acid accumulators in vehicles should be tested at 1.0 times the nominal voltage.

The terminal should be ready for operation within 1 minute of switching on the power.

6.3 Extreme test conditions

Additional environmental requirements can be made in reference RI-06 (Network operator information).

Budget

Reprod

A:292 51533

Cantel Mobitex

No. 24 1056 - A 296 5177/02 Ue	
Version: Spec 1990-02-26 A	Rev MTS20.2

The mobile unit should be tested at the lower and upper limits in the temperature and voltage ranges stated above.

Before testing is carried out, the equipment should have achieved thermal equilibrium in the test chamber. The power supply should be switched off during this period. Measurements should be carried out in such a sequence and with relative humidity controlled so that excessive condensation does not occur.

Testing at the upper temperature limit should begin with the sender in the send position for 1 minute and receiving for 4 minutes after which measurements are carried out.

Testing at the lower temperature limit should commence 1 minute after switching on the power supply.

Buskers

Raynot

A 2951553

Cantel Mobitex-

N° 1056 - A 296 5177/02 Ue

Quoted Date 1990-02-26 A Rev F. 2.2 MTS20.2

6.4 Test connections, interfaces and controls

For the type approval test, the mobile terminal should be equipped with test connections and manual controls to permit the measurements that are necessary to verify that the specification requirements are complied with. This applies particularly to the requirements stated in reference R1-18 ("Radio equipment, mobile terminals" and "Measurement methods"). These connections and controls can be implemented by external test adaptors during the test.

For the type approval test, the equipment should also be equipped with the "Machine interface (MASC)" as described in reference R1-19 ("Other interfaces, mobile terminal", minimum basic and type test functions). This interface can be implemented by an external test adaptor during the test.

Equipment intended to be used as partially active in MOBITECH should be possible to operate as a normal mobile terminal during the tests, i.e. continuously listening to MOBITECH.

Submitt

Agreed

A.292 51333

Cantel Mobitex

No. 1056 - A 296 5177/02 Ue

Current Date 1990-02-26 A P. 2.2 MTS20.2

7 MOBITEK TERMINAL SPECIFICATION REFERENCE LIST

This document includes a number of references, made to other sections in the terminal specification. The list below shows these references, together with the page(s) they are made on. Please note that a section could be referred to several times on the same page.

R1-06, 6
R1-09, 4
R1-18, 8
R1-19, 8

Below are the reference designations listed.

Reference	Section
R1-01	Arrangement of the documents
R1-02	MOBITEK System description
R1-03	General description of terminals
R1-04	Terminology
R1-05	References
R1-06	Network operator information
R1-08	Application layer
R1-09	Network layer
R1-11	Interface requirements, fixed terminals
R1-12	Other requirements, fixed terminals
R1-16	Link layer, mobile terminals
R1-17	Physical layer, mobile terminals
R1-18	Radio equipment, mobile terminals
R1-19	Other interfaces, mobile terminals
R1-20	Other requirements, mobile terminals

Bidder

Repro

A 292 11593